


WARINING:


When changing the gears, the accelerator should be released and the car has completely come to a stop. Electronic steering wheel is an optional function, it can be self position. Prohibit to change the gear while the car is still moving, because that can damage the wire and other transmission parts.

2. Operating(function reference diagram)










Remote control instruction (optional)

Remote control specification

Supply voltage: 2 X 1.5V

Frequency: 2.4Ghz

Button operation instructions



backward: The car goes backward


Code: Pair the remote control with the car

Left: The car goes left Right: The car goes right

Speed: Adjust the speed, there are three forward gear speed, high speed,

middle speed and low speed.

Stop: Press and hold this button, the car will stop immediately and can't be operated whether in manual mode or remote mode. Release this button, the car will return to normal.



2.4G Remoter Control Instructions

For the first time need to code, this product has a memory function, repl-acement battery next time, you do not need to match the code Once again.

- ①.Long press "M" button more than three seconds, until the first LED lights flashing.
- ②. Open body power, first a long bright LED turns on the success of the code.
- ③.Remote control 10 seconds without operating automatic standby, pressany key to wake up.
- 4.Key Description: " \triangle " Forward, " ∇ " Back," \triangleleft " Left, " \triangleright " Right, "S" Speed, "P" Stop.

Press the "S" key to set the speed, a light is low, two lights for medium-speed, three lights for high-speed, the car back with only medium-speed

Press the "P" key to keep the brakes, the indicator full flash, press the brake button again to lift the brake.

How to pair the remote control?

- 1. Turn on the power of the car, press and hold car "code" button until the speed display led light starts to flash.
- 2. The speed display led light will stop flashing after a few seconds. Release the button, the light will turn off.

Remote control battery installation method:

Use a screwdriver to loosen the screw on the back of the remote control, open the battery cover and insert two AAA (1.5V) batteries, then close the battery cover and fix with screw. Pay attention to the battery polarity, if the indicator light on remote control turns on, it indicates the successful install tion. If the indicator light becomes dim or flashing, the battery needs to be replaced.

WARNING:

1 . When operating the car, the distance between the car which kid sit in and the remote control which operated by adults should not be more than 10 meters.

2 .The remote is only for adults to use, keep far away from child.

3 .Before using the remote, you must read the instruction manual carefully, and operate the empty car first, only when knowing the way of operation, you can use the remote with kid in the car.

4. Please switch to the "P"of the gear before you get on the car.

- 5. This product should not be used on traffic road and the place with water and obstacles.
- 6 . To Avoid damaging the circuit, please keep the remote control from wet and in rains.

7 .Don't mix old and new batteries and different brands of dry batteries.

8 . In order to avoid damaging the remote control, please take out the batteries if not use the remote control for a long time to avoid battery leakage and circuit corrosion.

9. Avoid dropping the remote control during using.

10. Install batteries with right polarity to avoid battery short circuit.


11.Charging must be done by adults. Non rechargeable batteries can't be charged.

12.Exhausted battery should be removed from the toy properly and prevent children from playing.

13. Take out the battery if no use for long time, properly handle the battery, and prevent children from playing.


14.If the remote distance is less than 3 meters, it means the battery is down in the remote control, it is time to change the 2 pieces of AA alkaline batteries.

How to insert batteries: Use screwdriver to loosen the screw on the back of the remote control, open the battery cover, and install two AAA 1.5V alkaline type batteries according to the diagram (Batteries are self-provided), then close the battery cover, and fix with screw.



CHARGING WAY

- •For Safety purpose ,the charging must be done by adults.
- •The first time you use it, please open the bonnet, connect two clip locks of red wires, use it only after charging 8-12 hours.
- Charging socket is locate on the dashboard, please follow the instructions to charge the battery.
- •If the car has slowed down, it needs to be charged by 8-12 hours, maximum 20 hours.
- 1. First insert the plug of the charger into the charging port. (The car can not be used.)
- 2. Then insert the charger to the power socket.





WARNING:

- 1 The toy is to be assembled by an adult. In unassembled state, it contains potentially hazardous sharp points & small parts, so please keep out of baby's reach.
- 2 CHOCING HAZARD Small parts.
- 3 Not for children under 3 yrs.
- 4 Always wear shoes.
- 5 RISK OF FIRE. Do not bypass. Replace only with circuit protection device.
- 6 Protective equipment should be worn. Not to be used in traffic.

Attention:

- ·Can only use the charger and battery according to manufacturers regulations.
- ·Do not mix old and new or different types of batteries.
- The battery terminal should not be short circuit.
- ·Do not open the battery or charger.
- Do not reverse the battery.
- ·Before charging, please check whether the charger, battery and plug are ok, if you find any broken parts, you must stop using it immediately. And do not use it until it is fully repaired.
- •The battery will be little warm when being charged, it is normal. If not, it may be caused from the short circuit of charger or circuit board.
- ·Must use the pressing plate to fix the battery.
- Run out of battery must be handled by adults, remove the battery which has run out from toys to recycle properly and shall not be arbitrarily discard.
- ·If the product is going to be stored unused long time, it must be fully charged, and charge it every 3 months, so as to make sure the battery life.
- Charger and Battery are not toys. Keep them away from children.

MAINTENANCE AND SERVICE

- 1, Before use, parents should check whether all parts like batteries, charger, wires, plug, outer body and other parts are in good condition, check whether the screws are loose and whether there are potential safety hazards. Any damaged parts founded should be repaired before using.
- 2, After using the product for a period of time, use a small amount of lubricating oil to the moving parts to prevent wear and tear of rust.
- 3, Keep the car away from fire and direct sunlight. Place it stably, not upside down. The car shall be stored indoors or outdoors under cover.

- 4, The car should be kept away from hot items, such as stoves or heaters, or the plastic parts will melt. When charging, the car should be kept away from inflammable materials to prevent it from catching fire.
- 5, Charge in time after use. Charging should be done by adults. If the product is going to be unused for a long time, it must be fully charged. Charge it every month so as to extend the battery lifespan.
- 6, A soft cloth must be used to clean the car. Do not use chemical solvents to clean the plastic parts. Do not use soap or water to clean the car. Driving in rainy or snowy weather, water can damage the motor, battery and circuit system.
- 7, When stopping or storing the car, please cut off the power and make sure all switches are in the 'STOP' or 'OFF' position.
- 8, Do not use fuses different from the specifications of this product.
- 9, Do not change the product structure and circuit system. Maintenance and repair work must be done under the guidance of the professional or technical personnel in place.
- 10, Do not use the product for other purposes. Put the battery in the right polarity.
- 11, Battery negative short circuit is prohibited. Non-rechargeable batteries cannot be charged.
- 12, Rechargeable batteries can only be charged under the supervision of the adult.
- 13. Do not mix old and new batteries or different types of batteries.
- 14, The battery running out of power should be removed from the car properly and not allowed to be played by children.
- 15, Disconnect the batteries completely when not in use and do not allow children to play with them.

TROUBLESHOOTING

Car does not move or power on	If "power" switch is in OFF position	
	If the fuse is not functioning properly	
	If the battery is not connected, check the red and black wires.	
	If the charger is plugged in, car will not power on. Unplug charger.	
	If the pedal switch is not functioning properly	
	If the wheels stuck and cannot move	
Car moves slowly	If the battery is not fully charged. Need to be charged in time	
	If there is an issue with the wheels	
	If rider weight exceeds specifications	
Battery does not charge	If the charger is malfunctioning	
	If the battery lost its capacity	
	If the charger and battery connection are charged	

