

PRIME® 2 Outlet Wall Tap with USB Chargers

Wall Tap Instructions:

1. Plug the wall tap into a properly grounded outlet. Connecting this product to an improperly grounded outlet will void all warranties.
2. The wall tap is now providing power.
3. Make sure electronic devices are turned off before plugging them in .

USB Instructions*:

1. Connect the USB charging cable for the device(not included) to one of the USB ports on the Prime wall tap.
2. Connect the other end of the USB charging cable** to the portable electronic device that requires charging. Indicator light is red while charging and turns green when fully charged.

*USB charging ports may not charge all devices. Some devices may require a proprietary USB power supply. Charging speeds may vary by product.

**USB charging cable is not included. Ensure compatible USB charging cable is used. Refer to the charging instructions in the owner's manual of your portable electronic device.

FCC Statement:

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult with the dealer or an experienced radio/TV technician for help.

Warning: Risk of fire or electric shock – Do not use in wet locations or with aquariums / Use indoors only / Do not use in receptacles that are not properly grounded / Do not exceed electrical ratings listed on product / Fully insert plug / Do not attempt to perform repairs yourself / Do not use with heaters or heat producing devices

IC REGULATORY STATEMENT

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication. This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Limited 5 Year Warranty:

Prime warrants to the original purchaser of any Prime wall tap for 5 years after purchase, that the wall tap shall be free from defects in design, material, or workmanship. Prime will correct defects in its wall taps by repair or replacement, at its option, if within fifteen (15) days of the discovery of the defect the wall tap is returned with proof of purchase, and it is deemed by Prime to be covered under the Limited Warranty, as outlined above. Please refer to

<http://www.primewirecable.com/images/PDFmanualswarranties/PRIMEUSB05.pdf> to read our complete safety instructions, warranty and claim procedures including maximum coverage and other limitations.

For additional assistance or information please call our customer service department, toll free, at 1-888-445-9955 or visit our website at www.primewirecable.com

Prime Wire & Cable, Inc. - 1330 Valley Vista Drive, Diamond Bar, CA 91765