

**CAR COVERS
AND SHELTER**



Assembly instructions from TSS **OZ SHADE STABLE**

4010mm W x 4060mm L x 3050mm Apex

Assembly Instructions



RECOMMENDED TOOLS



Please read instructions **COMPLETELY** before assembly. This shelter **MUST** be securely anchored.

THIS IS A TEMPORARY STRUCTURE AND NOT RECOMMENDED AS A PERMANENT STRUCTURE.

Before you start: 2+ individuals recommended for assembly, approximate time 2 hr.

CAR COVERS AND SHELTER



ATTENTION:

Please read and understand the installation detail, warnings and cautions prior to beginning installation. If you have any questions contact your local dealer.

DANGER:

Prior to installation, choose the location of your shelter carefully.
DANGER: Keep away from electrical wires. Check for overhead utility lines, tree branches or other structures. Check for underground pipes or wires before you dig. DO NOT install near roof lines or other structures that could shed snow, ice or excessive run off onto your shelter.
DO NOT hang objects from the roof or support cables.



WARNING:

Risk of fire. DO NOT smoke or use open flame devices (including grills, fire pits, deep fryers, smokers or lanterns) in or around the shelter. DO NOT store flammable liquids (gasoline, kerosene, propane, etc.) in or around your shelter. Do not expose top or sides of the shelter to open fire or other flame source.



CAUTION:

Use CAUTION when erecting the frame. Use safety goggles during installation. Secure and bolt together overhead poles during assembly. Beware of end poles.

PROPER ANCHORING AND INSTALLATION OF FRAME:

PROPER ANCHORING OF THE FRAME IS THE RESPONSIBILITY OF THE CONSUMER.

We are not responsible for damage to the unit or the contents from acts of nature. Any shelter that is not anchored securely has the potential to fly away causing damage, and is not covered under the warranty. Periodically check the anchors to ensure stability of shelter. We cannot be responsible for any shelter that blows away.

NOTE: *Your shelter's cover can be quickly removed and stored prior to severe weather conditions.* If strong winds or severe weather is forecast in your area, we recommend removal of cover.

CARE AND CLEANING

A tight cover ensures longer life and performance. Always maintain a tight cover. Loose fabric can accelerate deterioration of cover fabric. Immediately remove any accumulated snow or ice from the roof structure with a broom, mop or other soft instrument. Use extreme caution when removing snow from cover - always remove from outside the structure. DO NOT use hard-edged tools or instruments like rakes or shovels to remove snow. This could result in punctures to the cover. DO NOT use bleach or harsh abrasive products to clean the fabric cover. Cover is easily cleaned with mild soap and water.

WARRANTY:

This shelter carries a full limited warranty against defects in workmanship. We warrant to the Original Purchaser that if property used and installed, the product and all associated parts, are free from manufacturer's defects:



Oz Shade Stable Check List

Check that you have all the required components.
Lay components out as shown below.



1. 4 x Base Rails
2. 6 x Portals
3. 3 x Nose Pieces
4. 6 x Spacers
5. 3 x Rachets

6. 4 x Ground Anchors
7. 6 x Top Hats
8. Screws
9. Canvacon Roof



STEP 1: BASE RAILS

Join base rails together using the 'slip fit' connection system.
Lock together with 4 screws at each join.
Measure the base rails so that they are 4010mm apart.



STEP 2: GROUND ANCHORS

Mark out where the ground anchors will go and hammer into the earth (as above).
Secure bolts to ground anchors hand tight.



STEP 3: ATTACHING BASE RAILS TO GROUND ANCHORS

Lay base rail over ground anchors, place saddles over base rails and secure to attach.



STEP 4: MAKING THE FRAME X 3

Join together your portals with the nose pieces using the 'slip fit' connection system (2 X portals and 1 x nose for each frame)
Screw together with 4 screws at each join.



STEP 5: COMPLETED PORTAL FRAMES

As each portal frame has been assembled place on top of each other.




STEP 6: ATTACHING FRAME TO BASE RAILS

Safely pick up the portal frame and slide it over and onto base rail pegs.

The front and back portal frames should be attached first.

Once the front and back frames are up, attach the centre frame making sure they line up.

Don't forget to screw the portal frames onto the base rail pegs.



STEP 7: FITTING 'TOP HATS'

Secure Top Hats on inside of portal frames, making sure one is 700mm from the centre nose and the other is 700mm from the shoulder.



STEP 8: ATTACHING COVER

Pull Canvacon cover over the frame.



STEP 9: FIXING COVER TO FRAME (SIDE ONE)


Join and insert 30mm x 30mm rail into sleeve on one side.
Tighten front and rear endless straps to pull cover over frame.
Then secure with 'Z brackets' to the 3 portal legs on the outside of the Shade Stable. This locks the 30 x 30 rail in place.



STEP 10: FIXING COVER TO FRAME (SIDE TWO)

Join and insert 30 x 30 rail into sleeve.

Tighten using ratchet straps.
Leave for 5 days to stretch cover over frame (tighten if required).
Then use 'Z brackets' to lock cover in place.
Once this is done, remove ratchet straps.



STEP 11: INSTALLING SIDE PANELS (OPTIONAL)

Install side panels (optional)
Put in place and lock with pins.



COMPLETED PRODUCT



info@carcoversandshelter.com.au
1300 851 038

