

Airless Piston Filling Instructions

Information on Fill Level

In order to avoid leakage of the bulk through the orifice, while snapping the pump onto the container, listed fill levels in the table below should not be exceeded.

When dispensers are extremely underfilled, the resulting air pocket between the bulk and the bottom of the pump might cause a higher number of strokes to prime. High underfilling or big air pockets, embedded inside the bulk, can result in leakage problems during air freight. In order to avoid air pockets, we recommend using diving fill nozzles.

