

LED 9W PLUG & GO™ CFL

INSTALL INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE INSTALLATION.

THE INSTALLATION SHOULD BE PERFORMED ONLY BY A QUALIFIED ELECTRICIAN IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE (NEC) AND RELEVANT LOCAL CODES.

WARNING - Risk of fire or electric shock. This product must be installed in full accordance with applicable electrical and building codes.

This retrofit kit is accepted as a component of a luminaire where the suitability of the combination shall be determined by authorities having jurisdiction Suitable for IC or non-IC recessed luminaires with through-branch wiring marked: max. 4 of if 12 AWG conductors.

Do not install in a pre-heat luminaire.

This lamp only operates on electronic ballasts. Check the ballast compatibility report to make sure the ballast is listed. If not, don't make this retrofit.

If the lamp does not light when the luminaire is energized, remove lamp from luminaire and contact manufacturer or a qualified electrician.

RISK OF FIRE - If the lamp or luminaire exhibits undesirable operation (buzzing, flickering, etc.) Immediately turn off power, remove lamp from luminaire and contact the manufacturer.

This device is not intended for use with emergency exit features or emergency exit lights.

Suitable for use in dry and damp locations.



WARNING - RISK OF ELECTRICAL SHOCK - TURN OFF MAIN POWER SWITCH BEFORE INSPECTION, INSTALLATION OR REMOVAL.

1. Turn off the power to the luminaire before removing the lamp.
2. Remove the diffuser, lens cover or louver (if provided).
3. Check the ballast compatibility report to make sure the ballast is listed. If not, don't make this retrofit.
4. Remove the fluorescent lamp.
5. Replace with LED Lamp.
6. Make sure that the pins are completely seated in the lampholder.
7. Repeat steps 3-5 as need for additional lamps. One LED lamp for each fluorescent lamp removed.
8. Replace the diffuser, lens cover or louver (if removed in step 2).
9. Turn the power to the luminaire back on.