



User Manual

Electron

A. Button and Function Overview

A Key: Backlight/Reset/Delete Data

B Key: Short Press for Function Mode/Long Press for Settings


C Key: Altitude Measurement

D Key: Digital Compass



- Hour, Minute, Second, Month, Date and Week display (From 2000 to 2099)
- Dual Time Display
- Double Alarms
- Stopwatch (Measuring Capacity 99:59:59)
- Countdown (Measuring Capacity 99:59:59)
- Pedometer Mode
- Pace Counter
- 12/24 Hour Display
- LCD Contrast Setting
- EL Backlight (3s display)

B. Function Display



in any mode, press A key to turn on EL backlight for 3s; press B key for 2s to enter its setting mode.

II. Normal Time Display

- Long press the B Key for 2s to enter time setting mode. You will see the SECOND will be flashing and ready to set. If you do not set the time within one minute of entering this mode it will retain the original setting.
- Press the E Key to increase seconds/minutes/hours slowly. Long press the E Key to rapidly increase seconds/minutes/hours.
- Press the C Key to decrease seconds /minutes/hours slowly. Long Press the C Key, to rapidly increase seconds/minutes/hours.
- To set the LCD contrast you can increase contrast by pressing the E Key and you can decrease by pressing the C Key. Long pressing will cycle through your contrast rapidly in either direction. Contrast is on a 1-10 scale.
- Long press the B Key for 3 Seconds to leave time setting Mode.

III. PEDOMETER

- Press E Key to cycle through pedometer data (STEP/CALORIE/DISTANCE/SPORT TIME)
- Long press the C Key to start and stop the pedometer.
- Long press the B Key to enter pedometer settings (Unit of Measure/Footstep/ Weight/)

IV. Data History Query

- Your watch will record a full week of data history
- You cannot access data history that if you have not stored any C Key and D Key can be used to cycle through data history
- The data will automatically reset after 7 days

V. Setting the Alarm

- To turn ALARM mode on you are going to press the E Key. Your screen should display a “CHIME” to let you know its been selected.
- Now press the C Key to turn the ALARM mode on/off.
- To set the alarm time long press B Key for 3s and the minutes will flash. Now a short press on B Key will cycle between hours and minutes.
- Use E Key to increases hours or minutes.
- Use D Key to decrease hours or minutes.

The Alarm will sound for 20 second with a BELL SYMBOL on the screen, when your set time is reached.

- Any Key on the watch will silence the alarm.
- Long press the B Key for 3s to exit ALARM mode.
- You have the option to set 2 alarms if needed

VI. Stopwatch

- You will be able to measure up to 99:59:59:59.
- Enter stopwatch mode.
- Press C Key to zero your stopwatch when it reaches its max time.
- Press E Key to start/stop your counter.
- Long press the C Key to take the counter back to zero.
- While the stopwatch is running you can press the C Key to create 1 of 99 laps.

By long pressing the B Key you can enter LAP query mode. This will be invalid if you don't have any laps saved.

- Press the E Key to search your laps in ascending order.
- Press the C Key to search your laps in descending order.
- Press A Key or B Key to exit LAP mode.

VII. Countdown

- You will be able to countdown from 99:59:59
- It will ring 30s when the countdown time is 00:00:00

Setting the Countdown

- Long press the B Key for 3s to enter

Countdown Mode.

- Press the B Key again to enter setting mode.
- Press E Key to increase the countdown time.
- Press C Key to decrease the countdown time.
- Long Press B Key for 3s to Confirm your countdown setting.

Using the Countdown

- Use the E Key to start/pause and restart your countdown.
- To restart your current countdown simply press the E Key to pause and then C Key to return the countdown to its original data.

VIII. Pacer Metronome

- In Metronome Mode press C Key to turn on/off the metronome.
- Long press the C Key for 2s to return to zero when the mode is paused.
- The metronome will reset, if its not stopped, when the counter reaches 99999.
- In the metronome mode long press, the B Key for 2s to enter the beat frequency setting.
- Press the E Key to increase your setting data.
- Press the C Key to decrease your setting data.
- Long press the B Key to exit setting mode

IX. Dual Time

- You can run two separate times. T1 and T2.
- In T2 mode long press the B Key for 3s and the second will begin flashing.
- E Key will increase second and D Key will decrease seconds.
- By pressing the B Key again, the hours will begin flashing.
- Use the same keys to increase or decrease.
- Long press the B Key again to leave T2 setting mode

X. Monitoring Weather, Temperature and Barometer

- In Metronome Mode press C Key to turn on/off the Press the E Key to enter Barometer Mode. It is called BARO Mode.

Press E Key in the mode of Barometer, Temperature and Weather Forecast Mode. The measurements will be displayed as follows

EXAMPLE OF METRICS

- In this mode you can enter barometer and temperature manual calibration mode by long pressing B Key for 3s.
- The calibration items show as below:
AIRP TEMP F.DEF
- In Temperature mode press the E Key to increase and C Key to decrease temperature.
- To modify pressure, enter the Mode of Input Present Pressure Data.
- Use the E Key to increase pressure and C Key to decrease.
- Long press B Key for 3s to confirm and back to standard measurement mode.

Any issues? Reach out!

✉ info@BoltWatches.com

🖱 www.BoltWatches.com/Pages/Support-Center