

Energizer[®]



**Smart Door/Window
Sensor**

QUICK START GUIDE


Thank you for choosing the *Energizer*® Smart Door/Window Sensor. This quick setup guide will help you install and setup your Door Sensor.

Package includes:

- 1 – Door/Window Sensor
- 1 – Mounting screws and adhesive
- 1 – Quick Start Guide



Note: Your phone or tablet must be connected to your 2.4ghz WiFi network. *Energizer*® Connect devices can only be added to the app while on a 2.4ghz WiFi network.



CAUTION: Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

RADIO AND TELEVISION INTERFERENCE

This equipment has been tested and found to comply with the limits, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

You may also find helpful the following booklet, prepared by the FCC: "How to Identify and Resolve Radio-TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington D.C. 20402.

Changes and Modifications not expressly approved by the manufacturer or registrant of this equipment can void your authority to operate this equipment under Federal Communications Commission's rules.

Installing the Smart Door/Window Sensor



- 1)** Download the **Energizer® Connect** app from the Apple App Store (for iPhones) or Google Play Store (for Android phones). Before opening the app, make sure your phone is connected to the WiFi network your door sensor will be placed on.
- 2)** Open the app and create an account by following the on screen instructions.
- 3)** Press the latch button on top of the sensor and pull off the cover. Insert two AAA batteries (not included) into the sensor.



Note: The indicator light on the door sensor should start flashing quickly (about 4 times per second) for EZ pairing mode.


©2018 Energizer. Energizer and certain graphic designs are trademarks of Energizer Brands, LLC and related subsidiaries and are used under license by Jem Connected IOT, Inc. All other brand names are trademarks of their respective owners. Neither Jem Connected IOT, Inc. nor Energizer Brands, LLC is affiliated with the respective owners of their trademarks.

4) After logging in, click “+” on the top right of the screen.




5) Select “Door Sensor”



6) Confirm the indicator light on your door sensor is flashing quickly, then click next.



7) Confirm that the network WiFi displayed is your 2.4ghz WiFi network, enter your WiFi password and click confirm.



8) Your door sensor will now be connected to the network. Click finish device setup.



Your **Energizer**® Smart Door/Window Sensor is now ready to use. You can now get alerts when your sensor is opened or closed. You can also automate other **Energizer**® Connect devices.

We hope you enjoy using your **Energizer**® Smart Door/Window Sensor. For frequently asked questions and instruction videos, please visit our website at www.energizerconnect.com.

Definition of Indicator Light


AP MODE	Slowly blinking (about 2 times per sec)
EZ MODE	Rapidly blinking (about 4 times per sec)

Troubleshooting:

If you need to reset or troubleshoot your device, simply hold down on the reset button for 5 seconds. The device will cycle between AP Mode and EZ Mode every time you hold down the reset button.

Installation:

1. The two parts of the Door Window Sensor should be placed in a manner such that when the door/window is closed, they are within 10mm from each other. By opening the door or window, the sensor body and magnet should separate in proximity.




Note:




- A. Door Window Sensor should not be mounted directly on or near metal framing or other large metallic objects since metal objects may weaken the radio signal strength.
- B. Door Window Sensor should only be placed indoors and away from water and other extreme weather conditions.


2. Ensure that the orientation marks of the sensor body and the magnet are oriented towards each other.



3a. Remove the back plate from the door sensor by holding down the latch button and pulling the back plate off.



3b. Or attach the double-sided mounting tape to the covers and to adhere to the wall, door or window frame.



Note:

Wipe clean the surface where the Door Window Sensor will be mounted.

Any dust and particles can reduce the adhesion of double-sided mounting tape.
