

***Energizer***<sup>®</sup>

™

**CONNECT**

**Smart Camera**


---

**QUICK  
START GUIDE**

Thank you for choosing the *Energizer*® Smart Camera. This quick start guide will help you with setup and installation.

## Package Includes:

- |                       |                       |
|-----------------------|-----------------------|
| 1 – Smart Camera      | 1 – 6 ft cable        |
| 1 – Quick Start Guide | 1 – Magnet            |
| 1 – USB power adapter | 1 – Double sided tape |



*Note: **Energizer**® Connect devices only work on a 2.4ghz WiFi network.*


©2018 Energizer. Energizer and certain graphic designs are trademarks of Energizer Brands, LLC and related subsidiaries and are used under license by Jem Connected IOT, Inc. All other brand names are trademarks of their respective owners. Neither Jem Connected IOT, Inc. nor Energizer Brands, LLC is affiliated with the respective owners of their trademarks.

# Pair the Smart Camera


1

Download the **Energizer®** Connect app from the App Store (for iPhones) or Google Play Store (for Android phones).

Before opening the app, make sure your phone is connected to the WiFi network that your smart camera will be placed on.



Download on the  
**App Store**





GET IT ON  
**Google Play**

# **Energizer®**

**CONNECT**

2

Open the app and create an account by following the on-screen instructions.




**Energizer**



2

Plug the camera into a wall outlet using the provided 6 foot cable and USB power adapter.





*Note: The indicator light on the camera should start blinking rapidly (about 4 times per second) for EZ pairing mode.*

AP MODE	Slowly blinking (about 2 times per second)
EZ MODE	Rapidly blinking (about 4 times per second)

4

After logging in, click “+” on the top right of the screen and select “Add Device”.




**Energizer**



4

5

Select "Camera".




**Energizer**



5

# 6

Confirm that the indicator light is rapidly blinking, then click next.



**Energizer**



6



7

Confirm that the network WiFi displayed is your 2.4ghz WiFi network, enter your WiFi password and click confirm.





**Energizer**



7

# 8


Your smart camera will now be connected to the network. Confirm the settings for your device and then click finish device setup.



## Installation Steps:

**STEP 1:**

Peel off back adhesive cover from magnet mount.


**STEP 2:**


Firmly place magnet mount on wall. Hold pressure for about 5 seconds to help create good bond.

*Note: For best results let sit for 10 minutes to fully stick.*


**STEP 3:**

Place camera base directly on magnet mount.





- 1** Camera Timestamp
- 2** Quality Switch: Toggle between High Definition (HD) and Standard Definition (SD)
- 3** Audio Switch: Enable camera audio so you can hear through the camera
- 4** Microphone Switch: Enable the microphone so you can speak through the camera. *Note: You cannot have both Audio Switch and Microphone Switch activated at the same time.*
- 5** Alarm Settings: Enable mobile notifications for motion detection
- 6** Manual Record: Begin recording the current live video of the camera directly to your smart device.
- 7** Device Settings
- 8** Recording Stamp
- 9** WiFi Signal Strength
- 10** Full Screen Landscape View
- 11** Recording Playback Controls (see next page for details)
- 12** Manual Screenshot: Save a snapshot of the current live video to your smart device.



- 1** Date: Shows the current date of recordings you are viewing
- 2** Date Controls: Click the arrows to go to the previous/next day of recordings
- 3** Camera Timestamp
- 4** Audio Switch: Enable the sound of the recording
- 5** Pause Button
- 6** Live View Controls (see previous page for details)
- 7** Calendar: Select a specific day to view recordings
- 8** Manual Screenshot: Save a snapshot of the current playback video to your smart device

- 9** Device Settings
- 10** Full Screen Landscape View
- 11** Recordings Timeline: Grey areas show when there is a saved recording device.
- 12** Time Marker: Scroll the line to choose the time of the recording you want to view.
- 13** Manual Record: Begin recording the current playback video of the camera directly to your smart device.

# Troubleshooting

If you need to reset or troubleshoot your camera, simply hold down on the power/reset button for 5-10 seconds.

## Pairing Modes:

**EZ mode:** The device's light is rapidly blinking for easy, quick pairing setup.

**AP Mode:** Access Point mode is a secondary setup process in which the device's light is slowly blinking and requires multiple steps for pairing. Follow the on-screen step by step instructions.



## **FCC Compliance**

This device complies with Part 15 of the FCC. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## Notice

### **RF Exposure Statement**

To satisfy FCC's RF exposure requirements, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during device operation.

To ensure compliance, operations at closer than this distance is not recommended.

***Energizer***

