

UniPrime

Acrylic Based Primer



Characteristics:

- Uniprime is an acrylic based universal wall / floor primer for use prior to the application of RLA Tile Adhesives.
- Uniprime increases the adhesion of RLA Tile Adhesives onto the substrate.
- Uniprime must be applied onto timber floors prior to using RLA Tile Adhesives.
- Uniprime can be applied onto concrete, timber and a variety of common building substrates.

Preparation:

- Ensure all surfaces are sound, dry and free from excessive movement, oil, dust, grease, wax, curing compounds, release agents, paint and any other loose contaminating materials.
- For non-porous surfaces like existing tiles, sheet vinyl etc or contaminated surfaces, use universal primer or consult your local RLA Office

Packaging / Shelf Life:

- When applying the primer onto floor surfaces it is recommended to firstly pour some primer in a section then spread the primer using a broom, brush or roller. Then continue this method of application until the entire area is primed. Note: This method of application ensures a thorough coat of the primer on the surface.
- Allow the primer to dry for approximately 10 minutes at 20°C prior to commencing tiling / waterproofing.

Coverage:

- Coverage will vary depending upon the substrate. As a guide it will cover approximately 8-10m²/L

Clean Up:

- Excess primer, tools and other equipment can be cleaned up using water while the primer is still wet.

Packaging / Shelf Life:

- Uniprime is available in 1L, 5L and 20L Pails.
- A pail of Uniprime, when stored in a cool, dry environment, and is stored above ground level, will have a shelf life of approximately 12 months

Handy Tips:

- Do not apply Uniprime in temperatures above 40°C and below 5°C.
- For applications / situations not mentioned in this data sheet please contact your nearest RLA office.
- For a full SDS on this product please contact your nearest RLA office.

Technical Data

Appearance	White Liquid
Density	1.10 +/- 0.05
Drying Time	Approx 30 minutes @ 20°C

Disclaimer: The information supplied is to the best of our knowledge true and accurate. The actual application of the product is beyond the manufacturers control. Any failure or damage caused by the incorrect usage of the product is not the responsibility of the manufacturer. The manufacturer insists that all workmanship must be carried out in accordance with AS 3958.1-2007. It is also the responsibility of the end user to ensure that the literature in their possession is the latest issue.