

GFRFCFT-1107 Large Ribbed Cylinder Fountain (2 pieces)

COMPONENTS AND PARTS LIST



Water Feature
19.5"W x 24"H
63 lbs

Basin
19.75"W x 9.5"H
37lbs

Fountain holds
approximately 10
gallons of water

Pump Kit Parts List

PK300 pump (1)
Wedges (4)
#5 Drain Stopper

* Tubing has been preassembled

This fountain is compatible with a
#10 or #7 Refill Device

Tools you will need

Level



This fountain takes cover
FTNCOV-LG

GFRCFT-1107 Large Ribbed Cylinder Fountain (2 pieces)

ASSEMBLY INSTRUCTIONS

1. Make sure you are assembling your fountain on a level surface
2. Assemble the pump kit
 - a. **NOTE: Be sure to use the appropriate size adapter provided with the pump.**
3. Place the pump inside the base of the fountain.
4. Feed the pump cord through the standpipe in the center of the basin, leaving enough cord length inside of the basin to work with the pump sitting flat in the bottom of the bowl.
 - a. When the pump cord exits the base of the fountain, make sure it lines up with the channel that is cut into the bottom of the basin.
5. Slide the pump adapter into the provided tubing that is attached to the cylindrical water feature.
6. Place the cylindrical water feature on top of the basin
 - a. Center the cylindrical water feature on top of the basin.
 - b. Note – Do not allow pump to run dry, as it will cause damage to the pump

WINTER CARE AND GENERAL FOUNTAIN INSTRUCTIONS

- W I N T E R C A R E -

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with plastic, making sure that water will not accumulate in the basin or other fountain component and freeze.
- (4) Check fountain periodically to insure that plastic is secure and water is not accumulating in any fountain component.

- G E N E R A L F O U N T A I N T I P S -

Install fountains on a level surface. You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump cord will be threaded through this opening.

For more Campania product information visit www.campaniainternational.com