


INCLUDED PARTS:

(1) 100 ft roll of Welded Wire Mesh Fence

(1) Bag (100) UV Resistant Zip Ties

Please note: The components listed above are for a 100 ft kit. If you purchased a larger kit, components may vary. Ex: 200 ft version would include 2X the components listed above.


1 UNROLL WIRE MESH AGAINST FENCE



1A. Unroll a few feet of wire mesh and connect it with zip ties around your pickets as shown to pin it in place.


Generally, the best location to begin is in a corner but you can begin anywhere you like. It is best to unroll the fence in long spans, leaving the fencing section uncut from the roll to hold it against the fence until it has been secured.

2 FASTEN WIRE MESH TO PICKETS



2A. Once you have a span of fencing material rolled out against your fence and pinned in place, go back and secure zip ties around the fence pickets and wire mesh approximately every 3 feet at the top, middle, and bottom of the wire mesh.

3 INSTALLING AROUND GATES AND CORNERS



GATES

3A. Run wire mesh overtop of your gate as if it was a normal part of the fence line. Once you have secured zip ties around the gate posts on either side of the gate and the gate itself you are free to take tin snips, aviation snips, wire cutters or similar and trim away the wire mesh on the hinge and latch space around the gate as shown.

CORNERS

3B. Corners and angles are handled easily by simply cutting the wire mesh for any directional change. Unroll the wire to the corner, cut the wire mesh one full square longer than needed then proceed to zip tie the entire section before trimming any excess as needed.

4 REPEAT UNTIL THE FENCE GAPS ARE COVERED

4A. Repeat steps 1 and 2 around the entire fence until all gaps are covered.

Please Note: If you are using this system on something that the zip ties will not span to secure the wire mesh to your fence (ex: pickets are too large), you can modify the installation by using a different fastening method as indicated below. Please contact Dog Proofer for additional information.

Wood - Use heavy-duty "fence" or "Romex" staples (not provided) to hold the fencing to wood surfaces. If pickets are small enough, zip ties can also be used or compounded to span a longer distance.

Brick & Block - Can be installed on these surfaces as well. Specialty masonry fasteners will need to be used with washer heads to hold the mesh wire securely to the surface.