

FITTING DIAGRAM

FORD FOCUS MK4 ST: REAR DIFFUSER + FLOW-LOCK FINS

INSTALLATION AND FITTING SERVICES

If you are having any difficulties please seek professional advice from the listed International and Domestic Authorised Dealers on our website.

www.flowdesignsaustralia.com

BUMPER REMOVAL NOT REQUIRED


HANDY HINTS

- Unbolt 4 bolts mounting rear bumper to heat shield before drilling
- Clamp and align Flow Designs Rear Diffuser to rear bumper before drilling
- Insert Chicago Bolt between heat shield and bumper

HANDY HINTS


Place 3D printed standoff between aerospacer and bottom of OEM rear bumper

HANDY HINTS



- Align FLOW-LOCK Fins to their corresponding slots.
- Please ensure to allocate the correct FLOW-LOCK Fin to the correct corresponding slot (L1 into L1 slot, R1 into R1 slot etc.)
- Ensure textured side of fin is facing out from opposing fin
- Push fin firmly into the slots until a clicking sound is heard.
- Check both top and bottom locking tabs have securely seated.

Please Note : Once fins have been locked into position, they will be difficult to remove.



FITTING KIT

a

M6 BOLT
30mm LONG

X 3

CB
washer
3D print
spacer
OD 25



PLEASE NOTE:
DRILLING REQUIRED
TO FASTEN TO BUMPER

PLEASE USE 8mm DRILL BIT