



HOLDEN VE COMMODORE SERIES 1 FRONT SPLITTER INSTRUCTIONS

PLEASE SCAN QR CODE
TO WATCH INSTRUCTIONAL VIDEO
BEFORE INSTALLING



FITTING DIAGRAM

HOLDEN VE COMMODORE SERIES 1 : FRONT SPLITTER

INSTALLATION AND FITTING SERVICES


If you are having any difficulties please seek professional advice from the listed International and Domestic Authorised Dealers on our website.

www.flowdesignsaustralia.com

BUMPER REMOVAL NOT REQUIRED


----- FRONT BUMPER

ASSEMBLY GUIDE (d.)




To attach the the outer aerospace (d.) to the front splitter, insert the chicago bolt to the rear aerospace hole and connect with a M6 15mm bolt and washer through the bottom of the front splitter.

HANDY HINT



- Ensure that 3D printed spacer is inserted into aerospace for bolts (a.) and (b.) prior to installation
- Install M6 bolts within the front bumper and Chicago bolts below the front splitter for both bolts (a.) and (b.)



FITTING KIT SERIES 1

<p>a</p> <p>OD 25 SPACER CB WASHER</p>	<p>M6 BOLT 30mm LONG</p> <p>X 4</p> <p>PLEASE NOTE: DRILLING REQUIRED TO FASTEN TO BUMPER</p> <p>PLEASE USE 9mm DRILL BIT</p>	<p>b</p> <p>OD 25 CB WASHER</p>	<p>M6 BOLT 12mm LONG</p> <p>X 4</p> <p>PLEASE NOTE: DRILLING REQUIRED TO FASTEN TO BUMPER</p> <p>PLEASE USE 9mm DRILL BIT</p>	<p>c</p> <p>OD 25 SPACER CB WASHER</p>	<p>M6 BOLT 35mm LONG</p> <p>X 2</p> <p>PLEASE NOTE: DRILLING REQUIRED TO FASTEN TO BUMPER</p> <p>PLEASE USE 9mm DRILL BIT</p>	<p>d</p> <p>OD 25 CHICAGO BOLT</p>	<p>M6 BOLT 15mm LONG</p> <p>X 2</p> <p>PLEASE NOTE: DRILLING NOT REQUIRED TO FASTEN TO BUMPER</p>
---	---	--	---	---	---	---	---

INSTRUCTIONAL VIDEO QR CODE



PLEASE NOTE
FOR ADD ON ACCESSORIES

DO NOT
OVERTIGHTEN FASTENERS
INTO BRASS FITTINGS

HAND TIGHTEN ONLY

FLOW DESIGNS

FLOW DESIGNS

FLOW DESIGNS AUSTRALIA
ABN: 99 606 962 199
10 LONGSTAFF RD
BUNNINGS VIC. 3153

DESIGNED AND MANUFACTURED IN AUSTRALIA

TERMS AND CONDITIONS : MISUSE OF GOODS

By taking possession of this Flow Designs Australia product, you (the buyer) agree that you have read, understood and will comply with the following disclaimer:

- This product may not be suitable for road use in your area. We cannot be held liable for any penalties or infringements that may occur after installing any of our products.
- We cannot guarantee that this product will comply with subsequent aftermarket products you have applied to your vehicle.
- It is not legal to fit parts onto a road registered vehicle unless it carries and meets the design rules and public road regulations of your area, region and/or country.
- We do make our best effort to consider safety when designing our products, we want the scene to be a safe place for everyone! This disclaimer absolves us (Flow Designs Australia) of any and all liability for breaches to any requirement as a result of installation of our products.

www.flowdesignsaustralia.com