

FITTING DIAGRAM

HONDA ACCORD CU2 PFL/FL: FRONT SPLITTER INSTRUCTIONS

INSTALLATION AND FITTING SERVICES

If you are having any difficulties please seek professional advice from the listed International and Domestic Authorised Dealers on our website.

www.flowdesignsaustralia.com

BUMPER REMOVAL NOT REQUIRED

INSTALLATION NOTE:

REMOVE OEM WEATHER STRIP UNDER BUMPER PRIOR TO SPLITTER INSTALLATION

HANDY HINTS

Align corner of splitter to back edge of bumper before drilling for best fitment.


Trimming part of the guardliner near mounting hole may be required to ensure guardliner can be clipped back into position.

HANDY HINTS

Undo OEM clips / bolts for front undertray and bumper to allow access for mounting bolts. Remove clips to inner plastic tray through front lower grille before removing tray prior to installation.

Remove OEM weatherstrip before mounting splitter. Reinstall inner plastic tray and clips after installation of splitter.

INSTALLATION GUIDE FITTING KIT - D



Install 3d printed spacer with top lip facing down as shown in diagram above prior to installation of splitter. Push spacer into hole to lock into place.

HANDY HINTS

Mount bolts (b) and (d) through OEM holes. Install mounting bolts through bumper and holes for lower grille plastic trim.

FITTING KIT

<p>a</p>	<p>M6 BOLT 25mm LONG</p> <p>X 6</p> <p>PLEASE NOTE: DRILLING REQUIRED TO FASTEN TO BUMPER PLEASE USE 8mm DRILL BIT</p>
<p>b</p>	<p>M6 BOLT 40mm LONG</p> <p>X 2</p> <p>PLEASE NOTE: DRILLING NOT REQUIRED TO FASTEN TO BUMPER REPLACE OEM CLIP</p>
<p>c</p>	<p>M6 BOLT 40mm LONG</p> <p>X 2</p> <p>PLEASE NOTE: DRILLING REQUIRED TO FASTEN TO BUMPER PLEASE USE 8mm DRILL BIT</p>
<p>d</p>	<p>M6 BOLT 40mm LONG</p> <p>X 2</p> <p>PLEASE NOTE: DRILLING NOT REQUIRED TO FASTEN TO BUMPER REPLACE OEM CLIP</p>

PLEASE NOTE
FOR ADD ON ACCESSORIES

DO NOT OVERTIGHTEN FASTENERS INTO BRASS FITTINGS

HAND TIGHTEN ONLY

FLOW DESIGNS

FLOW DESIGNS
FLOW DESIGNS AUSTRALIA
ABN : 99 605 842 199
10 LONGSTAFF RD
BAYSWATER
VIC, 3153



TERMS AND CONDITIONS: MISUSE OF GOODS

By taking possession of the Flow Designs Australia product, you (the buyer) agree that you have read, understood and will comply with the following disclaimer:

- This product may not be suitable for road use in your area. We cannot be held liable for any penalties or infringements that may occur after installing any of our products.
- We cannot guarantee that this product will comply with all subsequent aftermarket products you have applied to your vehicle.
- It is not legal to fit parts onto a road registered vehicle unless it carries and meets the designs rules and public road regulations of your area, region and/or country.
- We do our best effort to consider safety when designing our products. We want the scene to be a safe place for everyone!

This disclaimer absolves us (Flow Designs Australia) of any and all liability or breaches to any requirement as a result of installation of our products.

www.flowdesignsaustralia.com