

FITTING GUIDE

VW AW POLO GTI: FRONT SPLITTER PAGE 1


INSTALLATION AND FITTING SERVICES

If you are having any difficulties please seek professional advice from the listed International and Domestic Authorised Dealers on our website.

www.flowdesignsaustralia.com


BUMPER REMOVAL NOT REQUIRED

STEP 1



- Install and fasten front splitter using bolts (c.) before drilling holes for bolts (a.) and (b.) to ensure best alignment


STEP 2



- For installation of bracket, first drill holes (a.) using the splitter as a guide.
- **When drilling holes (a.), drill through bumper and bottom layer ONLY of metal lower crash bar.**


PLEASE NOTE : Drill bottom side of OEM Cross Bar **ONLY**

STEP 3



- Fit Flow Designs Bracket **WITHIN** the front bumper and below the OEM Crash Bar.
- For correct alignment, align cut outs in bracket with tabs found within the front bumper.
- Place the lip of the OEM Crash Bar within the groove found on the Flow Designs Bracket

STEP 4



- Install bolts (a.), ensuring the bottom lip of the OEM Crash Bar remains within the groove found within the Flow Designs Bracket.

FITTING DIAGRAM

VW AW POLO GTI: FRONT SPLITTER PAGE 2


INSTALLATION AND FITTING SERVICES

If you are having any difficulties please seek professional advice from the listed International and Domestic Authorised Dealers on our website.

www.flowdesignsaustralia.com

BUMPER REMOVAL

NOT REQUIRED



a

**M6 BOLT
40mm LONG
X 5**

SS FLANGE NUT
OD 25

PLEASE NOTE:
DRILLING REQUIRED
TO FASTEN TO BUMPER
PLEASE USE 8mm DRILL BIT

b

**M6 BOLT
30mm LONG
X 4**

OD 16
OD 25


PLEASE NOTE:
DRILLING REQUIRED
TO FASTEN TO BUMPER
PLEASE USE 8mm DRILL BIT

c

**M6 BOLT
20mm LONG
X 2**

OD 18
OD 25

PLEASE NOTE:
DRILLING NOT REQUIRED
TO FASTEN TO BUMPER



FLOW DESIGNS

FLOW DESIGNS AUSTRALIA
ABN: 99 606 842 199
FACTORY 11
6-7 NICOLE CLOSE
BAYSWATER NORTH
VIC. 3153

DESIGNED AND MANUFACTURED IN AUSTRALIA

TERMS AND CONDITIONS : MISUSE OF GOODS

This Product application is not intended for public road registered vehicles within Australia. Regulations may vary from Countries outside of Australia. Please check your Country's and State's road regulations before installing on a vehicle intended for public road use.

Flow Designs Australia PTY LTD will not be liable for any liabilities in relation to any use of the goods other than in strict accordance with the Company's instructions and for the purpose and application for which the goods were supplied by the Company.

The Client undertakes with the Company:

- That it will acquaint itself with the requirements of all relevant government or statutory and other authorities, bodies or corporations relating to the goods and/or services and to the applications to which the goods and/or services are to be put;
- That at all times while the goods are in its possession or under its control it will comply with such requirements;
- That it will procure that any purchaser of goods from it will also acquaint itself with, and will comply with, such requirements;
- That it will indemnify the Company against any liability resulting from a breach of any such requirements.

www.flowdesignsaustralia.com