

## Gen6 Convertible Radar Harness.

On the convertible models you must lower the header trim panel to gain access to the connector at the seat belt presence sensor. A member on Camaro6 ( **MattDinOC** ) shared some info on how to perform this on a convertible. We are also including the GM instructions, from the service manual.


1. Flip down the sun visors and remove 4 little tabs to access screw heads and remove the screws. The picture shows one of the tabs. You can pry the tabs out by pushing a thin flat blade screwdriver in the outboard edge of the tab and removing it. Try not to drop them, as they are easily lost!
2. Use a trim removal tool to gently pry the A pillar trim loose as shown in the second picture. This trim piece doesn't need to be removed completely, as it will be held in place at the bottom end. If you want to remove it completely, you can pull it out, but it's a little hard to get it back in place, so I would say leave it dangling. Do this for both A pillars.
3. There is another screw on each side holding the header trim in place. Once the A pillar trim is loosened, you can access those last 2 screws and remove them.
4. With all 6 screws removed, now you can use your trim removal tools to pry the header trim piece loose. Work carefully, and eventually you'll have the whole thing free.



Loosen the A pillar trim by prying here




## Windshield Upper Garnish Molding Replacement



Windshield Upper Garnish Molding Replacement

Callout	Component Name
<b>Preliminary Procedures</b>	
<ol style="list-style-type: none"> <li><a href="#">Inside Rearview Mirror Replacement</a></li> <li><a href="#">Windshield Garnish Molding Replacement - Left Side</a> <a href="#">Windshield Garnish Molding Replacement - Right Side</a></li> </ol>	
1	Folding Top Cover [4x] <b>Procedure</b> Tilt the sunshade down toward the windshield to access covers.
2	Roof Panel Bolt [6x] <b>Caution:</b> Refer to <a href="#">Fastener Caution</a> . <b>Tighten</b> 2.5N·m (22 lb in)
3	Windshield Upper Garnish Molding <b>Procedure</b> <ol style="list-style-type: none"> <li>Disconnect the electrical connectors and unclip the electrical harness from the windshield inner side frame.</li> <li>Transfer parts as necessary.</li> </ol>




### Inside Rearview Mirror Replacement

Callout	Component Name
1	Inside Rearview Mirror Cover <b>Procedure</b> Using appropriate tool, release the bottom cover from the mirror.
2	Inside Rearview Mirror <b>Procedure</b> <ol style="list-style-type: none"> <li>1. Adjust the mirror to the full upward position.</li> <li>2. Place a flat-bladed tool through both lower holes on the mirror.</li> <li>3. Using the flat-bladed tool, rotate the mirror 90 degrees to remove the mirror.</li> <li>4. Disconnect the electrical connector.</li> <li>5. Using the flat-bladed tool, install the mirror by rotating the mirror until an audible click is heard. An audible click is heard when the mirror is fully seated.</li> </ol> <b>Note:</b> <ul style="list-style-type: none"> <li>• DO NOT grab the mirror to remove or to install, you will damage the mirror.</li> <li>• Ensure screwdriver is through both lower holes of the mirror or you will damage the mirror.</li> <li>• More force is required to remove the mirror than to install the mirror.</li> </ul>

© 2019 General Motors. All rights reserved.

### Windshield Garnish Molding Replacement - Left Side (Convertible)



### Windshield Garnish Molding Replacement - Left Side

Callout	Component Name
<b>Preliminary Procedure</b> Place the folding top assembly in a full down position to allow access to the windshield side garnish molding.	
1	Windshield Garnish Molding <b>Procedure</b> <ol style="list-style-type: none"> <li>1. Starting at the top, gently pull on the garnish molding to disengage the clips.</li> <li>2. { If equipped } Disconnect the electrical connector.</li> <li>3. Transfer components as necessary.</li> <li>4. Garnish clips must be seated in roof front header garnish molding lower prior to installing sealing clips.</li> </ol> <b>Note:</b> Tabs to be fully seated in instrument panel trim pad.