

# Installation instructions STOPPA

## Installation steps



### 1. Select suitable diameter

Select the size of the air-sealing plug to match the diameter of the conduit.



### 2. Pre-form the penetration

Punch through STOPPA using a conical object (nail or cartridge nozzle). Create a hole that is about 60% of the cable diameter.



### 3. Feed the cable through

Support STOPPA at the penetration point with your hand and pull the cable through the prepared hole.



### 4. Create an airtight bond with the conduit

Push the plug firmly into the conduit as far as it will go.



### 5. You're finished!

No further bonding is required.  
The flexible thermoplastic elastomer creates an airtight seal between the cable and conduit.



### 6. Note regarding conduit grommets

Conduits can be quickly and reliably integrated into the airtightness/windtightness layer using the ROFLEX 20 and ROFLEX 20 multi conduit grommets.

---

The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Further information about the application and construction can be found in the pro clima planning documentation. For queries please call the pro clima technical hotline on +49 (0)6202 278245.

---

**MOLL**  
**bauökologische Produkte GmbH**  
Rheintalstraße 35 - 43  
D-68723 Schwetzingen  
Fon: +49 (0) 62 02 - 27 82.0  
eMail: [info@proclima.de](mailto:info@proclima.de)