


■ Configurations:



⑦ 8g CO2 cartridge (May not include)

- ① Carry Ring
- ② Top Cap
- ③ Max. fill with CO2 (450ml or 15.5oz)
- ④ Stainless Steel bottle (up to 620ml or 21oz)
- ⑤ Cartridge inlet
- ⑥ Bottom Cap

■ How to Use

1		Turn top cap counter-clockwise to remove. For sparkling drinks, add beverage to or below Max Fill line. Replace top cap and tighten it clockwise.
2		Turn the bottom cap clockwise to open the cartridge inlet window, then fully insert one Drinkmate 8g cartridge with the smaller side in first.
3		To sparkle drink, hold bottle upright and turn bottom cap counter-clockwise to activate cartridge. Hold for 10 seconds so all CO2 is injected and sound stops. Never open cartridge door while CO2 is injecting.
4		After injecting CO2 and before opening the top cap, shake the whole bottle up and down 5-6 times to have a better mix of CO2 with your beverage.

5		Slowly unscrew the top cap about a quarter turn, then pause and observe if any foam comes out (no foam if just carbonating water), then slowly unscrew it fully. If the drink is too foamy, close / tighten the cap and let the foam calm down. Then repeat the process.
6		Remove the top cap and enjoy a bottle of sparkling beverage!
How to remove the empty cartridge?		<p>If the beverage is still in the bottle, keep the top cap tight on the bottle, then turn the bottom cap to open the cartridge window, flip the bottle to have the opening down then tap the bottle against your palm, and the empty cartridge should fall out.</p>

1. Important Safety Instructions

- Please read the manual and check your new device for any shipping damage before use.
- Thoroughly clean the bottle with soapy water and rinse before first use.
- **When the bottle is pressurized, always unscrew the top cap slowly (more than 3 seconds) and always aim it away from any person.**
- After using the bottle to carbonate anything besides water (such as juice or wine), immediately soak the top cap in water and rinse it after each use.
- DO NOT make any modifications or repairs to the unit and accessories. Repairs may be made only by our authorized service personnel. Unauthorized repair may void the warranty.
- The bottle storage ambient temperature range is 33F (+1C) to +104F (+40C). Avoid storage in direct sunshine or heat. Never store inside a freezer!
- Always keep the bottom cap at charger piercing position to guarantee the CO2 chamber window is closed, unless you need to load a new charger or eject it after use. **Never open the charger window too early while the CO2 is still charging.**
- Do not fill the beverage over the "Max. Fill-Line" if use CO2 charger. The less beverage the stronger the carbonation.
- Keep the bottle straight up (not tilted) when activating the bottom cap to inject CO2. Never aim the top cap toward a person during the injecting CO2 and depressurization process.
- **instaFizz is only for cold drinks.** Never add hot water (above +104F or +40C) into the bottle. This bottle cannot be used with hot coffee or tea.
- Never inject CO2 into an empty bottle.
- Only use Drinkmate brand 8g CO2 cartridges. Other brands of 8g cartridges that look similar may not work properly and even damage the device. **Using other brand cartridges may void the warranty!**
- Do not carry around or store the machine with a filled 8g cartridge inside the chamber. Only insert the CO2 cartridge when you are ready to carbonate a drink.

2. Remarks:

- Carbonating flavored beverages is OK, but you need to (i) fill to a reduced volume (below dented mark "Max. fill with CO2") (ii) after carbonation, slowly unscrew the cap to avoid a potential burst from foamy beverages, and close the cap if the foam is escaping; (ii) after the gas is fully discharged, remove the cap and immediately soak in water. Rinse and shake out water to avoid residue blockage of tubing lines.

6. LIMITED WARRANTY

This product is warranted to be free from defects in material and workmanship for a period of 6 months from the date of original purchase. During this period, your exclusive remedy is repair or replacement of this product or any component found to be defective, at our option; however, you are responsible for all costs associated with returning the product to us and our returning a product or component under this warranty to you. This warranty does not cover 8g CO2 cartridges, wear from normal use, use not in conformity with the printed directions, or damage to the product resulting from accident, alteration, abuse, or misuse. This warranty extends only to the original consumer purchaser or gift recipient. Keep the original sales receipt, as proof of purchase is required to make a warranty claim. This warranty may void if the product is used with accessories other than iDrink Products. We exclude all claims for special, incidental, and consequential damages caused by breach of express or implied warranty. All liability is limited to the amount of the purchase price. Every implied warranty, including any statutory warranty or condition of merchantability or fitness for a particular purpose, is disclaimed except to the extent prohibited by law, in which case such warranty or condition is limited to the duration of this written warranty. This warranty gives you specific legal rights. You may have other legal rights that vary depending on where you live. Some states or provinces do not allow limitations on implied warranties or special, incidental, or consequential damages, so the foregoing limitations may not apply to you. This is the only express warranty for this product and is in lieu of another warranty or condition.

TO MAKE A WARRANTY CLAIM, DO NOT RETURN THIS APPLIANCE TO THE STORE.

Please call 1.844.812.6241, or visit www.drinkmate.us. For faster service, locate the model, type, and purchase receipt numbers on your appliance.

iDrink Products Inc.

119 Jackson Industrial Drive, Ann Arbor, MI, 48103, USA
Toll-Free: 1-844-812-6241
Email: info@idrinkproducts.com
www.drinkmate.us

Model: Drinkmate 210
Version: 210-000-1A



Problem	Possible root cause	Solutions
Beverage is not quite fizzy after carbonation	1. beverage temperature is not cold enough 2. did not shake up and down to mix after carbonation 3. too much liquid	1. the colder the beverage, the better the fizz 2. always shake after carbonation 3. store the beverage in the pressurized bottle for extended time after carbonation 4. use a 2 nd 8g charger

5. Where to buy gas cylinders – Scan the following code for online purchase



Or search online to find authorized Drinkmate brand 8g CO2 retail locations

- Do not use for beverages with pulp or solid particles, nor for thick or very sugary drinks. These liquids will produce a large amount of foam during the gas depressurization process and may cause a mess when pressure is released.
- When you hear the sound of escaping gas stop when sparkling a drink, the process is complete.

3. How to clean?

- This bottle is not dishwasher safe due to its mechanism and plastic parts.
- It is okay to use a mild dishwashing detergent to clean the bottle and cap. Please rinse and shake dry.
- If bottle is stored for a long period, keep it dry.
- Do not soak the bottom cap in water. For cleaning, wipe it with a moisturized towel.

4. FAQ and tips

Problem	Possible root cause	Solutions
The rubber seal fell off from cartridge chamber when removing the empty cartridge	Removing the cartridge too early while it still has CO2 gas inside. The gas may blow the seal out.	With the cartridge window facing up, place the seal back into the cartridge chamber, then use an empty cartridge to push it to its original position.
The 8g CO2 cartridge cannot be ejected from the chamber	The cartridge's outer diameter is too large, causing it to stick inside. You probably used another brand of CO2 cartridge.	Find a strong magnet to help remove it, or use a knife to enlarge the hole by scraping off a thin layer of plastic.

drinkmate®

instaFizz Stainless Steel Carbonation Bottle

User Manual

