



UNIVERSAL GAMING STEERING WHEEL AND PEDALS

Instructions manual
Manuel d'utilisation
Manual de instrucciones
Manual de utilização
Benutzerhandbuch
Gebruikershandleiding
Istruzioni per l'uso



Steering axis / Axe de direction / Eje de dirección / Eixo de direção / Lenkspindel /
Stuuras / Albergo di direzione

D-PAD

Left paddle shifter /
Palette gauche /
Leva izquierda /
Pala esquerda /
Kontroller links /
Linkerhendel /
Paletta sinistra




Right paddle shifter /
Palette droite / Leva
derecha / Pala
direita / Kontroller
rechts /
Rechterhendel /
Paletta destra




Player indicator LED (on PS3) /
LED d'indication du numéro du joueur (sur PS3) /
LED indicador del número de jugador (en PS3) /
LED de indicação do número do jogador (na PS3) / LED-
Anzeige Spielernummer (PS3) /
Indicatieve LED met het nummer van de speler (op PS3) /
LED d'indicazione numero del giocatore (su PS3)

Port for pedalboard / Port pour le pédalier /
Puerto para los pedales / Porta para os pedais / Anschluss
für Pedale / Poort voor de pedalen /
Porta per la pedaliera



Left pedal /
Pédale gauche /
Pedal izquierdo /
Pedal esquerdo /
Linkes Pedal /
Linkerpedaal /
Pedale di sinistra

Right pedal /
Pédale droite /
Pedal derecho /
Pedal direito /
Rechtes Pedal /
Rechterpedaal /
Pedale di destra



USB port to plug the official PS4/XBOX ONE
controller / Port USB pour brancher la manette
officielle PS4/XBOX ONE / Puerto USB para
conectar el mando oficial PS4/XBOX ONE /
Porta USB para ligar o comando oficial
PS4/XBOX ONE / USB-Anschluss zur
Verbindung mit einem offiziellen Joystick
für PS4/XBOX ONE / USB-poort om de officiële
PS4/XBOX ONE-controller aan
te sluiten / Porta USB per collegare il joystick
ufficiale PS4/XBOX ONE



1. Before the first use

Thank you for purchasing the Universal Gaming Steering Wheel and Pedals. Before using the wheel, please read this instruction manual carefully and keep it for future reference.

2. Features

- The Universal Gaming Steering Wheel is compatible with PS4, XBOX ONE, PC & PS3
- It is compatible with all the racing games on those platforms
- An official controller is required to use the wheel on PS4 and XBOX ONE
- Compatible with all PC games (X-Input and Direct Input)
- 180 degree steering rotation
- Steering sensitivity control (3 positions)
- 6 programmable buttons for tailor made button configuration for use with different racing games
- Fully analog driving control for more realistic driving experience
- Spring-loaded acceleration and brake control pedals
- Connection to the console through USB port
- The cable connector design for pedals prevents an accidental disconnection of cable
- Super strong and long lasting suction cups for stabilizing

3. Installation

Set up the wheel on PS4

1. Make sure that the PS4 is turned off.
2. Plug the wheel cable into a USB port on the console.
3. Plug the cable from the pedals into the steering wheel.
4. Turn on the console.
5. Plug an official PS4 controller into the USB port located on the wheel, use the provided USB/Micro USB cable. **IMPORTANT** : the controller must be switched off.
6. The red LED of the wheel stays lit. Press the HOME button on the wheel to connect it to the console.
7. The steering wheel is now ready to use.

Set up the wheel on XBOX ONE

1. Make sure that the XBOX ONE is turned off.
2. Plug the wheel cable into a USB port on the console.
3. Plug the cable from the pedals into the steering wheel.
4. Turn on the console. Plug an official XBOX ONE controller into the USB port located on the wheel, use the provided USB/Micro USB cable. **IMPORTANT:** the controller must be switched off.
5. The red LED of the wheel stays lit. Press the HOME button on the wheel to connect it to the console. The wheel is now ready.

Set up the wheel on PC

1. Turn on the PC.
2. Plug the cable from the pedals into the steering wheel.
3. Connect the USB cable of the wheel to any of the USB ports of the PC. A Windows utility starts automatically to install the device. At the end of that operation, the LED n°1 remains on, the wheel is now ready to use.

IMPORTANT: The steering wheel uses the X-Input protocol by default, so it is compatible with the latest games. Some older games use the Direct Input protocol. To switch to Direct Input mode, press and hold the Home/Mode button for 3 seconds, the LED will flash to indicate the change. This mode will then be used by default. You can switch from one mode to another at any time by holding down the Home/-Mode button for 3 seconds.

Set up the wheel on PS3

1. Make sure that the PS3 is turned off.
2. Plug the wheel cable into a USB port on the console.
3. Plug the cable from the pedals into the steering wheel.
4. Turn on the console.
5. Press the HOME button on the wheel to activate the connection.
6. The player indicator LED stays lit in the middle of the steering wheel.

4. Programming function

You can now play GRAN TURISMO or any other racing games that use the default button configuration. For other games, you have 2 options to make the right button configuration:

You can either go to the Options/Controllers menu in the game and create your own configuration. The advantage is that you can save it for later gaming sessions.

IMPORTANT: The Universal Gaming Steering Wheel is identified as a "game controller" in the commands menu of the games. If you wish to modify the button configuration in the game, go to the "game controller" section, not to the "steering wheel" section. You can also use the programming function "on-the-go" on the UNIVERSAL RACING WHEEL. It enables you to create the configuration you want without going in the Options menu of the game, but that configuration will not be saved.

This wheel has a built-in program function: you can assign a new function to some buttons to make your own driving comfort and experience.

6 keys can be programmed:

- Left pedal
- Right pedal
- Left paddle shifter
- Right paddle shifter
- L3
- R3

Programming procedure

- Press simultaneously the OPTIONS and SHARE buttons for 3 seconds. The LED will be lit in green.
- Then press any of the 6 programmable keys (listed above) to set up a new function. The LED will flash green.
- Finally press the button that you would like to reassign to the programmable button. The LED turns off, the key is now programmed.
- Repeat the above steps to program other buttons if necessary.

Reset one programmed key

- Press simultaneously the OPTIONS and SHARE buttons for 3 seconds. The LED will be lit in green.
- Then press on the programmed key that you would like to reset. The LED will flash green.
- Press again on the same key. The LED turns off, the key is now reset to default.

Reset all the programmed keys

- Press simultaneously the OPTIONS and SHARE buttons for 3 seconds. The LED will be lit in green.
- Press again simultaneously on the OPTIONS and SHARE buttons for 4 seconds. The LED turns off, all keys are now reset to default.

You can also unplug the wheel for resetting the configuration.

5. Sensitivity adjustment

The sensitivity control is designed for a better steering control adapted to the different types of racing game environments, such as Off-Road, Grand Prix racing, etc. To adjust the sensitivity, press OPTIONS & SHARE simultaneously for 3 seconds, when the LED turns green, release the keys. Press on SHARE again to reset the current sensitivity. Then press several times on SHARE to select the expected sensitivity. The LED will flash in green to indicate the different options:

- **Medium sensitivity:** the LED flashes in green regularly.
Steering angle is small, good for quick turns racing games
- **High sensitivity:** the LED flashes in green quickly.
Steering angle is very small, good for very quick turns, corner turning, etc.
- **Low sensitivity:** the LED flashes in green slowly. Steering angle is normal.

6. Precautions of uses

- Do not use this product for other purposes than the ones described in this document.
- The wheel should not be used in humid places, splashed or be placed near objects filled with liquids, such as vases. After use, keep the wheel in a dry place.
- Never attempt to disassemble or reconstruct it by yourself.
- Do not apply any excessive pressure to the device.
- Stop using this unit immediately if you begin to feel tired or if you experience discomfort or pain in your hands and/or arms while operating the product. If the condition persists, consult a doctor.
- Take breaks every 30 minutes.
- Place the wheel away from direct sunlight, excessive heat, fire or extreme cold. Exposure to extreme temperatures may damage the body and the internal circuitry of the device.
- Do not let unattended children play with the wheel. Do not allow children to play with cords. This product contains small parts that may cause choking if swallowed. This product is not intended to be used by children under 3 years of age.

7. Contact and Customer Support

Please feel free to contact Numskull for more information about the Universal Gaming Steering Wheel and Pedals, or other products in our range of peripherals.

Email: hello@numskull.com Tel: (+44)1707 800881

9. Respect the environment



In order to protect the environment, please do not discard electric/electronic devices and appliances with household garbage. Please take them to a recycling collection centre.

Australia & New Zealand Technical and Warranty Support

These goods come with guarantees that cannot be excluded under the Australian Consumer Law and New Zealand Consumer Guarantees Act. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

If purchased in Australia or New Zealand, this product comes with one year (12 months) warranty from date of purchase.

Defects in the product must have appeared within one year from date of purchase, in order to claim warranty. All warranty claims must be facilitated back through the retailer of purchase in accordance with the retailers returns policy and procedures.

Any expense incurred as a result of returning the product to the retailer of purchase are the full responsibility of the customer.

AUSTRALIA

**Bluemouth Interactive
Level 2, 2 Darling Street
South Yarra
VIC 3141
Phone: (03) 9867 2666
Email - Support@bluemouth.com.au
Visit - www.bluemouth.com.au**

NEW ZEALAND

**Fiveight Distribution Ltd
Unit B, 39 Westpoint Drive
Hobsonville
Auckland 0618, New Zealand
Phone: (64) 9 479 1530
Email - info@fiveight.co.nz Visit -
<http://www.fiveight.co.nz>**