

ATOMIC DIGITAL OFFICE CLOCK




MODEL: 513-1419-WAV4
DC: 110218


Full manual can be found under the Support tab here: bit.ly/513-1419-WAV4

POWER UP

1. Insert 2-AA batteries into your Wall Clock.
2. Complete basic Settings.



WWVB ATOMIC TIME SIGNAL

- After an initial search, the clock will automatically search for the WWVB Atomic Time Signal at UTC 7:00, 8:00, 9:00, 10:00, and 11:00.
- The Atomic Time Signal Icon  will flash while searching, and be solid when connected.
- Hold the MINUS (-) button anytime, to manually search for the atomic time signal.

For information about WWVB Atomic time visit: bit.ly/AtomicTime

SETTINGS

1. Hold the MODE button to enter the Settings Menu.
2. Press the + or - buttons to adjust values.
3. Press the MODE button to confirm and move to next item.
4. Press the SNOOZE button at any time to exit.

Settings Menu Order:

- Language (English or Spanish)
- Beep ON/OFF
- Atomic ON/OFF
- Time Zone
- Daylight Saving Time (DST) ON/OFF
- 12/24 Hour
- Hour
- Minutes
- Year
- Month
- Date
- Fahrenheit/Celsius

TIME ZONES


AST = Atlantic
EST = Eastern
CST = Central
MST = Mountain
PST = Pacific
AKT = Alaska
HAT = HAWAII

Note: When Español is selected, the following instructions and weekday will be presented in that language.

Note: Weekday sets automatically when Year, Month and Date are set.

CUSTOM DISPLAY

- Press and release the MODE button to select between Calendar, Indoor Temperature, Seconds, Full Weekday, or Date



OTHER BUTTON FUNCTIONS

SNOOZE:

- When alarm sounds, press SNOOZE to silence alarm for 10 minutes.

ALARM:

- Hold for two seconds to set Alarm Time. Use +/- buttons to adjust and ALARM to confirm.
- Press to view Alarm Time. Press again to activate/deactivate time alarm.

LOW BATTERY INDICATOR

- When battery appears in between the hours and minutes, replace batteries in your Clock.



WE'RE HERE TO HELP!

If you require additional support, call our friendly customer support team based out of La Crosse, Wisconsin.

Phone: 1.608.782.1610

Or fill out our online support request form here:

bit.ly/contact_techsupport

Our knowledgeable customer support team is available:

Monday-Friday, 8am-6pm CST.

JOIN THE CONVERSATION

Ask questions, watch detailed setup videos, and provide feedback on our social media outlets!



SPECIFICATIONS

Temperature Range: +32F to 99F (0C to 37C)

Update Interval: About every 60 seconds

Power: 2 AA (LR6, IEC) batteries not included

Battery Life: over 24 months

Dimensions: 9.84" W x 1.14" D x 7.48" H (25cm W x 2.9cm D x 19cm H)

WARRANTY INFO

La Crosse Technology, Ltd. provides a **1-year limited time warranty** (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

For Full Warranty Details, Visit: www.lacrossetechnology.com/support

CARE + MAINTENANCE

- Do not mix old and new batteries.
- Do not mix Alkaline, Lithium, standard, or rechargeable batteries.
- Always purchase the correct size and grade of battery most suitable for intended use.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries have with correct polarity (+ / -).
- Remove batteries from equipment that will not to be used for an extended period.
- Promptly remove expired batteries.

CANADA STATEMENT

This device complies with CNR Industry Canada license -exempt devices. Operation is subject to the following two conditions: (1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Increase separation between equipment & receiver.
- Consult the dealer or an experienced radio/TV technician for help.

This device must not be co-located or operating in conjunction with any other antenna or transmitter.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

CAUTION!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized changes or modifications to this equipment. Such changes or modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher.

This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and patents are recognized.



WARNING: This product can expose you to chemicals including styrene, which is known to the State of California to cause cancer. For more information go to: www.P65Warnings.ca.gov