

Wireless Color Temperature Station




For online video support:
http://bit.ly/308-1415_SetupGuide

Model: T85258 DC 111016

Protected under U.S. Patents:
5,978,738 | 6,076,044 | RE43903

Initial Setup

1. Insert 2 "AA" batteries into the TX141-Bv2 temperature sensor.



2. Insert 5 Volt AC adapter into the wall outlet, then into the temperature station.

3. Insert 2 "AA" batteries into the temperature station (optional).

4. After 5 minutes place sensor outside in a shaded location.

LCD Icons



Indoor Temperature Icon



Low Battery Indicator for Station



Temperature °F/°C



Outdoor Temperature Icon




Low Battery Indicator for Sensor




Temperature Trend (3 hours)



Sensor Reception Icon




Buttons




Weekday or Date Display

- Press and release the MODE button to display either the weekday or month, date and year.
- The station will remain on the display chosen.

Weekday Display



Month, Date, Year Display



Backlight HI/LO/OFF

- When operating with the AC adapter, the constant backlight is adjustable.
- Press the LIGHT button to change the backlight brightness (HI/LO/OFF)
- If operating on batteries alone, press the LIGHT button to activate the backlight for 10 seconds.

Settings

- Hold the MODE button for 3 seconds to enter setting mode.
- Use the + or - buttons to adjust a value.
- Press the MODE button to confirm and advance.
- Press the LIGHT button at any time to exit.

Setting Order:

1. Language (English, Spanish, French)
2. Beep ON/OFF
3. 12 hour or 24 hour time format
4. Hour
5. Minutes
6. Year
7. Month
8. Date
9. Fahrenheit/Celsius

Note: Day of the week will set automatically when year, month and date are set.

1. Choose Language



Weekday Language

English	Español	Français
Monday	Lunes	Lundi
Tuesday	Martes	Mardi
Wednesday	Miercoles	Mercredi
Thursday	Jueves	Jeudi
Friday	Viernes	Vendredi
Saturday	Sabado	Samedi
Sunday	Domingo	Dimanche

2. Beep ON/OFF



Month Language

English	Español	Français
JAN	ENE	JAN
FEB	FEB	FEV
MAR	MAR	MAR
APR	ABR	AVR
May	MAY	MAI
JUN	JUN	JUI
JUL	JUL	JUL
AUG	AGO	AOU
SEP	SEP	SEP
OCT	OCT	OCT

3. Select 12h or 24h

4. Set Hour

5. Set Minutes





6. Year

7. Month

8. Date

9. Fahrenheit or Celsius



HI/LO Temperatures Records

The indoor and outdoor HI/LO temperature records will reset daily at midnight. This provides a daily 24 hour HI/LO reading.

View HI/LO Temperature Records:





Press and release the + button to view in order:

- Outdoor HI temperature
- Outdoor LO temperature
- Indoor HI temperature
- Indoor LO temperature

English	HI	LO
Español	AL	BA
Français	HA	BA

Manually Reset HI/LO Records:

When HI or LO temperatures are showing, hold the + button for 5 seconds to reset all temperature records.



Follow Us on Social Media



Latest video content
http://bit.ly/LaxTech_YouTube



For personalized interaction
http://bit.ly/LaxTech_Facebook



Join the conversation
http://bit.ly/LaxTech__Twitter



Pin and share
http://bit.ly/LaxTech_Pinterest




Sensor Reception

- Hold the - button 3 seconds to search for the sensor.
- The signal reception icon will flash until the sensor signal is received or for 3 minutes if no signal is available.
- The signal will show solid when connected to the sensor.

Temperature Trend Arrow

The temperature (2°F/1°C) trend indicators update every 30 minutes. The trend reflects changes over the past 3 hours.

E.G.: At 3:00 — compares to 12:00 data;
at 3:30 — compares to 12:30.

Temperature increased 	Temperature did not change 	Temperature decreased 
--	---	--

Low Battery Icon

- Orange battery icon by indoor temperature: Change batteries in the temperature station.
- Green battery icon by outdoor temperature: Change batteries in the outdoor sensor.

Mount Temperature Sensor

- Mount the outdoor sensor on a north-facing wall or in any well-shaded area. Under an eave or deck rail is preferred.
- The maximum wireless transmission range to the forecast station is over 300 feet (91 meters) in open air; this does not include barriers such as walls or floors.
- Be sure the outdoor sensor is mounted vertically.

Restart

When the outdoor readings show dashes:

- Bring the sensor in the house five feet from the station.
- Remove batteries from the sensor, and the batteries from the station.
- Press any button 20 times.
- After 15 minutes insert batteries into the sensor, and into the station.
- Wait 15 minutes to establish a strong connection.
- Place sensor outside in shaded location.

Specifications

Indoor	<ul style="list-style-type: none">• Temperature Range: 32°F to 122°F (0°C to 50°C)
Outdoor	<ul style="list-style-type: none">• Temperature Range: -40°F to 140°F (-40°C to 60°C)• Temperature Range: Over 300 ft. (91 meters)• RF 433MHz (open air)
Power	<ul style="list-style-type: none">• Weather Station Primary AC Power: 5-volt AC power adapter (included) AC6#: GPU280500150WA00• Optional: 2-AA, IEC, LR6 batteries (not included)• TX141-Bv2 Sensor: 2-AA, IEC, LR6 batteries (not included)
Battery Life	<ul style="list-style-type: none">• 24 months with reputable batteries brands
Dimensions	<ul style="list-style-type: none">• Station: 5.98" H x 3.24" W x 2.16" D (152 x 82.5 x 54.9 mm)• Sensor: 5.11" H x 1.57" W x 0.82" D (129.8 x 40 x 20.8 mm)

Warranty and Support

La Crosse Technology, Ltd. provides a 1-year limited time warranty (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

Before returning a product, please contact our friendly customer support or visit our online help:

Phone: 1-608-782-1610

Online: www.lacrossetechnology.com/support

View full warranty details online at:

www.lacrossetechnology.com/warranty_info.pdf

Care and Maintenance

- Do not mix old and new batteries
- Do not mix Alkaline, Standard, Lithium or Rechargeable Batteries
- Always purchase the correct size and grade of battery most suitable for intended use.
- Replace all batteries of a set at the same time.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed with correct polarity (+ and -).
- Remove batteries from equipment which is not to be used for an extended period.
- Promptly remove expired batteries.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off

and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device must not be co-located or operating in conjunction with any other antenna or transmitter.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized changes or modifications to this equipment. Such changes or modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher. This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent

editions. We disclaim any responsibility for any technical error or printing error, or their consequences.

All trademarks and patents are recognized.

Canada Statement

This device complies with CNR Industry Canada license -exempt devices.

Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.