

## WARRANTY INFO

La Crosse Technology, Ltd. provides a 1-year limited time warranty (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

For Full Warranty Details, Visit: [www.lacrossetechnology.com/support](http://www.lacrossetechnology.com/support)

## CARE + MAINTENANCE

- Do not mix old and new batteries.
- Do not mix Alkaline, Lithium, standard, or rechargeable batteries.
- Always purchase the correct size and grade of battery most suitable for intended use.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries have with correct polarity (+ / -).
- Remove batteries from equipment that will not to be used for an extended period.
- Promptly remove expired batteries.

## FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Increase separation between equipment & receiver.
- Consult the dealer or an experienced radio/TV technician for help.

This device must not be co-located or operating in conjunction with any other antenna or transmitter. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

### CAUTION!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized changes or modifications to this equipment. Such changes or modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher.

This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and patents are recognized.



**WARNING:** This product can expose you to chemicals including styrene, which is known to the State of California to cause cancer. For more information go to: [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

LA CROSSE®  
TECHNOLOGY

# WIRELESS RAIN SENSOR



Model: TX14R-BL


DC: 112718

View online at: [bit.ly/tx14r-bl](http://bit.ly/tx14r-bl)

## POWER UP

Insert 2- AA batteries into the rain sensor according to polarity.

1. Flip open both locking tabs on your rain sensor and lift off the funnel portion.
2. Pull up on the battery cover and remove.
3. Install 2-AA batteries according to polarity. Reposition the battery cover over the battery compartment, and firmly push down to lock it back into place
5. Remove cardboard and any tape around the rocker before use. These were used to protect the sensor from unwanted movement during shipping.
6. Place the funnel portion back over the sensor and re-secure the locking tabs.



## CLEAN RAIN SENSOR

1. Press the Locking Tabs on each end and lift off the funnel.
2. Gently remove debris or insects inside the rain sensor.
3. Clear debris from drain vents.
4. Clear debris from the rain funnel itself.
5. Reinstall the rain funnel.

**Note:** Do not oil the rain sensor.

## POSITION SENSOR

- Mount your rain sensor in an open area for a more accurate rain count.
- Placing the rain sensor on the ground provides the most accurate rainfall measurement as there is no wind shear. Unfortunately, since insects think of rain sensors as personal hotels, placing your sensor 3-6 feet above ground may deter the insects.
- This is a self-emptying sensor, but be sure your unit is not sitting in a depression that would prevent rain from draining out of the bottom.
- Your rain sensor should be accessible to allow for periodic cleaning of leaves or other debris that may clog the funnel.
- Install the Rain sensor on a level platform that is stationary and has a direct line of sight to your station.
- Insert mounting screws through the holes in the base of the rain sensor. Do not over tighten.
- Use the bubble level inside your sensor to be sure it is level.
- Avoid other wireless rain sensors as this can cause inaccuracy due to signal interference.
- The maximum wireless transmission range to the rain station is over 300 feet (91 meters) in open air, not including walls or floors.
- For video instruction, please visit: [bit.ly/Rain\\_SensorMounting](https://bit.ly/Rain_SensorMounting)

## SPECIFICATIONS

**Rain Range:** 0-393.6 inches (0-9999mm) over 300 feet open air  
433MHz RF

**Batteries:** 2-AA, IEC, LR6 batteries (not included)

**Battery Life:** over 12 months with reputable batteries.

**Dimensions:** 7.14" L x 3.43" W x 4.94" H (18.13cm L x 8.72cm W x 12.54cm H)