

Projection Alarm Clock




For online video support visit: <http://bit.ly/LaxTechTalk>

Table of Contents


LCD Features	1
Buttons	1
Setup	1
Set Time, Date, etc.	2
Projection Rotation Focus	3
Set Alarm	4
Deactivate Activate	4
Snooze	4
Backlight	5
Reset Button	5
Specifications	5
Visit Us on Social Media	5
Warranty and Support	6
Care and Maintenance	6
FCC Statement	7
Canada Statement	7

LCD Features

- ① AM/PM
- ② Time
- ③ Alarm
- ④ Weekday
- ⑤ Month/Date
- ⑥ Indoor Temperature




Buttons



Setup

1. Insert the 4.5-volt AC adapter into 120V AC wall outlet, and then plug the AC jack to the back of the unit.
2. Optional: Insert two AAA batteries (not included) to provide backup power to the clock.



Set Time, Date, Etc.

Note: Only press one button at a time when setting.

- Hold then release the **SET** button to enter time set mode.
- Press and release the **+** or **-** buttons to adjust the values. Hold to adjust quickly.
- Press and release the **SET** button to confirm and move to the next item.

Time set order:


1. 12/24 hour time format
2. Hour
3. Minutes
4. Year
5. Month
6. Date
7. Fahrenheit/Celsius

To begin: Hold the **SET** button 3 seconds to enter the settings:


1. 12/24 hour time



2. Hour




3. Minutes




4. Year




5. Month



6. Date



7. Fahrenheit | Celsius



Note: Weekday will set automatically when year, month and date are set. If weekday is incorrect, check the year setting.

Projection Rotation | Focus


Tip: The AC adapter must be plugged in for the projection to work.

Rotate Projection:

- The projected image can be rotated in 90 degree increments.
- Press and release the PROJECTION button to rotate the image.

Focus Projection:

- Use the Focus Wheel on the back of the projection arm to provide a clear projection image.




Set Alarm


- Hold then release the **ALARM** button to enter time set mode.
- Press and release the **+** or **-** buttons to adjust the values. Hold to adjust quickly.
- Press and release the **ALARM** button to confirm and move to the next item.

To begin: Hold the **ALARM** button to enter the settings:

1. Alarm Hour



2. Alarm Minutes



Deactivate | Activate the Alarm

The alarm will be active after setting. The alarm icon (clock) will show.


- To deactivate/activate, press and release the **ALARM** button to view alarm time.
- When alarm time is showing, press and release the **ALARM** button again to deactivate or activate the time alarm.



Active Alarm



Active Snooze



Snooze

When alarm is sounding, press **SNOOZE LIGHT** button to silence the alarm for 10 minutes.

- The snooze icon **Zz** will flash.
- Press any button except **SNOOZE/LIGHT** to silence the alarm for 24 hours.
- This is a crescendo alarm. It will sound for 2 minutes then shut off if no buttons are pressed.

Backlight

- **AC adapter:** Backlight and projection are on constantly.
- **Batteries only:** Press the SNOOZE/LIGHT button for a 3 second backlight and projection.

Reset button

- If the clock display appears distorted or is not responding to buttons, use a pen or paper clip to press and release the **RESET** button one time.
- This will reset the clock to default settings.

Specifications

Temperature Range: 32 F to 122 F (0C to 50C)
Power Clock: AC6 GPU280450150WAOO 4.5VAC adapter Optional: 2-AAA batteries (not included)
Battery life Clock: over 12 months with reputable batteries
Dimensions Clock: 5.9" L x 2.3" W x 4.4" H inch (150 x 60 x 112mm)

Visit Us on Social Media



For personalized interaction
http://bit.ly/LaxTech_Facebook



Latest video content
http://bit.ly/LaxTech_YouTube



Join the conversation
http://bit.ly/LaxTech__Twitter



Pin and share
http://bit.ly/LaxTech_Pinterest

Warranty and Support

La Crosse Technology, Ltd. provides a 1-year limited time warranty (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

Before returning a product, please contact our friendly customer support with questions or visit our online help:

Phone: 1-608-782-1610

Online Product Support:

www.lacrossetechnology.com/support

Product Registration:

www.lacrossetechnology.com/support/register

View full warranty details online at:

www.lacrossetechnology.com/warranty_info.pdf

Warranty Address:

La Crosse Technology, Ltd

2830 S. 26th St.

La Crosse, WI 54601

Care and Maintenance

- Do not mix old and new batteries
- Do not mix Alkaline, Standard, Lithium, or Rechargeable Batteries
- Always purchase the correct size and grade of battery most suitable for intended use.
- Replace all batteries of a set at the same time.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed with correct polarity (+ and -).
- Remove batteries from equipment when it is not to be used for an extended period of time.
- Promptly remove expired batteries.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device must not be co-located or operating in conjunction with any other antenna or transmitter.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized changes or modifications to this equipment. Such changes or modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher. This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and patents are recognized.

Canada Statement

This device complies with CNR Industry Canada license -exempt devices. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.