

MULTI-COLOR ALARM CLOCK

**FRONT
VIEW**


Manual Set Time, Perpetual Calendar,
Weekday and Low Battery Indicator

BUTTONS



Indoor Temperature with Trend Indicators,
Moon phase + Two Time Alarms.

**BACK
VIEW**



GET STARTED

Step 1: Insert 5 volt AC power cord into the wall then into the bottom of the alarm clock.

Step 2: Insert 2 *new* AAA Alkaline batteries (not included) into the alarm clock. Observe the correct polarity.

Restart: If there is no indoor temperature data after 60 seconds, unplug the AC adapter and remove batteries from the alarm clock, press any button 20 times. After 15 minutes, return to **Step 1** above.


SET TIME & DATE

1. Hold the **SET** button to enter time set mode.
2. Press the **+** or **-** buttons to adjust values.
3. Press the **SET** button to confirm adjustments and move to the next item.

TIME SET ORDER:

1. Hour
2. Minutes
3. Year
4. Month
5. Date

Press the **SET** button to exit, or wait 20 seconds without pressing buttons to return to the normal time display.



12/24 HOUR TIME FORMAT

- Press the **+** button to select 12 hour or 24 hour time format.



FAHRENHEIT/CELSIUS


- Press the **-** button to select temperature readings in Fahrenheit or Celsius.



ADJUST BACKLIGHT HI/LOW/OFF

When using A/C power:

- Press the **LIGHT HI/LOW/OFF** button to adjust the backlight.




When using Battery power only:

- Press the **LIGHT HI/LOW/OFF** button for a 10 second backlight.

USB CHARGING PORT

Charge a smart phone, camera or other devices when the alarm clock is plugged into a power outlet with the included 5V AC adapter.



- Connect your external device's USB charging cable (not included) to the USB charging port.
- Charging times will vary.
- **USB Power Output:** 1A maximum current. Charge 1A devices or devices that are self-regulating.

NOTE: This is a power-output charging port. It does not supply power to the alarm clock.

NOTE: Some USB cables are for data transfer only and cannot be used for charging. Make sure that the USB cable you use will charge your device. Most USB cables included with mobile devices will work for charging.

SET TIME ALARMS

Setting the alarm and activating the alarms are separate actions.

1. Press and release the **ALARM** button to select Alarm 1 or Alarm 2.
2. Hold the **ALARM** button for 5 seconds to enter alarm time set mode. The alarm hour will flash.
3. Press the **+** or **-** buttons to adjust the alarm hour.
4. Press the **ALARM** button to confirm and move to the alarm minutes.
5. Press the **+** or **-** buttons to adjust the alarm minutes.
6. Press the **ALARM** button to confirm and exit.




Alarm Time setting order: 1. Hours, 2. Minutes

Note: The alarm is crescendo sound. The alarm will sound for 2 minutes and then shut off completely if no buttons are pressed.

ACTIVATE/DEACTIVATE TIME ALARM

- Press and release the **ALARM** button to select Alarm 1 or Alarm 2.
- Press the **ALARM ON/OFF** button to activate the selected alarm. Once activated, the bell icon appears.
- Press the **ALARM ON/OFF** button again to deactivate the selected alarm. The bell icon will disappear.



Alarm Bell

SNOOZE (SILENCES ALARM TEMPORARILY)

- When alarm sounds, press the **SNOOZE** button to silence the alarm for 9 minutes.
- The alarm icon will flash.
- To stop alarm for one day, press any button, while in snooze mode.
- The alarm icon will show solid

LIGHT
HI - LOW - OFF

SNOOZE

TEMPERATURE TREND INDICATORS

The temperature (2°F / 1°C) trend indicators update every 30 minutes or less.

- Temperature has **risen** in the past 3 hours.



- Temperature has **not changed** in the past 3 hours.




- Temperature has **fallen** in the past 3 hours.



MOON PHASE

The moon phase is based on the Gregorian calendar and the year, month and date set. Most Internet moon phase calculations are based on the lunar calendar.



NEW

WAXING
CRESCENT

FIRST
QUARTER

WAXING
GIBBOUS

FULL

WANING
GIBBOUS

LAST
QUARTER

WANING
CRESCENT

LOW BATTERY ICON

View full warranty details online at: When the icon is displayed in the upper right hand corner, replace batteries in the alarm clock.



Low
Battery
Icon

ALARM CLOCK CARE AND MAINTENANCE

- **Do not mix old and new batteries**
- **Do not mix Alkaline, Standard, Lithium or Rechargeable Batteries**
- Always purchase the correct size and grade of battery most suitable for intended use.
- Replace all batteries of a set at the same time.
- Clean the battery contacts and also those of the device prior to battery installation.

- Ensure the batteries are installed with correct polarity (+and -).
- Remove batteries from equipment which is not to be used for an extended period of time.
- Remove expired batteries promptly.
- Improper use or unauthorized opening of housing voids warranty.
- If the alarm clock is not working properly, change the batteries and/or check the A/C cord connection.

SPECIFICATIONS

Indoor Temperature Range: +32°F to +122°F (0°C to 50°C)

Power:

Alarm Clock: 5V A/C power adapter (included)

AC Adapter No: HX06-0501200-AU

Battery backup: 2-AAA, IEC, LR3 batteries (not included)

Battery Life: Battery life is over 12 months when using the AC adapter for primary power

USB: Output 1 Amp maximum current (charging cable not included)

Dimensions: 5.9" L x 1.9" D x 3.5 " H (150 x 48 x 89 mm)

WARRANTY AND SUPPORT INFORMATION

La Crosse Technology, Ltd. provides a 1-year limited time warranty (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

Before returning a product, please contact our friendly customer support with questions or visit our online help (manuals and FAQs):

Phone: 1-608-782-1610

Online Product Support: www.lacrossetechnology.com/support

Product Registration:

www.lacrossetechnology.com/support/register

View full warranty details online at:

www.lacrossetechnology.com/warranty_info.pdf

Warranty Address:

La Crosse Technology, Ltd

2830 S. 26th St.

La Crosse, WI 54601



FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device must not be co-located or operating in conjunction with any other antenna or transmitter.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher.

This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences.

All trademarks and patents are recognized.

CANADA STATEMENT

This device complies with Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.