

SmartWorx™ Open Top File Cart Vertiflex

Products **

VF52000


Assembly Instructions


www.advantus.com


904.482.0091


Top Shelf






























4mm Hex Wrench













3 Attaching End Pieces

Insert each Side Piece into the upper pre-drilled holes on the frame piece as shown. Place 4mm hex screw through washer and tighten using 4mm hex wrench (included). Repeat on opposite side. Do not over tighten.





© Advantus Corp. VF52000 @ Advantus Corp. VF52000