

GRAVITY 10

USER MANUAL

www.sunslice-solar.com

I. INTRODUCTION

Thank you for your purchase. We hope you will have a great experience using the Sunslice Gravity.




The Gravity has been developed with the ultimate goal to give people access to energy everywhere.

Travellers, but also users in their daily life, will have a great use of this powerbank as it makes it possible for the user to carry a compact and light storage system to charge a large range of USB devices at any time and everywhere. With 3 USB outputs and a very compact size, the Gravity is a very handy powerbank for outdoor and daily life.

This manual contains important safety and product care information, as well as step-by-step instructions for using your Gravity powerbank. To get the greatest benefit from your purchase, we recommend you read the manual thoroughly, and keep it in a safe place in case you need to refer to it later.

Geoffroy & Henri

IN THE BOX



Gravity 10

COMPATIBLE WITH



II. PRODUCT OVERVIEW

LED INDICATORS
Shows charge status

15 mm

137 mm

6.8 mm

10'000 mAh * 3.7V
37 Wh

POWER
button


Weight : 204g

BATTERY INTERFACE

USB-C

Output : 5V/3A, 9V/2A

Input : 5V/3A, 9V/2A



USB QC3.0 (orange)
5V/3A, 9V/2A, 12V/1.5

Micro-USB Input
5V/2A

USB-A Output 2 (black)
5V/2.1A

III. KEY FEATURES

- 10'000 mAh (3.7V)/37 Wh POWERBANK
- CHARGES 3 DEVICES AT THE SAME TIME
- Micro-USB INPUT 10W
- USB-C INPUT 18W
- COMPACT SIZE
- 4 LED INDICATORS FOR CHARGE STATUS
- ROBUST DESIGN
- 204g

IV. SPECIFICATIONS

CAPACITY	10'000 mAh (3.7V) / 37Wh
BATTERY OUTPUT	5V/2.1A : <u>USB-A</u> 5V/3A, 9V/2A, 12V/1.5 : <u>USB QC3.0</u> 5V/3A, 9V/2A, 12V/1.5 : <u>USB-C</u>
BATTERY INPUT	5V/2A : <u>Micro-USB</u> 5V/3A, 9V/2A, 12V/1.5 : <u>USB-C</u>
WEIGHT	204g
DIMENSIONS	137 x 68 X15 mm
CHARGE STATUS	4 LED indicators

V.

AIRPORT PROOF

The Sunslice Gravity is airport proof as it has a 37 Wh capacity, which is under the maximum 100 Wh capacity allowed on a plane. Please note that the Gravity must be carried in the cabin only.


VI.

CHARGE THE GRAVITY


There are two ways to charge the Gravity. With a standard power adapter and with another power source such as a laptop.

Power Adapter

To charge the Gravity with a standard power adapter, use a micro-USB cable or a USB-C cable, connect it to the USB-A port of the power adapter and to the micro-USB or USB-C port of the Gravity (Cfr. Section II Product Overview).



Laptop




You can also charge the Gravity with your laptop by connecting the USB cable to the USB-A output of your laptop and the micro-USB or USB-C end of the cable to the micro-USB or USB-C port of the Gravity.

VII.

CHARGE YOUR DEVICE

To charge your device, use the adapted USB cable to your device, plug it into the Gravity USB ports at one end and into the USB port of your device at the other end. It will start charging automatically. If not, please push the POWER button of the Gravity.



VIII. OUR WARRANTIES

PREMIUM QUALITY

We select the finest materials to insure a high quality and durability for all of our products.

PROTECTION CIRCUIT

The Sunslice Gravity is equipped with a voltage stabilising circuit to avoid damaging your devices.

2 YEARS WARRANTY

The Gravity has a 2 year warranty. In case something goes wrong, please contact us directly by email at :

service@sunslice-solar.com

Before contacting us, please have a look at our FAQ at :

www.sunslice-solar.com/apps/help-center



IX. PRECAUTIONS

- If the Gravity does not charge your device, please read this user manual again. If the problem lasts, please contact us.
- Do not puncture, throw, drop, bend or modify your Sunslice Gravity.
- Do not leave the Sunslice Gravity out in the rain, keep away from water. Do not expose the Gravity to fire or excessive heat.
- Do not short-circuit the battery with lead or any metal objects.
- Keep the battery ports free from dust, lint, etc that may prevent proper connections.
- Please full charge the power bank after a long period of storage as it may discharge slowly with time.
- Do not use excessive force when connecting or disconnecting cables to/from the Gravity.
- Do not disassemble the charger or change its structure in any way.
- Stop using the Sunslice Gravity if it generates unusual smell, heating, distortion or any other abnormality.
- Keep away from children.

You are welcome on our website to learn more about our products.

www.sunslice-solar.com

Sunslice SRL
Chemin du Cyclotron 6,
1348 Louvain-la-Neuve, Belgium