

COCONU WAVE PERSONAL MASSAGER

User Manual


Specifications

- Size: 1.96L"x1.45W"x3.26H"
- 3.7V polymer lithium battery, battery capacity 300mAh, run time 55 min, charging time 120 min
- Platinum grade silicone
- Water resistant
- No BPA, BPS, PVC or Phthalates
- USB Rechargeable
- 10 Vibration Settings

Getting Started

Coconu Wave ships with a partial charge though it may have depleted over time. Before first use, charge your Wave for a full two hours.

Make sure the charging plug is fully inserted into the charging jack (the jack is the dot above the "DC" logo on the side of the Wave). The indicator light will flash when charging and the light will be constant when fully charged.



To Use

Turn on: Hold down the power button (located on the bottom of Coconu Wave) for 1.5 seconds to turn on. (The indicator light will illuminate while powered on.)

Turn off: Hold down the power button for 1.5 seconds to turn off.

Vibration Mode

Press the power button to cycle through the 10 vibration modes. The first mode is a consistent vibration, the second mode is a stronger consistent vibration, and the remaining 8 modes are different vibration patterns.

Care

Wash Coconu Wave (before initial use and) after every use, to prevent bacteria from building up. Wash with unscented soap and water and rinse thoroughly. (Or use a cleaner made for a personal massager.)

Safety

Do not charge near water.

Do not press power button while charging.

Do not use silicone-based lubricants with Coconu Wave.

Do not clean Coconu Wave with products containing alcohol, petrol, or acetone.

Do not bake, boil, microwave or wash Coconu Wave in a dishwasher.

Do not submerge Coconu Wave in water.

Lifespan

Coconu Wave is powered by a rechargeable lithium-ion battery. The expected lifespan of is dependent on frequency of use.

Tips for First Timers

First time using a toy? Check out these tips to help get you started.

Charge it

Make sure Coconu Wave is charged and ready to go.

Get in the mood

Before you get down to business, spend some time on foreplay and getting turned on.

Lube

Even if you are turned on and don't need extra lubrication, consider using it while using Coconu Wave.

Lube is an essential accessory that makes sex much better and that's no different when using a vibrator.

Take your time

Start slowly by trying Coconu Wave on your secondary erogenous zones first (neck, lower belly, inner thighs, behind knees, breasts, nipples) before you use it on your genitals. Take your time making your way to your vulva. Slow down and savor it, there's no rush!

Together or Solo first?

If you and your partner want to try out Coconu Wave for the first time together, it can be a great way to connect and deepen intimacy. However, it can also be a great option to try it on your own to become comfortable with it first.