


UNBOXING & SET-UP GUIDE

This guide assumes you have purchased a Revolution Rolling Pack or All-In-One Bundle. If you have purchased a different product, follow the steps that pertain to the product you have purchased.

1. Unzip the **Expandable Spinner**. Remove the **Messenger Tote Pack** and the **Expandable Daypack**.

If you purchased the All-in-One Bundle, also remove the **Packing Cubes** . . .



2. Zip the **Expandable Daypack** and the **Messenger Tote Pack** together, to form the **Double Backpack**, and to get a feel for how the attachment zippers work.




Position the **Messenger Tote Pack** in front of the **Expandable Daypack**. Note that the zipper must be fully seated into the zipper slider before starting to zip.

Pull the zipper all the way around to connect the two units.

Note the small elastic loop at the end of the zipper track. You can loop this around the zipper slider for added security.


3. Put the backpack on, and adjust the sternum strap so that it is even and comfortable.



Note that the sternum strap is fully removable, by sliding the buckles up and off the top of the tracks.

We recommend deciding if you are going to use the sternum strap regularly or not. If you decide not to use it regularly, we recommend removing it and storing it in a pocket.

4. Take a moment to locate the expansion zipper on the rear section of the backpack (the **Expandable Daypack**).




Pull the expansion zipper all the way around to expand the bag.

This gives you about 3.5" of extra space, enough to turn the **Double Backpack** into a weekender bag!

This also releases two pockets (one on each side) to carry water bottles or umbrellas.

Notice also how the **Double Backpack** opens flat like a suitcase, and there are sleeves for both a laptop and an iPad or tablet inside.


5. Next, unzip the **Messenger Tote Pack** from the **Expandable Daypack**.




Now you have two separate bags, allowing you and a companion to split up if you decide to go separate ways for a time on a trip you are taking together.



Note that the **Messenger Tote Pack** has space for a laptop . . .



And a tablet.




Turn the **Messenger Tote Pack** around; unzip the pocket on the left hand side to deploy a hidden water bottle holder.


6. The **Messenger Tote Pack** has an adjustable strap system. You can configure the straps in a number of different ways for different uses.




Pull the strap up and adjust the cam buckles to carry as a crossbody tote . . .



tighten the cam buckles to carry as a shoulder bag



or loosen the cam buckles again and pull the strap down to wear as a backpack.





The Messenger Tote Pack can also be strapped to an airplane seat - please see last page for instructions.

7. If you have purchased a **Hip Belt**, attach it to the back of the **Expandable Daypack**.




down
in

To open the clips on the **Hip Belt**, first press IN on the metal ring until it clears the plastic hook, then press DOWN on the plastic hook.




Hook clips through lower webbing loop and secure clips.




Adjust the **Hip Belt**. It should fit snug across your hips, so that some of the weight is transferred from your shoulders to your hips.

We recommend deciding if you are going to use the hip belt regularly or not. If you decide not to use it regularly, we recommend removing it and storing it in a pocket.


8. Stow the shoulder straps and deploy the rear cover on the **Expandable Daypack** to protect the padding & straps in storage or transit.



Unclip the shoulder straps from the base of the bag.




Tuck them into the pocket at the top of the bag and zip it closed.



Locate the Velcro-sealed pocket at the base of the bag.


Remove the rear cover.




Fully zip the rear cover around the bag.

UNBOXING & SET-UP GUIDE

9. You can reposition the rear cover to serve as a sling, if you wish to carry a sleeping, yoga mat, or similar items.



10. Unclip and repack the rear cover in its Velcro pocket at the base of the **Expandable Daypack**. Fold as pictured below.




11. Next, combine all three bags to form the complete **Revolution Rolling Pack**.



12. Try putting on the **Revolution Rolling Pack**, to see how all three units can be carried together as a travel pack. This is useful when you don't want to roll the spinner (think cobblestone streets!) or when you need both hands free for other things. You can also use the hip belt and sternum strap for added support.





13. Stow the backpack straps again, and deploy the telescopic handle.



If you plan to check the bag, we recommend deploying the rear cover to protect the padding and backpack straps while in transit.

Locate the zippered pocket on top of the **Expandable Spinner**. Unzip this zipper and pull out the handle inside to roll the backpack.

14. Lay the bag flat on its back and unzip the main compartment.




Note that the **Shirt & Pants Folder** is designed to fit in sideways for more efficient usage of the space.

Note that you should pack your heavier items at the bottom of the suitcase (closest to the wheels). This improves stability when rolling the bag.

If you have purchased packing cubes, they will all be stored inside of the **Shoe Cube**; unzip and remove.

To see our recommendations for how best to fit the packing cubes in the main compartment, watch the videos at the URL below:
<https://onlitravel.com/pages/instructional-videos>

15. Note the expansion zipper on the middle **Expandable Spinner** unit.



Find the expansion zipper on the middle **Expandable Spinner** unit.

Pull the expansion zipper all the way around to expand the bag.

When the middle **Expandable Spinner** unit is expanded, it may be a good idea to remove the front **Messenger Tote Pack** unit and the rear **Expandable Daypack** unit . . .

. . . and wear them together as the **Double Backpack**, if you wish to avoid checking a bag.

16. For an in-flight work station and added leg room, you may wish to fasten the **Messenger Tote Pack** to the back of the airplane seat in front of you.




1. Place the Messenger Tote Pack on your lap with the rear of the pack up and the top of the pack facing towards you.




2. Pull the strap towards you through the guides in the top. Adjust the buckles so they are a couple inches above the guides.




3. Unlatch the tray on the back of the airplane seat in front of you, and pull it down towards your lap, so it sits right on top of the Messenger Tote Pack.



4. Loop the strap over the airplane tray, and secure it to the hook at the bottom of the pack.



5. Tighten the buckles so that the pack is snugly secured to the tray.



6. Fold the airplane tray back up, and secure it to the seat in front of you.



7. Unzip the top front pocket, which will become a shelf for your tablet.



8. Place your tablet on the shelf. Enjoy your extra leg room, easy access to the items in your pack, and the convenience of having your tablet easily accessible!

That's it! We hope that your bag gives you years of enjoyment and use, and that it solves a lot of your travel and everyday carrying challenges. If you have questions, you can visit us at our website at OnliTravel.com, and contact us there if you wish.