







Tap the menu button in the upper left to bring out the menu.



Tap "Routines" on the menu that slides out from the left.




Tap the "+" in the upper right to create a new Routine.





Tap the “+” next to “When this happens.”




Here’s where you get to set what the “trigger” is. If you want to use one of our sensors as a trigger, select “Device”.




Select the sensor you want to use as a trigger.







You can select if you want the sensor OPENING to be a trigger, or CLOSING. If it's a motion sensor, you can use "MOTION" or "NO MOTION" as a trigger, then tap "SAVE".



If you want to have the routine active only during certain times, tap "change" next to "Anytime" to set specific days/times, otherwise tap the + next to "Add Action". This is where you add what's going to happen when the sensor is triggered




Scroll down to "Smart Home" if you want a device to have a particular action. In this case, I'm going to have my patio lights turn on when the back door opens. If you want Alexa to announce something, select "Alexa Says". There's a lot of different options.





Select the device you want to react to the sensor being triggered. I'm selecting my patio lights.



Select what you want the action to be when the sensor is triggered, then tap "Next". In this case, I'm just having my patio lights turn on.



Tap "Save". You can try out your new routine.



You can add a lot of different actions to a single routine. The way I've set this up is that when the door is opened, the patio light will turn on, Alexa will announce "Back Door is open," wait 10 minutes, then turn off the light.

