1080P HD TVI/AHD/CVI CAMERA

C-All8972G



- · Key Features:
- 1/2.7" 2.1 Megapixel CMOS Sensor
- Mode 1080P TVI/AHD/CVI (1920 X 1080)
- · With IR-CUT / DNR

SPECIFICATION

DESCRIPTION	PAL	
Imaging Device	1/2.7" 2.1 Megapixel CMOS Sensor	
Effective Pixels	1080P (1920 X 1080)	
Scanning System	Progressive Scan	
Synchronization	Internal, Negative Sync	
Horizontal Resolution	1080P (1920 X 1080)	
Video Output	TVI/AHD/CVI/960H	
S/N Ratio	More than 50dB (AGC Off)	
Min. Illumination	0.001Lux(Color)/F1.2	
IRIS Adjustment	Auto	
LENS	2.8~12 Manual Zoom Lens	
Electronic Shutter	Auto/FLK/1/25,30sec ~ 1/60000sec	
Electronic Shutter	MANUAL(X2~X512)	
IR LEDs	72Pcs LEDs	
Gama Characteristic	ristic 0.45	
IR Distance	60 Meters	
IR Status	Under 10 Lux by PD	
Auto Gain Control	ol Auto	
Day&Night	Auto	
Privacy Masking	On / Off (Programmable)	
3D-DNR	3D-DNR LEVEL(0~100)Adjustment	
Digital Zoom	1.0X-8.0X	
SENS-UP	JP OFF/ X2-X8	
MOTION	ON/OFF	
Digital Effect	OFF / V-FLIP / MIRROR / ROTATE	
Dimension (mm)		
Weight(g)	1700	
Input Voltage	DC 12V(±10%)	
Power Consumption	IR OFF: 210mA / IR ON: 550mA(±10%)	
Operating Temp/Hum.	-10°C~ +50°C / 30% ~ 80% RH	
Storage Temp. / Hum.	-20°C ~ +60°C / 20% ~ 90% RH	

WARRANTY

		Warra	nty Period: 2 years
Product	TV//ALID (C)// BUILLET CAMERA	Model C	-All8972G
	t TVI/AHD/CVI BULLET CAMERA	Serial No.	
Purchase		Customer	
Addres	S		
Deale	Representative		
' '			
Ple	ase contact purchasing office or serv	ice center when yo	u find any
	nage or problem with this product.	•	•
ua	mage of problem with this product.		
♠A/S w	ithout cost�		
	Within Warranty Period		y details
Within Warranty Ferrod		Within warranty	After Warran
When		Product	
damages occurred in		A/S without	
nomal	Repair or Replace	cost	
working environment		Product	
		exchange	
♠A/S w	ith cost◆		
Damage by customer's negligence			Warranty detai
	Damage by customer's careless handling		
chargeahl	 Damage by customer's careless handling Damage by natural disaster (Fire, Flood, etc 		
e case	3. Damage by not keeping the cautions and in		
even	4. Damage by not using appointed power(freq	A/S with cos	
within	adapter.	,	


chargeabl e case even within

adapter.

DIMENSION

5. Damage by disassemble or cleaning by customer 6. Damage by repairment by a person excepting the dealer

C-A118972G



CONNECTING OF CAMERA



- 1. No Picture after providing power. May be the power supply voltage abnormity, please check the power supply voltage and pole whether exactitude. Please check all the connecting cable and monitors whether be connected correctly or not.
- 2. The picture level direction have flowing interference ripples. May be caused by the power supply AC ripples, it need filter the wave of the power supply. Check the monitor and peripheral equipments used
- 3. The picture background color changes continuously. The fluorescent lamp's electromagnetic field cause color roll. This is proper phenomenon of the cameras. Reduce the fluore scent lamp numbers or increase the distance between the camera and the fluorescent lamps can improve it. Use power supply external sync. camera can solve it.
- 4. The picture smear too mass . The power supply's voltage unstable. Connecting cables not connect correctly or have high impedance.

Feature Summary

- * Sensor (CMOS)
- 1/2.7" 2.1 Megapixel CMOS
- * Auto Gain Control (AGC)

Built-in auto gain control (AGC) circuit. The color camera can get high definition picture in low Lux condition.

* Scanning Mode

NTSC or PAL mode.

* Auto Electronic Shutter (AES)

Built-in auto electronic shutter function. The color camera's AES speed can reach 1/100,000s.

* Gama Characteristic

Camera Gama characteristic is 0.45.

*Scanning Mode

NTSC or PAL mode.

*Switch the output signal by OSD button

Press "left" key after 5 seconds then release: CVBS

Press "right" key after 5 seconds then release: TVI

Press "up" key after 5 seconds then release: AHD

Press "down" key after 5 seconds then release: CVI

CAUTION IN INSTALLATION

- Do not install the camera opposite of the sun so that it be avoided direct light.
- Be careful not to drop this camera and not to impact on it. CCTV camera is a precision device.
- Do not pull the cable. If you pull the cable, it will make electrical problems such as disconnection.
- The camera should be worked within a range of the allowable temperature that refers to specification.
- A Do not try to fix even if the camera does not work.
- Installation this camera at safety place where is no water, If the camera has some problems with water accidently. You have to contact A/S centre that sold the camera to you.
- If you would like to relocate the already installed product, be sure to turn off the power and then move or reinstall it.
- Please contact the nearest A/S centre if you find out any Problems. Please do not ignore any small problems they can become a big problem.

CAUTION



To prevent fire or shock hazarded. Do not expose the unit rain to rain or moisture.



The symbol is intended to alert the user to the presence of important important operating and maintenance (servicing) Instructions in the literature accompanying the appliance.



The symbol is intended to alert the user to the presence of uninsulated 'dangerous voltage' within the product's enclosure that may be of sufficient Magnitude to constitute a risk of electric shock to persons.



CAUTION:
RISK OF ELECTRIC. DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER OR BACK NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO

CAUTION: To prevent electric shocks and risk of fire hazards, do NOT use other than specified power source.



Note:

- Please note the camera's operating temperature and its using environment requirement. Avoid using the camera at too high or too low temperatures. The operating temperature is -30°+60°C.

 (Recommendatory operating temperature is -10°+50°C.)
- Never make the camera face the sun or bright object. Otherwise, it will damage the CMOS.