Panasonic 1080P HD-SDI CAMERA

C-DG-IR9970HD




Key Features:

- 1/3" 2.1 Megapixel Panasonic CMOS
- · Mode 1080P(1920 X 1080)
- · ACCE(Adaptive Color & Contrast Enhancement)
- · WDR/BLC/HLC/D-ZOOM/DNR


SPECIFICATION

DESCRIPTION	PAL		
Imaging Device	1/3" 2.1 Megapixel Panasonic CMOS		
Effective Pixels	1080P(1920 X 1080)		
Scanning System	Progressive Scan		
Synchronization	Internal, Negative Sync		
Horizontal Resolution	1080P(1920 X 1080)		
Video Output	HD–SDI /1.0 Vp–p (75 Ω , Composite)		
S/N Ratio	More than 50dB (AGC Off)		
Min. Illumination	1.0Lux(Color),0.5Lux(BW)		
IRIS Adjustment Auto			
LENS	2.8~12 Manual Zoom Lens		
Electronic Shutter	Auto/FLK/1/25,30sec ~ 1/60000sec		
	MANUAL(X2~X512)		
IR LEDs	72Pcs LEDs		
Gama Characteristic	0.45		
IR Distance	60 Meters		
Auto Gain Control	Auto		
Day&Night	Auto		
Privacy Masking	acy Masking On / Off (Programmable)		
3D-DNR	LEVEL(0~100)Adjustment		
Digital Zoom	1.0X-8.0X		
SENS-UP	0FF/ X2-X8		
MOTION	TON ON/OFF		
Digital Effect	t OFF / V-FLIP / MIRROR / ROTATE		
Dimension (mm)	131x93(H)		
Weight(g)	800		
Input Voltage	DC 12V(±10%)		
Power Consumption	IR OFF: 210mA / IR ON: 550mA(±10%)		
Operating Temp/Hum.	−10°C~ +50°C / 30% ~ 80% RH		
Storage Temp. / Hum.	-20°C ~ +60°C / 20% ~ 90% RH		

WARRANTY Warranty Period: 2 years Model C-DG-IR9970HD Product GIMBAL DOME CAMERA Serial No. Purchase Customer Address Dealer Please contact purchasing office or service center when you find any damage or problem with this product. ► The warranty period is 2 years from Invoice date. ♠A/S without cost Warranty details Within warranty After Warranty Within Warranty Period Product A/S without Repair or Replace cost Product exchange ♠A/S with cost ◆ Damage by customer's negligence Warranty details Damage by customer's careless handling Damage by natural disaster (Fire, Flood, etc.) chargeabl e case even within Damage by not keeping the cautions and instructions on manual Damage by not using appointed power(frequency, voltage) or A/S with cost dapter. 5. Damage by disassemble or cleaning by customer 6. Damage by repairment by a person excepting the dealer warranty



CONNECTING OF CAMERA



- 1. No Picture after providing power. May be the power supply voltage abnormity, please check the power supply voltage and pole whether exactitude. Please check all the connecting cable and monitors whether be connected correctly or not.
- 2. The picture level direction have flowing interference ripples. May be caused by the power supply AC ripples, it need filter the wave of the power supply. Check the monitor and peripheral equipments used
- 3. The picture background color changes continuously. The fluorescent lamp's electromagnetic field cause color roll. This is proper phenomenon of the cameras. Reduce the fluore scent lamp numbers or increase the distance between the camera and the fluorescent lamps can improve it. Use power supply external sync. camera can solve it.
- 4. The picture smear too mass . The power supply's voltage unstable. Connecting cables not connect correctly or have high impedance.

Feature Summary & OSD Setting

* Sensor (CMOS)

1/3" 2.1 Megapixel Panasonic CMOS

* Auto Gain Control (AGC)

Built-in auto gain control (AGC) circuit. The color camera can get high definition picture in low Lux condition.

* Scanning Mode

NTSC or PAL mode.

* OSD SETTING:

OSD MENU					
LENS	■ELC	■ALC			
EXPOSURE	■BRIGHTNESS	■AGC	■SENS-UP	■AGC	
BACKLIGHT	■HLC	■BLC	■WDR		
WHITE BAL	■AUTO	■AUTOext	■PRESET	■MANUAL	
DNR	■LOW	■MIDDLE	■HIGH		
IMAGE	■SHARPNESS ■FLIP ■SHADING	■GAMMA ■D-ZOOM ■PRIVACY	■COLOR GAIN ■AEC	■MIRROR ■DEFOG	
MOTION	■SENSITIVITY ■DET H-SIZE	■WINDOW TONE ■DET V-SIZE	■DET H-POS ■MOTION OSD	■DET V-POS ■ALARM	
SYSTEM	■COM. ■FRAME RATE	■IMAGE RANGE ■CVBS	■OUTPUT MODE ■LANGUAGE	■COLOR SPACE ■COLORBAR	
EXIT					

CAUTION IN INSTALLATION

- Do not install the camera opposite of the sun so that it be avoided direct light.
- Be careful not to drop this camera and not to impact on it. CCTV camera is a precision device.
- Do not pull the cable. If you pull the cable, it will make electrical problems such as disconnection.
- The camera should be worked within a range of the allowable temperature that refers to specification.
- ♣ Do not try to fix even if the camera does not work.
- Installation this camera at safety place where is no water, If the camera has some problems with water accidently. You have to contact A/S centre that sold the camera to you.
- If you would like to relocate the already installed product, be sure to turn off the power and then move or reinstall it.
- Please contact the nearest A/S centre if you find out any Problems. Please do not ignore any small problems they can become a big problem.

CAUTION



To prevent fire or shock hazarded. Do not expose the unit rain to rain or moisture.



The symbol is intended to alert the user to the presence of important important operating and maintenance (servicing) Instructions in the literature accompanying the appliance.



The symbol is intended to alert the user to the presence of uninsulated 'dangerous voltage' within the product's enclosure that may be of sufficient Magnitude to constitute a risk of electric shock to persons.



RISK OF ELECTRIC. DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER OR BACK NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO OUALIFIED SERVICE PERSONNEL.

CAUTION: To prevent electric shocks and risk of fire hazards, do NOT use other than specified power source.



Note:

- Please note the camera's operating temperature and its using environment requirement. Avoid using the camera at too high or too low temperatures. The operating temperature is -30∼+60℃. (Recommendatory operating temperature is -10∼+50℃.)
- Never make the camera face the sun or bright object. Otherwise, it will