

Series Two assembly instructions

Tables and Benches:

1 – Place a blanket or another protective covering on the floor and place the table or bench top upside down on it.

2 – Line up holes in the tops of the leg frames with the underside of the bench or table top. Ensure that the legs point outward to the sides. Once aligned fix in place with four Allen key bolts for each leg (note that we have not included an Allen key in your hardware box due to its common use but we can supply one if need be). The bolts thread into a metal insert in the underside of the top.

3 – Next, first secure the metal bar into the bottom of the top with a brass screw and then fit the ends of the bar into the dowels of both leg frames. Secure the brass screws into the ends of the bar using an appropriate screwdriver or coin (be careful not to damage the screw slots by using too small a screwdriver). Do not over tighten.

4 – Once complete, turn the bench and table upright by lifting the top without using the legs as leverage.

Sideboard and Day Bed:

1 – As per tables and benches (alternatively carefully rest the sideboard on its back).

2 – Use a Phillips screwdriver to fix each leg to the base by fastening the (M5/5mm) screws provided.

3 – Ensure the sideboard is placed on a level floor to avoid the movement of the doors. Adjust the hinges if necessary or place a coin or similar item under a leg to level the unit.

Coffee and Side Table:

1 – As per tables and benches.

2 – Manually screw legs into the underside of the tops.

3 – Align the screw holes toward the middle of the top and do not overtighten.

4 – Using the screws provided and a flat head screwdriver fix the brass bar to the legs.

