

SLA.878 - 6 pk. Ninja Grip Clips



BE SAFE! - ALWAYS FOLLOW THESE RULES

- Adult supervision is required at all times.
- Maximum user weight is 250 LBS (113 Kg).
- Maximum height(clearance) from NINJALINE™ user's feet to the ground when they are hanging from the lowest NINJA LINE™ obstacle is 18 inches (45 cm). Be safe, stay low.
- Every time you use the NINJALINE™, make sure everything is installed correctly and check for wear before using.
- If worn or damaged parts are found, contact b4Adventure for replacement parts Do not substitute with other, non-b4Adventure parts or failure resulting in injury could result.
- One person only at a time. Wear close fitting, athletic style clothing, NO scarves or other loose clothing that could become entangled.
- Never use the line when it is wet or if there is rain or lightning in the area

FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN SERIOUS INJURY!





This product should be unpacked and assembled by an adult, including site and tree selection, as well as the secure and proper installation

WARNING! ADULT SUPERVISION REQUIRED! SERIOUS INJURY OR DEATH MAY RESULT -

Always exercise extreme caution when using the slackline. Keep bystanders at least 10 ft. (3 m) away from the course to avoid collisions






Ninja Grip Clip Instructions




STEP 1 Start by feeding the line through the top opening of the clip



STEP 2
Make sure the line is flat inside the clip, with the opening facing upward



STEP 3
Pull the line through the bottom of the clip to create a U shape



STEP 4
Insert the Delta
carabiner into the U
shape and pull the line
outside the clip taut.

*Note: The Delta carabiner should be centered between the 2 divits on the inside of the clip

*Tip: Placement of the clips (and carabiners) should be done BEFORE ratcheting the line.

The clips will be difficult to move after your line is ratcheted.

