







www.steelcut.design

INSTALLING THE 7-INCH (5/8" X 7") STAINLESS STEEL WEDGE ANCHOR

WEDGE ANCHOR



PRODUCT SPECIFICATIONS

Bit size	5/8"
Minimum embedment	2 3/4"
Thread length	4"
Type	Male
Primary	Concrete only
Diameter	5/8"
Length	7"
Material	304 stainless steel
Environment	Wet
Minimum edge distance	3 1/8"
Maximum fixture thickness	3 5/8"
Maximum torque	75-90 ft./lbs.
Wrench size for nut	15/16"
Length measurement	End to end

INSTRUCTIONS

1. Drill a 5/8" hole into the concrete using a carbide-tipped bit.
2. Drill the hole a 1/2" deeper than the anchor will penetrate the concrete, making sure the minimum embedment requirement of 2 3/4" is met.
3. The hole can be drilled while the fixture is in place.
4. Clean the hole with a wire brush, vacuum, compressed air, or a blow-out bulb.
5. Put the nut and washer on the Anchor, making sure the nut is on the last threads; this will protect the threads from damage when the wedge anchor is hammered into the hole.
6. Insert the Anchor through the hole in the Gooseneck Base and into the hole in the concrete. This should be a tight fit.
7. Use a hammer to complete the installation until the nut and washer are tight against the Gooseneck Base. It is important that the threads go below the surface of either the concrete or the Gooseneck Base.
8. Turn the nut clockwise on the Anchor until finger tight.
9. Using a 15/16" wrench, turn the nut 3 to 4 times until snug or until the proper torque value of 75-90 ft./lbs. is reached.
10. Always use proper personal protective equipment per manufacturer and OSHA instructions.