

UNIVERSAL BIKE MOUNT CLAMP HOLDER FOR PHONE AND TABLET

No. 082




USER MANUAL

Package Contents:

- Universal Phone & Tablet Holder
- Quick Release Strap Mount




Please read instructions completely before using the device.

For Customer Service, please contact support@sunnyhealthfitness.com



1. Attach the Strap Mount's t-notch adapter into the holder's 4 slots and push up firmly to lock in position until secure. You should hear a click.
 2. Wrap the strap around the handlebar and insert through slot on the mount. Pull strap tightly to secure. Press and hold the two release buttons to release the strap.
- ⚠️ **CAUTION:** It is important to make sure that the holder is secure with the strap mount. The whole unit is in danger of falling if it is not.

3. Press and hold the two buttons and pull the extendable arm up to create room for the device to fit (make sure the height of the open clamps is shorter than the device).



The Strap Mount comes with 2 strap spacers that can be removed when mounting on a smaller handlebar for better grip and stability.

4. For a secure and snug fit, pull the retractable top clamp upward while placing your device in the open clamps. Release the retractable top clamp with device inside. Make sure device is secure.
5. Pull the holder's 2 lower legs outward for stable holding of the larger device.
6. Loosen by turning the swivel ball head counter-clockwise. Adjust the holder for vertical or horizontal viewing, then turn swivel ball head clockwise to tighten and secure position.

IMPORTANT: The Sunny Health & Fitness Universal Bike Mount Clamp for Phone & Tablet is not designed for outdoor use on intensively moving bikes such as, mountain bikes.

Sunny Health & Fitness is not responsible for any damages caused to your exercise equipment, to your device, or to yourself due to the installation or use of this mount.