


MULTIFUNCTIONAL & ADJUSTABLE HEIGHT POWER TOWER

SF-XF922081

USER MANUAL



IMPORTANT! Please retain owner's manual for maintenance and adjustment instructions. Your satisfaction is very important to us, **PLEASE DO NOT RETURN UNTIL YOU HAVE CONTACTED US:** <u>support@sunnyhealthfitness.com</u> or 1-877-90SUNNY (877-907-8669).



 \mathbf{O}

WWW.SUNNYHEALTHFITNESS.COM


IMPORTANT SAFETY INFORMATION

We thank you for choosing our product. To ensure your safety and health, please use this equipment correctly. It is important to read this entire manual before assembling and using the equipment. Safe and effective use can only be achieved if the equipment is assembled, maintained, and used properly. It is your responsibility to ensure that all users of the equipment are informed of all warnings and precautions.

- 1. Before starting any exercise program, you should consult your physician to determine if you have any medical or physical conditions that could put your health and safety at risk or prevent you from using the equipment properly. Your physician's advice is essential if you are taking medication that affects your heart rate, blood pressure, or cholesterol level.
- 2. Be aware of your body's signals. Incorrect or excessive exercise can damage your health. Stop exercising if you experience any of the following symptoms: pain, tightness in your chest, irregular heartbeat, shortness of breath, lightheadedness, dizziness, or feelings of nausea. If you do experience any of these conditions, you should consult your physician before continuing with your exercise program.
- 3. Keep children and pets away from the equipment. The equipment is designed for adult use only.
- 4. Use the equipment on a solid, flat level surface with a protective cover for your floor or carpet. To ensure safety, the equipment should have at least 2 ft (60 cm) of free space all around it.
- 5. Ensure that all nuts and bolts are securely tightened before using the equipment. The safety of the equipment can only be maintained if it is regularly examined for damage and/or wear and tear.
- 6. Always use the equipment as indicated. If you find any defective components while assembling or checking the equipment, or if you hear any unusual noises coming from the equipment during exercise, discontinue use of the equipment immediately and do not use until the problem has been rectified.
- 7. Wear suitable clothing while using the equipment. Avoid wearing loose clothing that may become entangled in the equipment.
- 8. Do not place fingers or objects into the moving parts of the equipment.
- 9. The maximum weight capacity of this unit is 330 pounds (150KG).
- 10. The equipment is not suitable for therapeutic use.
- 11. To avoid bodily injury and/or damage to the product or property, proper lifting and moving are required.
- 12. Your product is intended for use in cool and dry conditions. You should avoid storage in extreme cold, hot or damp areas as this may lead to corrosion and other related problems.
- 13. This equipment is designed for indoor and home use only; it is not intended for commercial use.

PRE-ASSEMBLY CHECK LIST


Before you start to assemble, please make sure all parts are included.



No.	Description	Spec.	Qty.
1	Base Frame		2
2	Connection Tube		1
3	Left Front Support Tube		1
4	Left Rear Support Tube		1
5	Right Front Support Tube		1
6	Right Rear Support Tube		1
7	Arm Tube		2
8	Backrest Support Tube		1

No.	Description	Spec.	Qty.
9	Upright Post		1
10	Horizontal Tube		1
14	Spring Knob		1
20	Arm Cushion		2
21	Back Cushion		1
А	Manual		1
В	Thank You Card		1
С	Hardware Package		1

HARDWARE PACKAGE



Ordering Replacement Parts (U.S. and Canadian Customers only)


Please provide the following information in order for us to accurately identify the part(s) needed:

- ✓ The model number (found on cover of manual)
- ✓ The product name (found on cover of manual)
- ✓ The part number found on the "EXPLODED DIAGRAM" and "PARTS LIST" (found near the end of the manual)

Please contact us at <u>support@sunnyhealthfitness.com</u> or 1-877-90SUNNY (877-907-8669).

ASSEMBLY INSTRUCTIONS


We value your experience using Sunny Health and Fitness products. For assistance with parts or troubleshooting, please contact us at support@sunnyhealthfitness.com or 1-877-90SUNNY (877-907-8669).



STEP 1:

Attach Connection Tube (No. 2) to 2 Base Frames (No. 1) using 4 Hex Socket Head Bolts (No. 22), 4 Flat Washers (No. 23) and 4 Lock Nuts (No. 24). Tighten and secure with Wrench (No. 32) and Allen Wrench (No. 33).


NOTE: The side with metal plate of the **Connection Tube (No. 2)** should be facing up.



STEP 2:

Attach Left Front Support Tube (No. 3), Left Rear Support Tube (No. 4), Right Front Support Tube (No. 5) and Right Rear Support Tube (No. 6) to 2 Base Frames (No. 1) respectively using 4 Hex Socket Head Bolts (No. 22), 4 Flat Washers (No. 23), and 4 Lock Nuts (No. 24). Then secure 4 Support Tubes with 2 Hex Socket Head Bolts (No. 22), 4 Flat Washers (No. 23), and 2 Lock Nuts (No. 24), with Wrench (No. 32) and Allen Wrench (No. 33).


NOTE: Do not tighten the 6 **Hex Socket Head Bolts (No. 22)** during this step. We value your experience using Sunny Health and Fitness products. For assistance with parts or troubleshooting, please contact us at support@sunnyhealthfitness.com or 1-877-90SUNNY (877-907-8669).



STEP 3:

Attach 2 Arm Tubes (No. 7) to the assembled 4 Support Tubes using 4 Hex Socket Head Bolts (No. 22), 4 Flat Washers (No. 23), and 4 Lock Nuts (No. 24). Secure with Wrench (No. 32) and Allen Wrench (No. 33).


NOTE: Do not tighten the 4 **Hex Socket Head Bolts (No. 22)** during this step.



STEP 4:

Attach the Backrest Support Tube (No. 8) to 2 assembled Arm Tubes (No. 7) using 4 Hex Socket Head Bolts (No. 22), 4 Hex Socket Head Bolts (No. 26), 8 Flat Washers (No. 23), and 8 Lock Nuts (No. 24). Tighten and secure with Wrench (No. 32) and Allen Wrench (No. 33).

NOTE: Now you can tighten all the **Hex Socket Head Bolts (No. 22)** from STEP 2 & STEP 3. We value your experience using Sunny Health and Fitness products. For assistance with parts or troubleshooting, please contact us at support@sunnyhealthfitness.com or 1-877-90SUNNY (877-907-8669).



STEP 5:

Insert Upright Post (No. 9) into the assembled Backrest Support Tube (No. 8), insert and tighten the Spring Knob (No. 14) to secure.


There are 10 height options for the **Upright Post (No. 9)**, loosen and pull out the **Spring Knob (No. 14)** to adjust the height, then re-insert and tighten the **Spring Knob (No. 14)** to secure.

CAUTION!

To avoid any injury, please make sure that the **Spring Knob (No. 14)** is properly engaged. Once the **Spring Knob (No. 14)** is tightened, the height can't be adjusted.

STEP 6:

Attach the Horizontal Tube (No. 10) to the Upright Post (No. 9) using 2 Hex Socket Head Bolts (No. 25), 2 Flat Washers (No. 23), and 2 Lock Nuts (No. 24). Tighten and secure with Wrench (No. 32) and Allen Wrench (No. 33). We value your experience using Sunny Health and Fitness products. For assistance with parts or troubleshooting, please contact us at support@sunnyhealthfitness.com or 1-877-90SUNNY (877-907-8669).



STEP 7:

Attach 2 Arm Cushions (No. 20) to the 2 Arm Tubes (No. 7) with 4 Hex Socket Head Bolts (No. 22), 4 Spring Washers (No. 28), and 4 Flat Washers (No. 23). Tighten and secure with Allen Wrench (No. 33).

Then attach Back Cushion (No. 21) to the Backrest Support Tube (No. 8) using 4 Hex Socket Head Bolts (No. 27), 4 Spring Washers (No. 28), and 4 Flat Washers (No. 23). Tighten and secure with Allen Wrench (No. 33).

The assembly is complete!

MAINTENANCE INSTRUCTIONS

DAILY MAINTENANCE

Inspect and tighten all parts regularly. (Nuts, Bolts, Rubber Pads, Steel Brackets, etc.) Replace any worn or torn parts immediately. Check and ensure the equipment is levelled at all time. Check and tighten all adjustment pins/knobs regularly.

WEEKLY MAINTENANCE


Use damp cloth on plastic parts only, use dry cloth on metal frames. Inspect the metal frame structure of the equipment.

DOWNLOAD SUNNYFIT - FOR HOME FITNESS



SunnyFit is an all-in-one home fitness app designed to empower users of all levels to achieve their fitness goals. Discover over 1,000 free on-demand workout video courses crafted by certified trainers, tailored for various exercise equipment such as indoor bikes, treadmills, rowers, ellipticals, dumbbells, bodyweight, and even resistance band exercises. Whether you have equipment or not, SunnyFit offers the perfect workout for every fitness level and preference. You can enjoy a collection of over 300 free workout courses that require nothing more than your body and the SunnyFit app.

EXPLODED DIAGRAM



PARTS LIST

No.	Description	Spec.	Qty.
1	Base Frame		2
2	Connection Tube		1
3	Left Front Support Tube		1
4	Left Rear Support Tube		1
5	Right Front Support Tube		1
6	Right Rear Support Tube		1
7	Arm Tube		2
8	Backrest Support Tube		1
9	Upright Post		1
10	Horizontal Tube		1
11	Foot End Cap	50*50*1.5mm	4
12	Round End Cap	∮ 25mm	4
13	Square End Cap	50*50*1.2mm	3
14	Spring Knob		1
15	Plastic Bushing		2
16	Round End Cap	∮ 25*3.0mm	2
17	Rock Climbing Block		2

No.	Description	Spec.	Qty.
18	Foam Grip	∮ 22*∮ 32*150mm	4
19	Foam Grip	∮ 22* ∮ 32*265mm	2
20	Arm Cushion		2
21	Back Cushion		1
22	Hex Socket Head Bolt	M8*65mm	22
23	Flat Washer	∮ 25*∮ 8.5*2.0mm	32
24	Lock Nuts	M8	24
25	Hex Socket Head Bolt	M8*70mm	2
26	Hex Socket Head Bolt	M8*40mm	4
27	Hex Socket Head Bolt	M8*20mm	4
28	Spring Washer	M8	8
29	Round Hex Socket Head Bolt	M10*30mm	4
30	Flat Washer	∮ 20* ∮ 10.5*2.0m m	4
31	Nylon Nut	M10	4
32	Wrench	#13-17	1
33	Allen Wrench	#6	1

CONN with us



Track your fitness progress & join FREE workout courses!

Download **SUNNYFIT** today!



Find us on social media @sunnyhealthfitness



O @sunnyhealthfitness





@sunnyhealthfit

/sunnyhealthfitness





/sunnyhealthandfitness

www.sunnyhealthfitness.com