Lunar Oasis

boAt

LUNAR OASIS

Thank you for choosing the boAt Lunar Oasis as your fitness transformation companion.

Allow this manual to guide you through the functioning of your smartwatch. Please read it thoroughly before using it for a smooth sail. You may refer to these instructions for later use as well.

USER MANUAL

CHARGING THE WATCH

The smartwatch must be charged before initial use. It takes up to 2 hours to be fully charged. Connect and charge the watch with the image below as a reference, using a 5V/2A adapter.

TURNING THE WATCH ON/OFF

To restart or turn the watch on/off, long-press the side button for 3-5 seconds.
You can wake up the Screen by lifting your wrist.

CONNECTING TO THE APP

1. Download the boAt Crest app on your phone.
Available on both App Store (iOS 4.4 and above) & Google Play Store (Android 8.0 and above)

OR

Scan [QR CODE] (Also available on the watch)

2. Connect the device with the boAt Crest app, ensure that the phone's Bluetooth as well as the GPS functionalities are turned on
3. Select Lunar Oasis on the home screen of the app and click pair to connect.
4. Once connected, you will get an alert to connect with LUNAROASIS_XXXX, click pair if need to receive or make calls from the watch
4. To use all features of your Lunar Oasis seamlessly, tap on 'yes' to the 'connection' and 'grant access' system prompt.
5. Disable battery optimization

SYNCING YOUR SMARTWATCH TO THE APP

Data Synchronization
- Open the app on your phone.
- Make sure your Lunar Oasis is connected to the app
- Synchronization will start automatically once you enter the app interface.

Note:
Synchronize data at least once a day to avoid data loss in the watch.

NAVIGATING THROUGH THE FUNCTIONS

SHORT PRESS THE SIDE BUTTON FOR THE MAIN MENU

Apps
Tap on this to start navigating your route. Follow the steps to use this feature
- Search your desired destination on the boAt Crest app.
- Then send navigation instructions to your build smartwatch by clicking on get directions.
- After clicking on it choose the navigate on watch option.
- Then follow step-by-step instructions on your smartwatch to reach your destination
- Click on the three dots on the right side of navigation feature in your smartwatch to enable the Audio, Haptic or Always on Display mode while navigating.
Note: The navigation is not shown in maps instead it is shown by direction arrows. You can access the last alert from the watch navigation menu or by swiping left from the home screen.
- To avoid receiving notifications on your smartwatch during navigation enable DND mode

Alarm
Tap on this to set an alarm on your watch.

Activities
Choose from multiple sports modes like Walking, treadmill, Running, Badminton, Football, Basketball, Tennis, Yoga, Dancing, Cycling, Indoor Cycling, etc. The watch has 700+ activity modes. You can also add or replace the activities according to your preference.
Tap on any sport mode to start the activity, click the go button, and the watch will start recording the duration of the activity. Swipe right to pause or stop the activity. The activity will not be recorded if it is less than 1 mins.
Note: By selecting the settings option, you can enable the activity guide

Activity Records
Sync your smartwatch to the app to get a detailed record of your activities.

Breathing
Preset the time of exercise and click on the start icon to regulate your breathing by doing breathing exercises.

Camera
Tap on the remote camera icon on your smartwatch to click a photo from your phone.
*Note: Turn the camera on from your phone to use this feature

CALL

Dialer
You can use the dialer to dial any number.

Phone Book
Add up to 20 contacts from boAt Crest app. You can select any contact to directly dial from the watch.

Call History
You can find recently received, missed, and outgoing call logs in the Call History of the watch.

Flashlight
Tap on this to turn your dial into a flashlight.

Find Phone
Tap on this icon to find your phone. Once enabled, your phone will start ringing and vibrating. Tap again to stop it.
Note: Your smartwatch should be connected to your phone via Bluetooth and within its range for this feature to work.

Heart Rate Monitoring
Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app.
Note: Measurements are for reference only and not for medical purposes

Music Control
Tap on the remote music control icon on your watch to play music from your phone.
*Note: Some apps with different protocols might not work.

Notifications
You can check all the notifications from here

Reminders
You can set any upcoming reminders from here.

Sports Score
You can check the cricket and football live scores from here.

Stress
Click this option to start the stress monitoring. Make sure you wear your watch on your wrist properly to get the accurate results.
Analysis of the measurement is
Relax: 1-29
Normal: 30-59
Medium: 60-79
High: 80-100
Note: Measurements are for reference only and not for medical purposes.

SETTINGS

Watch Faces
Tap on this icon to change your watch face. You can choose from 5 default watch faces. Alternatively, you can long press the home screen to switch between the watch faces.

Always on Display
Click on this to enable always on display.
Note: The battery will drain quickly once this mode is enabled.

Screen Sleep
Tap on this and adjust the screen sleep time.

Sounds
Tap on this to choose ringtone, adjust the volume and put the watch on silent mode.

QR Tray
Tap on this to access the QR of different applications. You can transfer the QR code of metro ticket/pass, bus pass, UPI, social apps, and more to the smartwatch by adding the QR code in the boAt crest app. To add the QR code follow these steps:
- Click on "QR Tray" option in the boAt Crest app.
- To add a QR code, capture a screenshot of the QR code of the app you want to include.
- After this, you'll be able to find a collection of QR codes in the smartwatch under the QR Tray feature. Select the QR code you want to be scanned.

Vibration
Tap on this to adjust vibration levels from strong, soft, and none.

Wake Gesture
Tap on this to enable wake gesture.

Layout
You can change the main menu view to the grid, circular, ring or list view from here.

Brightness
Tap on this to adjust the brightness.

Do not Disturb
Tap on this to turn on the Do Not Disturb mode.

Bedtime Mode
Click on this to schedule your bedtime.

About
Shows the device details.

Regulatory
Shows the device's regulatory details.

SpO2 monitoring
Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app.
Note: Measurements are for reference only and not for medical purposes.

System
Tap on this to restart, factory reset or to power off the smartwatch.

App QR Code
Tap on this and scan the bar code 'Aim t=mobile to =connect the smartwatch.

Battery Saver Mode
Tap on this icon to enable power-saving mode.

Steps
Tap on this to check your daily step count, distance traveled and calories.

Stopwatch
Click on this to start the stopwatch on your watch.

Timer
Tap on this to turn on the timer.

Sleep Monitor
Tap on the icon to review the sleep data of the previous night.
Once the asleep criteria are met, your smartwatch will start recording from 8 pm at night to 10 am in the morning the next day.
Once you lie down and watch detects no movement for 30 minutes, it will start recording, and will stop recording if it detects excessive movement. You can check the data on the app only after the awake criteria is met.
You can also track sleep scores on the boAt Crest app.
Note:
*For accurate sleep data recording, the asleep criteria have to be met which includes limited movement, wrist positions and angles, and more.
*The awake criteria will be met only after it records some noticeable movement

Voice Assistant
Tap on this to enable the voice assistant feature and give the command from the watch.
Note: Make sure the watch is connected with the app

Weather
Connect with the boAt crest app to get daily weather updates on the watch.

SWIPE UP TO ACCESS RECENT NOTIFICATIONS
You can check all the recent notifications over here

SIDE BUTTON FUNCTIONALITY
Rotate the side button to navigate through the main menu.

SWIPE DOWN FOR THE SHORTCUT MENU
You can access settings, battery saver, phone book, DND, Layout, Wake Gesture, Brightness, Silent Mode, Flashlight, Bed time, Always on Display, Find my Phone, Navigation, and Off/Restart

SWIPE LEFT OR RIGHT TO ACCESS ALL DATA
You can access call, navigation, QR Tray, Sports score, Camera control, Music control, weather, activities, breath exercise, sleep, stress, SpO2, steps, and Heart Rate. Alternatively, you can swipe right to go back to previous tab.

MAINTENANCE
Regularly clean your wrist and the strap of the smartwatch, especially after sweating during exercise or being exposed to substances such as soap or detergent, which may get stuck on the other end of the product. Do not wash the strap with a household cleaner. Please use soap less detergent, rinse thoroughly and wipe with a piece of soft towel or napkin. For spots or stains that are not easy to remove, scrub the area with rubbing alcohol and then follow the above procedure.

FAQ

Search for the app to connect keeps failing
1. Keep the boAt Crest app updated to the latest version
2. Close all the programs on the watch -> Stop and restart Bluetooth and GPS -> Connect again
3. Check and enable notification functions of your phone and keep the phone and watch in close contact.
Note: Make sure your phone system meets Android 8.0 above and iOS 4.4 and above.

My Watch Lunar Oasis is receiving no alerts, texts, or phone calls.
Make sure smart reminders on the app are on and synced to Lunar Oasis Also, make sure the notification centre of the phone is displaying messages. Only then will your smartwatch also display those notifications. Make sure app is running in the background and the battery optimization feature on the phone is disabled

My Bluetooth keeps getting disconnected.
1. Make sure there is not more than 7m distance between Bluetooth on the phone and the watch.
2. There is no obstacle between the watch and the phone.
3. Make sure the app is running in the background.

PRODUCT PARAMETERS

Model	boAt Lunar Oasis
Screen type	1.43" AMOLED Display
Battery capacity	300 mAh
Net weight	106.8g
Bluetooth version	Bluetooth 5.3
Working temperature	-20℃-60℃
Charging time	2 hours
Working time	5-7 days
Water Resistance	IP68
Frequency band	2400-2480 Mhz

Which functions of Lunar Oasis need Bluetooth to work?
Call & Text Notifications, Find My Phone, music control, camera control, weather forecast, cloud and custom watch faces and Bluetooth calling need Bluetooth connectivity to work.

Will it be okay to take a bath wearing Lunar Oasis?
The IP68 water resistance will only work, when under the following conditions:
(1) Maximum depth of water: 1.5m (2) Maximum time for exposure to water: 10 minutes
The watch isn't suitable for hot baths, hot springs, saunas, snorkelling, diving, water skiing and other wading or deep-water activities with high-speed water flow.

SAFETY & PRODUCT INFORMATION

Battery
- Do not disassemble, bore or damage the battery.
- Do not disassemble the built-in batteries of non-replaceable battery devices.
- Do not use sharp objects to remove the battery.

HEALTH WARNING
If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitor of the watch.
The optical heart rate sensor will glow green. If you suffer from epilepsy or are sensitive to blinking light sources, please consult your physician before wearing this device.
The device tracks your daily activities such as steps, sleep, distance, heart rate and calories, but may not be completely accurate.

- The device accessories, heart rate sensor, oxygen level monitor, and other relevant data is designed for fitness and not for medical purposes. They do not apply to the diagnosis, monitoring, treatment or prevention of any diseases or symptoms. They are for reference only. We're not responsible for any deviation in data.
- Avoid wearing the watch too tightly. Make sure you keep your skin dry - the area that comes in contact with the watch. If symptoms such as redness or swelling appear on your skin, immediately stop using the watch and consult the doctor.

THINGS TO KEEP IN MIND
- Sync data everyday days to avoid data loss.
- Water Resistance will not work for seawater, acidic and alkaline solutions, chemical reagents and other corrosive liquid. The damage or defects caused by misuse or improper use are not covered by the warranty.
- Sports modes support up to 6 hours of exercise at a time.
- Avoid wearing the watch too tight in daily use. Keep the parts of skin touching the watch dry.
- Keep your arm still while measuring data for accurate measurement.

Disclaimer: This product is an electronic monitoring product and is not intended as a medical reference. We reserve the right to modify or improve any of the functions described in this manual without any prior notice. At the same time, we hold the right to continuously update the product content.

CAUTION
RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT SUBSTITUTE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Old electrical appliances must not be disposed of together with the residual waste but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycling valuable raw materials and treatment of toxic substances.