

WAVE ARMOUR 2

Thank you for choosing the boAt Wave Armour 2 as your fitness transformation companion.

Allow this manual to guide you through the functioning of your smartwatch. Please read it thoroughly before using it for a smooth sail. You may refer to these instructions for later use as well.










PACKAGE CONTAINS:

· Warranty Card x1

CHARGING THE WATCH

The smartwatch must be charged before initial use. It takes up to 2 hours to be fully charged Connect and charge the watch with the image below as a reference, using a 5V/2A adapter.



o restart or turn the watch on/off, long-press the upper

side button for 3-5 seconds. You can wake up the screen by lifting your wrist.



CONNECTING TO THE APP

1. Download the boAt Crest app on your phone. Available on both App Store (IOS 10.0 and above) and Google Play Store (Android 7.0 and above)

Scan [QR CODE] (Also available on the watch)

2. Connect the device with the boAt Crest app; ensure that the phone's Bluetooth as well as the GPS functionalities are turned on 3. Select Wave Armour 2 on the home screen of the app and click pair to connect.

4. Once connected, you will get an alert to connect with ARMOUR2BT, click pair if need to receive or make calls from the watch

5. To use all features of your Wave Armour 2 seamlessly, tap on 'yes' to the 'connection' and 'grant access' system prompt. 6. Disable battery optimization





Note: To ensure connectivity throughout your journey, make sure the app is allowed to run in the background of your phone at all times.

SYNCING YOUR SMARTWATCH TO THE APP

Data Synchronization Open the app on your phone.

- Make sure your Wave Armour 2 is connected to the app
- Synchronization will start automatically once you enter the app interface.

Synchronize data at least once a day to avoid data loss in the watch.

Tap on this to enable the voice assistant feature and give the Note: Make sure the watch is connected with the app

Choose from multiple sports mode like walking, running, climbing,

Click on this to check your daily activity data like step count, calorie,

cycling, basketball, badminton, football, Elliptical, Yoga, table tennis, skipping, tennis, baseball, rugby, hula hoop, golf, long jump, sit ups,

Tap on any sport mode to start the activity, you can pre-set your goal as well for each activity. Press the side button to pause or stop the activity. If the activity is less than 3 mins, it will not be recorded.

Sync your smartwatch to the app to get the detailed analysis. Workout records

You can view the records of your workouts here.

Wear the watch on your wrist, then click on the icon to start

active minutes, no. of times you were standing.

measurements. You can also view the data on the app.

Note: Measurements are for reference only and not for medical purposes.

Tap on the icon to review the sleep data of the previous night. Once the asleep criteria are met, your smartwatch will start recording from 8 pm at night to 10 am in the morning the next day. Once you lie down and watch detects no movement for 30 minutes, it will start recording, and will stop recording if it detects excessive movement. You can check the data on the app only after the awake criteria is met. You can also track sleep scores on the boAt Crest app.

*For accurate sleep data recording, the asleep criteria have to be met which includes limited

movement, wrist positions and angles, and more. *The awake criteria will be met only after it records some noticeable

Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app. Note: : Measurements are for reference only and not for medical purposes.

Check your notification from this menu option



Connect with the boAt crest app to get daily weather updates on the watch



Enable and set the details on the boAt Crest app and get the alerts of your period and ovulation dates on the watch.



Music Control

Tap on the remote music control icon on your watch to play *Note: Some apps with different protocols might not work.



Click on this to start the stopwatch on your watch.







Tap on the remote camera icon on your smartwatch to click a photo from your phone.

*Note: Turn the camera on from your phone to use this

Click on the breath training icon to regulate your breathing with the instructions given to relax.

Tap on this icon to do all the calculations in your smartwatch.

Camera Control Mode



Tap on this icon to check the date on your smartwatch.

Tap on this icon to get the right directions according to the poles of earth

Tap on this icon to find your phone. Once enabled, your

phone will start ringing and vibrating. Tap again to stop it. Note: Your smartwatch should be connected to your phone via Bluetooth and within its range for this feature to work.

Menu Style

SCREEN DISPLAY

Tap on this to adjust the brightness:





Adjust the screen time out from here.

Enable this feature, to adjust the wake time.

Tap on this icon to adjust the vibration intensity to soft,

strong or turn off the vibration.

Scan and download the boat Crest app from here.

Tap on this icon to set the language.



Raise To Wake

Tap on this icon to enable power saving mode.

Vibration Intensity



System Info Shows the device details.

Tap on this to reset watch data *Note: All data will be erased if watch is reset.

Power off

Tap on this to set the date and time format.

Date &Time

You can set or change your watch password from here.

Tap on this to switch your watch off.

SWIPE DOWN FOR SHORTCUT MENU

You can access DND, Brightness, Settings, find my phone etc.





SWIPE LEFT TO ACCESS ALL DATA sleep, weather, music player from here or select any other menu



FOR RECENTLY USED APPS

to add by clicking on '+'

SWIPE UP TO ACCESS THE NOTIFICATIONS You can check all the notifications from here. Click the delete icon to delete all the notifications.

PRODUCT PARAMETERS

NAVIGATING THROUGH THE FUNCTIONS

SHORT PRESS THE BOTTOM SIDE BUTTON

Add up to 10 contacts from boat Crest app. You can select any

Use the dialer to dial any number from the watch

FOR MAIN MENU

Contact Person

Recent Calls

Voice Assistant

ommand from the watch.

Model	boAt Wave Armour 2	
Screen type	1.96" HD Display	
Battery capacity	400 mAh	
Net weight	35.5g	
Bluetooth version	BLE 5.1	
Working temperature	0-40℃	
Charging time	up to 2 hours	_
Working time	up to 3 days with BT calling, up to 7 days in normal mode	
Water Resistance	IP68	_
Frequency band	no	_

MAINTENANCE Regularly clean your wrist and the strap of the smartwatch, especially after sweating

then follow the above procedure.

during exercise or being exposed to substances such as soap or detergent, which may get stuck on the other end of the product. Do not wash the strap with a household cleanser. Please use soap less detergent, rinse thoroughly and wipe with a piece of soft towel or napkin. For spots or stains that are not easy to remove, scrub the area with rubbing alcohol and

Search for the app to connect keeps failing 1. Keep the boAt Crest app updated to the latest version

2. Close all the programs on the watch -> Stop and restart Bluetooth and GPS -> Connect again 3. Check and enable notification functions of your phone and keep the phone and watch in

Also make sure your notification center of the phone is displaying messages. Only then will your

Note: Make sure your phone system meets Android 7.0 and above and iOS 10.0 and above My Wave Armour 2 is receiving no alerts, texts, or phone calls Make sure smart reminders on the app are on and synced to the Wave Armour 2.

smartwatch also display those notifications. Make sure app is running in the background and battery optimization feature on the phone is

Make sure the app is running in background

My Bluetooth keeps getting disconnected 1. Make sure there is not more than 7m distance between Bluetooth on the phone and the watch. 2. There is no obstacle in between the watch and the phone.

and custom watch faces and Bluetooth calling need Bluetooth connectivity to work.

Which functions of the Wave Armour 2 need Bluetooth to work? Call & Text Notifications, Find My Phone, music control, camera control, weather forecast, cloud

Will it be okay to take a bath wearing the Wave Armour 2? The IP68 water resistance will only work under the following conditions

SAFETY & PRODUCT INFORMATION

Do not disassemble, bore or damage the battery.

(1) Maximum depth of water: 1.5m (2) Maximum time for exposure to water: 10 minutes The watch isn't suitable for hot baths, hot springs, saunas, snorkeling, diving, water skiing and other wading or deep-water activities with high-speed water flow.

Do not disassemble the built in batteries of non-replaceable battery devices. Do not use sharp objects to remove the battery.

If you are wearing a pacemaker or other implanted electronic devices, please consult your

HEALTH WARNING

Female Wellness

doctor before using the heart rate monitor of the watch. The optical heart rate sensor will glow green. If you suffer from epilepsy or are sensitive to blinking light sources, please consult your physician before wearing this device. The device tracks your daily activities through sensors. This data is intended to tell you about

your daily activities such as steps, sleep, distance, heart rate and calories, but may not be

- completely accurate. The device accessories, heart rate sensor, oxygen level monitor, and other relevant data is designed for fitness and not for medical purposes. They are not applicable to the diagnosis, pressure data is for reference only. We're not responsible for any deviation in data
- Avoid wearing the watch too tightly. Make sure you keep your skin dry the area that comes in contact with the watch. If symptoms such as redness or swelling appear on your skin, immediately stop using the watch and consult the doctor.

THINGS TO KEEP IN MIND

Sync data everyday days to avoid data loss:

- Water Resistance will not work for seawater, acidic and alkaline solutions, chemical reagents and other corrosive liquid. The damage or defects caused by misuse or improper use are not
- Sports modes support up to 6 hours of exercise at a time. Avoid wearing the watch too tight in daily use. Keep the parts of skin touching the watch dry. Keep your arm still while measuring data for accurate measurement.
- Disclaimer: This product is an electronic monitoring product and is not intended as a medical reference. We reserve the right to modify or improve any of the functions described in this manual without any prior notice. At the same time, we hold the right to continuously update the product

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS. Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort you

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT SUBSTITUTE.

contribute to recycle valuable raw materials and treatment of toxic substances.









