

WATCH  
VERTEX



boAt

## WATCH VERTEX

Thank you for choosing the boAt Watch as your fitness transformation companion.

Allow this manual to guide you through the functioning of your smartwatch. Please read it thoroughly before using it for a smooth sail. You may refer to these instructions for later use as well.



Package Contains:  
• boAt Watch x1 • USB magnetic charging cable x1  
• User Manual x1 • Warranty Card x1

### USER MANUAL

### CHARGING THE WATCH

The smartwatch must be charged before initial use. It takes 2 hours to be fully charged. Connect and charge the watch with the image below as a reference, using a 5V/2A adapter.




Note:  
Once your watch is at 10% battery, it will automatically switch to power saving mode which will disable all functions.

### TURNING THE WATCH ON/OFF

To turn the watch on/off, long-press the side button for 3-5 seconds.

You can wake the screen by lifting your wrist. Enable the feature on the app to use.



### CONNECTING TO THE APP

1. Download the boAt Crest app on your phone.

Available on both App Store (iOS 13.0 and above) and Google Play Store (Android 7.0 and above)

OR

Scan [QR CODE] (Also available on the watch)

2. Connect the device directly with the mobile application. Do not connect with the phone's Bluetooth directly.

3. Select Vertex on the home screen of the app and click OK to connect.

4. To use all features of your Watch Vertex seamlessly, tap on 'yes' to the 'connection' and 'grant access' system prompt.

5. Turn your phone's Bluetooth and GPS on.

Note:  
To ensure connectivity throughout your journey, make sure the app is allowed to run in the background of your phone at all times.



### SYNCING YOUR SMARTWATCH TO THE APP

#### Data Synchronization

• Open the app on your phone.  
• Make sure your watch Vertex is connected to the app.

• Synchronization will start automatically once you enter the app interface.

Note:  
Synchronize data at least once every day to avoid data loss in the watch.

#### NAVIGATING THROUGH THE FUNCTIONS

Changing the dial interface  
Using the app

Select cloud watch faces on the app and push your preferred watch face to your smartwatch.

Go to settings -> watch faces -> select your preferred watch face -> Select apply.

Using the watch Vertex

Long press the home screen to choose watch faces from the available options.

Swipe up from the home screen to enter the main menu.



### MESSAGES

#### Messages

Turn this feature on from your app to receive notifications on your watch Vertex.

#### Steps, Distance & Calorie Monitor

You can view daily records of steps, distance and calories on the app as well as your smart watch. The data will be cleared at the end of every day.

Note:  
All records will be available on the app if you keep it synchronized.

#### Sleep Monitor

Tap on the icon to review the sleep data of the previous night.

Once the asleep criteria is met, your watch Vertex will start recording from 8 pm at night to 10 am in the morning the next day.

Once you lie down and watch detects no movement for 30 minutes, it will start recording, and will stop recording if it detects excessive movement.

You can check the data on the app only after the awake criteria is met.

Note:  
\*For accurate sleep data recording, the asleep criteria has to be met which includes limited movement, wrist positions and angles, and more.  
\*The awake criteria will be met only after it records some noticeable movement.

### TRAINING MODE

#### Training Mode

Click on the sports mode icon to choose from 7 different sports modes: Walking, Running, Cycling, Skipping, Badminton, Basketball, Football.

To pause or stop the exercise, press the side button.

Note:  
• Minimum of 3 minutes of exercise is required in order to store the data. Data will not be recorded for less than 3 minutes of exercise.  
• All records will be available on the app if you keep it synchronized.

\*The touch screen will not function when exposed to water. When your watch does get wet, wipe the surface with a soft cloth before using it.

Make sure maximum depth of water is 1.5m & maximum time for exposure to water is 30 minutes.

#### Heart Rate Monitor

Click on the heart rate monitor icon to check heart rate data for the day. For accurate measurements, try to stay still and raise your hand to the same level as your heart. It should start measuring in about 2 seconds and last up to 20 seconds to complete the measurement. To allow the watch to measure your heart rate automatically throughout the day, enable the function on the app.

Note:  
• For accurate sleep data recording, the asleep criteria has to be met which includes limited movement, wrist positions and angles, and more.  
\*The awake criteria will be met only after it records some noticeable movement.

For Auto heart rate monitoring, make sure you enable this feature from the app. Settings-> Auto HR tracker

Note:  
Measurements are for reference only and not for medical purposes.



**Blood Oxygen Level Monitor**  
Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app.

Note:  
Measurements are for reference only and not for medical purposes as this is not a medical grade equipment.



**Camera Control Mode**  
Click on the remote camera icon on your watch Vertex to click a photo from your phone.  
Make sure you open boAt crest app first in order to take pictures.



**Music Control Mode**  
Tap on this icon to launch music control mode.

Note:  
Ensure the music App is running on your phone for this feature to work properly. This feature might not work for some of the Music Apps with different control protocols.



**Guided Breathing Mode**  
Click on the breath training icon to regulate your breathing with the instructions given to relax.



**Flashlight**  
Tap on this icon to turn your screen into a flashlight when in need.

### Settings

You can access stopwatch, alarms, countdown, brightness, vibration & theater mode, reset, power off, about the device, and QR code from the settings menu.

Swipe right or left to enter shortcuts for training mode, sleep, heart rate, camera and music control.

Swipe down from the home screen to enter the shortcut menu.  
You can access connectivity status, vibration mode, theater mode, flashlight, brightness, alarm and settings from here.

### PRODUCT PARAMETERS

Model:	Watch Vertex
Screen type:	1.69" Full touch LCD display
Battery capacity:	200 mAh
Net weight:	45 g
Bluetooth version:	5.1
Working temperature:	-20°C-60°C
Charging time:	2 hours
Working time:	up to 7 days
Maximum transmit power:	100mW
Frequency band:	2402—2408

### MAINTENANCE:

Regularly clean your wrist and the strap of the smartwatch, especially after sweating during exercise or being exposed to substances such as soap or detergent, which may get stuck on the other end of the product.  
Do not wash the strap with a household cleanser. Please use soap less detergent, rinse thoroughly and wipe with a piece of soft towel or paper.  
For spots or stains that are not easy to remove, scrub the area with rubbing alcohol and then follow the above procedure.

### FAQ

#### Search for the app to connect keeps failing

1. Keep the boAt Crest app updated to the latest version
2. Close all the programs on the watch —> Stop and restart Bluetooth and GPS —> Connect again
3. Check and enable notification functions of your phone and keep the phone and watch in close contact.

Note: Make sure your phone system meets Android 7.0 and above and iOS 13.0 and above.

#### My Watch Vertex is receiving no alerts, texts, or phone calls

Make sure smart reminders on the app are on and synced to the Watch Vertex.

Also make sure your notification center of the phone is displaying messages. Only then will your smartwatch also display those notifications.

#### My Bluetooth keeps getting disconnected

1. Make sure there is not more than 5m distance between Bluetooth on the phone and the watch.
2. There is no obstacle in between the watch and the phone.

#### Which functions of the Watch Vertex need Bluetooth to work?

Activity tracker, Sleep Monitor, Alarm Clock, Sports Mode, Call & Text Notifications, Find My Phone, Music control, Camera control need Bluetooth connectivity to work.

#### The time displayed on my phone and on the watch Vertex are inconsistent

Make sure your watch Vertex is connected to your phone through the app and not your phone's bluetooth feature itself.

#### The calculated number of steps on the app and on the watch Vertex are inconsistent

Ensure that your app and the watch Vertex are synchronized.

#### Will it be okay to take a bath wearing the watch Vertex?

The IP68 water resistance will only work under the following conditions:

- (1) Maximum depth of water: 1.5m
  - (2) Maximum time for exposure to water: 30 minutes
- The watch isn't suitable for hot baths, hot springs, saunas, snorkeling, diving, water skiing and other wading or deep-water activities with high-speed water flow.

### SAFETY & PRODUCT INFORMATION

#### Battery

• Do not disassemble, bore or damage the battery.  
• Do not disassemble the built-in batteries of non-replaceable battery devices.  
• Do not use sharp objects to remove the battery.

#### Health Warning

• If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitor of the watch.

• The optical heart rate sensor will glow green and red. If you suffer from epilepsy or are sensitive to blinking light sources, please consult your physician before wearing this device.

• The device tracks your daily activities through sensors. This data is intended to tell you about your daily activities such as steps, sleep, distance, heart rate and calories, but may not be completely accurate.

• The device accessories, heart rate sensor, blood pressure, oxygen level monitor, and other relevant data is designed for fitness and not for medical purposes. They are not applicable to the diagnosis, monitoring, treatment or prevention of any diseases or symptoms. The heart rate and blood pressure data is for reference only. We're not responsible for any deviation in data.

• Avoid wearing the watch too tightly. Make sure you keep your skin dry — the area that comes in contact with the watch. If symptoms such as redness or swelling appear on your skin, immediately stop using the watch and consult the doctor.

#### Things to keep in mind

• Sync data every day to avoid data loss.  
• Water Resistance will not work for seawater, acidic and alkaline solutions, chemical reagents and other corrosive liquid. The damage or defects caused by misuse or improper use are not covered by the warranty.  
• Sports modes support up to 6 hours of exercise at a time.

• Avoid wearing the watch too tight in daily use.  
• Keep the parts of skin touching the watch dry.  
• Keep your arm still while measuring data to accurate measurement.

Disclaimer: This product is an electronic monitoring product and is not intended as a medical reference. We reserve the right to modify or improve any of the functions described in this manual without any prior notice. At the same time, we hold the right to continuously update the product content.

CAUTION  
RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT SUBSTITUTE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort you contribute to recycle valuable raw materials and treatment of toxic substances.