DOAT **WAVE PRO**

Thank you for choosing the boAt Wave pro as your fitness transformation companion.

Allow this manual to guide you through the functioning of your smartwatch. Please read it thoroughly before using it for a smooth sail. You may refer to these instructions for later use as well.



Tap on this icon to play in-built game.

Tap on this icon to find your phone. Once enabled,

your phone will start ringing and vibrating. Tap again

Note: Your watch Wave pro should be connected to your

phone via Bluetooth and within its range for this feature

The smartwatch must be charged before initial use. It takes 2 hours to be fully charged.

> Connect and charge the watch with the image below as a reference, using a 5V/2A adapter.

To turn the watch on/off, long-press side button for 3-5 seconds.



CONNECTING TO THE APP

1. Download the boAt Crest app on your phone.

Scan [QR CODE] (Also available on the watch)

- 4. To use all features of your Watch Wave pro seamlessly, tap on 'yes' to the 'connection' and 'grant access' system prompt.
- 6. Disable battery optimization

SYNCING YOUR SMARTWATCH TO THE APP

Data Synchronization

Open the app on your phone.

 Make sure your Wave Pro is connected to Synchronization will start automatically once

you enter the app interface.

Synchronize data at least once every day to avoid data loss in the watch.

NAVIGATING THROUGH THE FUNCTIONS

Changing the dial interface

Using the app

Select cloud watch faces on the app and push your preferred watch face

Make sure your watch and phone are connected via Bluetooth. Do not exit the downloading interface until it displays 100% downloaded. It may take up to 60 secs to sync the watch face with the app.

Using the Wave Pro

Go to settings in the main menu of the watch->Scroll down Select 'watch faces'-> Tap on your preferred display.

Short press the side button once to enter the main menu



Activity (accept

Click on this icon to choose from 15 different sports modes: Walking, Treadmill, Running, Badminton, Football, Basketball, Tennis, Yoga, Dancing, Indoor Cycling, Cricket, Boxing, Karate, Table Tennis & Pilates. To pause or stop the exercise, press the home button.

*All records will be available on the app if you keep it

Activity Records

Tap on this icon to check sports records.



Heart Rate Monitor

Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the

Note: Measurements are for reference only and not for

Note: Resting heart rate will be calculated between 6AM

market for \$5mil.

Blood Oxygen Level Monitor

Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the

Note: Measurements are for reference only and not for medical purposes.

Tap on the icon to review the sleep data of the

Once the asleep criteria is met, your watch Wave Pro

Once you lie down and watch detects no movement

for 30 minutes, It will start recording, and will stop

You can check the data on the app only after the

*For accurate sleep data recording, the asleep criteria has to be met which includes limited movement, wrist

*The awake criteria will be met only after it records some noticeable movement

recording if it detects excessive movement.

will start recording from 8 pm at night to 10 am in the



Guided Breathing Mode

Temperature Monitor


Click on the breath training icon to regulate your reathing with the instructions given to relax.

Tap on this icon to measure your body temperature



Turn this feature on from your app to receive notifications on your watch.

Note: The watch can be used to reject calls only.



Tap on this icon to set alarms

00:03.58

Tap on this icon to turn your screen into the flashlight.

Tap on the icon to start the stopwatch.

Tap on this icon to start the timer.




WAVE PRO

pro to click a photo from your phone.

feature.

Note: Ensure the music App is running on your phone for this feature to work properly. This feature might not work for some of the Music Apps with different control





AMBIN . OLD ut.

You can view daily records of steps, distance and

calories on the app as well as your smart watch. The data will be cleared at the end of every day.

Note: All records will be available on the app if you keep it synchronized.

Camera Control

Click on the remote camera icon on your watch Wave

Note: Turn the camera on from your app to use this



Tap on this icon to aunch music control mode.

Tap on this icon to use the calculator.

Tap on this icon to change your watch face.















Once your watch is at 5% battery, it will automatically switch to power saving mode which will disable all functions.

oAt Wave Pro x1 • USB magnetic charging cable x1

User Manual x1 • Warranty Card x1

TURNING THE WATCH ON/OFF

CHARGING THE WATCH

You can wake the screen by lifting your wrist. Enable on the shortcut menu of the watch

Screen sleen



Available on both App Store (iOS 13.0 and above and Google Play Store (Android 7.0 and above)

2. Connect the device directly via the mobile application. Do not connect via the phone's Bluetooth directly.

3. Select Wave pro on the home screen of the app and click OK to connect.

5. Turn your phone's Bluetooth and GPS on.

To ensure connectivity throughout your journey, make sure the app is allowed to run in the background of your phone at all times.

iPhones will not prompt any information unless you complete Bluetooth pairing with WAVE PRO.

Tap on this to restart your watch.



Tap on this icon to set screen timeout duration.

Screen on time

Tap on this icon to set screen on duration. Enable this feature from the shortcut menu.



Set your preferred vibration intensity for your watch



Note: battery will drain out quickly once this feature is







Tap on this to switch your watch off.

Tap on this to reset watch data.

*Note: All data will be erased if watch is reset

Tap on this icon to download the app through QR code.

Tap on this icon to view information about the watch.

Swipe down for shortcut menu You can access DND, find my phone, screen on gesture, alarms, brightness and settings.

Swipe left or right to access records and monitors You can access daily activity and sports records, heart rate monitor, blood oxygen monitor, temperature monitor, sleep monitor, music control and notifications from here

boAt Wave Pro

Swipe up to view live cricket scores.

Enable this feature from the app to use. Go to the home page -> tap on the cricket icon on the top right corner -> Select the

match and time Intervals to receive notifications on the watch.

PRODUCT PARAMETERS:

rpe	1.69" HD Disp l ay
apacity	200 mAh
ht	44g
version	Bluetooth 5.0
temperature	20 \sim 60 degree
time	about 30 mins
time	about 7 days
n transmission power	8dBm
y band	2402 - 2480 MHz

Regularly clean your wrist and the strap of the smartwatch, especially after sweating during exercise or being exposed to substances such as soap or detergent, which may get stuck on the other end of the product.

Do not wash the strap with a household cleanser. Please use soap less detergent, rinse thoroughly and wipe with a piece of soft towel or napkin.

For spots or stains that are not easy to remove, scrub the area with rubbing alcohol and then follow the above procedure.

Search for the app to connect keeps failing

1. Keep the boAt Crest app updated to the latest version 2. Close all the programs on the watch → Stop and restart Bluetooth and GPS → Connec

3. Check and enable notification functions of your phone and keep the phone and watch in close contact. Note: Make sure your phone system meets Android 7.0 and above and iOS 13.0 and above

My Watch Wave pro is receiving no alerts, texts, or phone calls

. There is no obstacle in between the watch and the phone.

Make sure smart reminders on the app are on and synced to the Watch Wave pro. Also make sure your notification centre of the phone is displaying messages. Only ther will your smartwatch also display those notifications.

My Bluetooth keeps getting disconnected 1. Make sure there is not more than 7m distance between Bluetooth on the phone and

Which functions of the Watch Wave pro need Bluetooth to work? Call & Text Notifications, Find My Phone, music control, cloud and custom watch faces

The time displayed on my phone and on the watch Wave pro are inconsistent Make sure your watch wave pro is connected to your phone through the app and not your phone's Bluetooth feature itself.

The calculated number of steps on the app and on the watch Wave pro

morning the next day.

awake criteria is met.

positions and angles, and more.

Ensure that your app and the watch Wave pro are synchronized. Will it be okay to take a bath wearing the watch Wave pro?

The IP68 water resistance will only work under the following conditions: (1) Maximum depth of water: 1.5m (2) Maximum time for exposure to water: 30 minutes

skiing and other wading or deep-water activities with high-speed water flow.

Why is my blood oxygen level measurement not accurate? The measurements are for reference only because there is a different way to measure your blood ocygen levels on your watch and a different way when medical equipment is

The watch isn't suitable for hot baths, hot springs, saunas, snorkeling, diving, water

The measurements are for reference only because there is a different way to measure your temperature on your watch and a different way when medical equipment is used.

Why is my temperature monitoring not accurate?

Note: Notifications can be received for 1 match at a time.

How do I receive live cricket scores? Go to app home page-> click on the cricket icon top right corner-> select the match for which you want to receive notifications -> Select the time interval

What is the average rate of fast charging: Watch will be fully charged in 30 minutes.

SAFETY & PRODUCT INFORMATION

Do not disassemble, bore or damage the battery. Do not disassemble the built in batteries of non-replaceable battery devices. Do not use sharp objects to remove the battery.

• If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitor of the watch.

The optical heart rate sensor will glow green and flash. If you suffer from epilepsy or are sensitive to blinking light sources, please consult your physician before wearing this device.

The device tracks your daily activities through sensors. This data is intended to tell you about your daily activities such as steps, sleep, distance, heart rate and calories, but may not be completely

 The device accessories, heart rate sensor, blood oxygen level monitor, and other relevant data is designed for fitness and not for medical purposes. They are not applicable to the diagnosis, monitoring, treatment or prevention of any diseases or symptoms. The heart rate and blood oxyger data is for reference only. We're not responsible for any deviation in data.

Avoid wearing the watch too tightly. Make sure you keep your skin dry- the area that comes in contact with the watch. If symptoms such as redness or swelling appear on your skin, immediately

stop using the watch and consult the doctor.

Sync data everyday to avoid data loss.
 Water Resistance will not work for seawater, acidic and alkaline solutions, chemical reagents and

Sports modes support up to 6 hours of exercise at a time.
 Avoid wearing the watch too tight in daily use. Keep the parts of skin touching the watch dry.
 Keep your arm still while measuring data for accurate measurement.

Disclaimer: This product is an electronic monitoring product and is not intended as a medical reference. We reserve the right to modify or improve any of the functions described in this manual without any prior notice. At the same time, we hold the right to continuously update the product

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT SUBSTITUTE.

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort you contribute to recycle

Charging norms & Precautionary Guidelines: -

) Charger/Brick/Adapter : 5V 2A Any other accessory can be paired up with the product as long as the specifications are as per above norms.

