



boat

WAVE ULTIMA MAX

Thank you for choosing the boAt Wave Ultima Max as your fitness transformation companion.

Allow this manual to guide you through the functioning of your smartwatch. Please read it thoroughly before using it for a smooth sail. You may refer to these instructions for later use as well.




PACKAGE CONTAINS:

- boAt Wave Ultima Max x1
- USB magnetic charging cable x1
- User Manual x1
- Warranty Card x1

CHARGING THE WATCH

The smartwatch must be charged before initial use. It takes 2 hours to be fully charged. Connect and charge the watch with the image below as a reference, using a 5V/2A adapter.



Note: Once your watch is at 10% battery, it will automatically switch to power saving mode which will disable all functions.

TURNING THE WATCH ON/OFF

To turn the watch on/off, long-press the side button for 3-5 seconds. You can wake the screen by lifting your wrist.



CONNECTING TO THE APP

1. Download the boAt Wearables app on your phone.

Available on both App Store (iOS 12.0 and above) and Google Play Store (Android 6.0 and above)

OR

Scan [QR CODE] (Also available on the watch)

2. Connect the device with the boAt Wearables app

3. Select Ultima Max on the home screen of the app and click pair to connect.

4. To use all features of your Ultima Max seamlessly, tap on 'yes' to the 'connection' and 'grant access' system prompt.

5. Turn your phone's Bluetooth and GPS on.

6. Disable battery optimization



Note: To ensure connectivity throughout your journey, make sure the app is allowed to run in the background of your phone at all times. iPhones will not prompt any information unless you complete Bluetooth pairing with WAVE ULTIMA MAX.



SYNCING YOUR SMARTWATCH TO THE APP

Data Synchronization

- Open the app on your phone.
- Make sure Wave Ultima Max is connected to the app.
- Synchronization will start automatically once you enter the app interface.

Note:

Synchronize data at least once a day to avoid data loss in the watch.

NAVIGATING THROUGH THE FUNCTIONS

Swipe up for main menu

Activity Records

Tap to check Activity Records of the day.



Sleep Monitor

Tap on the icon to review the sleep data of the previous night. Once the asleep criteria is met, your Ultima Max will start recording from 8 pm at night to 10 am in the morning the next day. Once you lie down and watch detects no movement for 30 minutes, it will start recording, and will stop recording if it detects excessive movement. You can check the data on the app only after the awake criteria is met. You can also track sleep scores on the boAt Wearables app.



Note:

*For accurate sleep data recording, the asleep criteria has to be met which includes limited movement, wrist positions and angles, and more.
*The awake criteria will be met only after it records some noticeable movement

Heart Rate Monitor

Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app.



Notes:

Measurements are for reference only and not for medical purposes.

Workout

Click on the workout icon to choose from different sports modes: Walking, Running, Cycling, Skipping, Badminton, Football, Basketball, Swimming, Climbing, Tennis, Rugby, Golf, Yoga, Workout, Dancing, Baseball, Elliptical, Indoor Cycling, Free Training, Rowing, Outdoor Running, Skiing, Bowling, Dumbbell, Sit ups

To pause or stop the exercise, press the home button, click finish to end the exercise.



Notes:

*All records will be available on the app if you keep it synchronized.

Blood Oxygen Level Monitor

Wear the watch on your wrist, then click on the icon to click a photo from your phone.



Notes:

Measurements are for reference only and not for medical purposes.


Weather

Tap on this to know weather forecast for the next 5 days.



Messages

Tap on this to check your notifications. You can also swipe up from the home screen to view your notifications.



Camera Control Mode

Tap on the remote camera icon on your Ultima Max to click a photo from your phone.



Notes:

Turn the camera on from your phone to use this feature.

Music Control

Tap on the remote music control icon on your Wave Ultima Max to play music from your phone.



Notes:

Some apps with different protocols might not work.


Guided Breathing Mode

Click on the breath training icon to regulate your breathing with the instructions given to relax.



Stopwatch

Tap on the icon to start the stopwatch.



WAVE ULTIMA MAX

USER MANUAL

Alarm

Tap on this to set an alarm on your watch.



Timer

Tap on this to turn on the timer.



Flashlight

Tap on this to turn your dial into a flashlight.



Settings

Brightness

Tap on this to adjust the brightness of your watch.



Vibration

Tap on this to enable or disable vibration settings on your watch.



Do Not Disturb

Tap on this to disable all notifications except alarms.



Theater Mode

Tap on this to reduce brightness and mute your notifications.



Watch Faces

Tap on this icon to change your watch face.



Factory Reset

Tap on this to reset watch data.

Notes:

All data will be erased if watch is reset



Power off

Tap on this to switch your watch off.



App QR code

Tap on this to access the app QR code on your watch.

About

Tap on this to know information about your watch.

Swipe down for shortcut menu

You can access Settings, Brightness, DND, About, App QR Code & Power Off from here.

PRODUCT PARAMETERS:

Model	boAt Ultima Max
Screen Type	1.9" HD Display
Battery Capacity	300 mAh
Net weight	70g
Bluetooth version	BLES 0
Working temperature	20-50 degree
Charging time	about 2 hours
Working time	up to 15 days
Maximum transmission power	5V
Frequency band	2402 - 2480 MHz

Maintenance:

Regularly clean your wrist and the strap of the smartwatch, especially after sweating during exercise or being exposed to substances such as soap or detergent, which may get stuck on the other end of the product.

Do not wash the strap with a household cleanser. Please use soap less detergent, rinse thoroughly and wipe with a piece of soft towel or napkin.

For spots or stains that are not easy to remove, scrub the area with rubbing alcohol and then follow the above procedure.

FAQ

Search for the app to connect keeps failing

1. Keep the boAt Wearables app updated to the latest version
2. Close all the programs on the watch→Stop and restart Bluetooth and GPS→Connect again
3. Check and enable notification functions of your phone and keep the phone and watch in close contact.

Note: Make sure your phone system meets Android 6.0 and above and iOS 9.0 and above.

My Wave Ultima Max is receiving no alerts, texts, or phone calls

Make sure smart reminders on the app are on and synced to the Ultima Max. Also make sure your notification center of the phone is displaying messages. Only then will your smartwatch also display those notifications. Make sure app is running in the background and battery optimization feature on the phone is disabled.

My Bluetooth keeps getting disconnected

1. Make sure there is not more than 7m distance between Bluetooth on the phone & the watch.
2. There is no obstacle in between the watch and the phone.
3. Make sure the app is running in background

Which functions of the Ultima Max need Bluetooth to work?

Call & Text Notifications, Find My Phone, music control, camera control, weather forecast, cloud and custom watch faces and need Bluetooth connectivity to work.

Will it be okay to take a bath wearing the Ultima Max?

The IP68 water resistance will only work under the following conditions:

- (1) Maximum depth of water: 1.5m (2) Maximum time for exposure to water: 10 minutes

The watch isn't suitable for hot baths, hot springs, saunas, snorkeling, diving, water skiing and other wading or deep-water activities with high-speed water flow.

SAFETY & PRODUCT INFORMATION

Battery

- Do not disassemble, bore or damage the battery.
- Do not disassemble the built-in batteries of non-replaceable battery devices.
- Do not use sharp objects to remove the battery.

Health Warning

- If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitor of the watch.
- The optical heart rate sensor will glow green. If you suffer from epilepsy or are sensitive to blinking light sources, please consult your physician before wearing this device.
- The device tracks your daily activities through sensors. This data is intended to tell you about your daily activities such as steps, sleep, distance, heart rate and calories, but may not be completely accurate.

The device accessories, heart rate sensor, oxygen level monitor, and other relevant data is designed for fitness and not for medical purposes. They are not applicable to the diagnosis, monitoring, treatment or prevention of any diseases or symptoms. The heart rate and blood pressure data is for reference only. We're not responsible for any deviation in data.

Avoid wearing the watch too tightly. Make sure you keep your skin dry - the area that comes in contact with the watch. If symptoms such as redness or swelling appear on your skin, immediately stop using the watch and consult the doctor.

WAVE ULTIMA MAX

