

Technical Specifications

Materials	Aluminium
Connections	½" flow and return.
Test pressure	13 Bar
Testing authority	EN442
Maximum operating pressure	10 Bar
Maximum working temperature	90 °C
Packaging	Double layered box with internal protection

PLEASE NOTE: To reduce the possibility of noise caused by rapid heating and cooling of aluminium radiators; adequate capacity for expansion must be provided within the overall heating system. Systems using micro bore pipework must have adequate pressure and flow rates for the number and style of radiators on the system.

Terms & Conditions

All products must be inspected once removed from the packaging and The Radiator Company notified within 28 days of delivery of any scratches, blemishes or other damage. The Radiator Company will then replace the radiator.

Imperfect radiators should therefore not be fitted and The Radiator Company will not accept responsibility for replacement of scratched or damaged radiators once they have been fitted. This includes any consequential loss or cost of fitting.

If The Radiator Company are not notified within 28 days of the date on the signed delivery note then it will be deemed that The Radiator Company have fully complied with its obligations and claims will not be considered.

Failure to comply with any of the above may invalidate any claims.

We recommend that after you check the product on delivery that it is stored in its packaging to prevent damage prior to installation. The Radiator Company cannot accept responsibility for items damaged after delivery.

Guarantees & Liabilities

As we are not the manufacturers of this product we will take all reasonable endeavours to make over to you the benefit of any warranty or guarantee given by the manufacturer, which is usually five years on most of our range. (Copies of specific guarantees for any of our products are available on request).

The guarantees in all cases are subject to the products being installed in accordance with British and or European standards as well as these fitting instructions. The guarantees in all cases are restricted to the free of charge replacement or repair of the failed product only. Our liability will under no circumstances extend beyond the repair or replacement of the product supplied by us. Claims for either labour in replacement or damage to property are not admissible. Any goods that are returned, in the event of a problem, will belong to The Radiator Company.

Fittings Instructions




Please read these instructions and terms and conditions carefully prior to installation. Failure to do so may invalidate the warranty

The Radiator Company
Units 13 - 14 Charlwoods Road
East Grinstead
West Sussex
RH19 2HU





Diagrams of Kura

Same dimensions for all horizontal and vertical models:



X = fixed diverter position



Minimum depth from wall & pipe centres from wall


Maximum depth from wall & pipe centres from wall

Pipe Centres

Pipe centres left to right	width - 15mm + Valves
Pipe centres from wall	30mm - 75mm
Depth from wall	90mm - 135mm

1 Unpack & Inspect

The Radiator Company prides itself on selecting products from manufacturers who exercise tight quality control measures. We only select models with excellent standards of welding and brazing, as well as high quality finishes. All of our products are well packaged and should reach you in perfect condition. Just in case however, we offer a minimum 5-year no quibble guarantee for all radiators and towel rails.



Please carefully unpack and inspect this radiator and all fittings.

The Radiator Company must be notified of any shortages or damage within 28 days of delivery. For further information please see terms and conditions on back page.

2 Contents

You should have:


- 1 Radiator
- 4 Brackets (consisting of two parts and a screw)
- 1 Fixed Diverter - *the diverter for the Kura is fixed and cannot be moved, it is positioned between the 1st and 2nd element from the left (please see diagram opposite)*

You will need:


- Suitable drill bits, plugs and screws for your wall type
- 3mm Allen Key
- Crosshead Screwdriver
- Spirit Level
- Drill

3 Mark Bracket Positions

1. Brackets are supplied fixed to the radiator. Loosen the L-Shape bracket with an Allen Key, tilt up (to the position shown) and tighten.




2. Stickers are available to use on the L shape brackets to mark out the bracket positions on the wall; the top layer needs to be peeled off, and you can then lift your radiator and press against the wall, and the stickers will stick to the wall in the bracket positions. If you prefer you can use the dimensions in the diagrams opposite to mark out the bracket positions.




4 Fix Brackets and Hang Radiator


3. Remove the L-Shape bracket from the radiator and fix to the wall in the positions shown, using a suitable drill bit, plugs and screws. Use a spirit level to ensure the brackets are vertically and horizontally level.




4. Lift up the radiator and place into position. The top brackets will sit under the top collector as support.




5. Using an allen key re-attach the L-Shape Brackets to the bracket body on the top two brackets first, then the bottom.



6. The Brackets can slide along the collector to alter the position of the radiator.



Ensure the radiator is in its final position and secure the brackets in place using a 3mm Allen key on the grub screws on the bracket body.



PLEASE NOTE :

It is essential that all brackets are level to ensure a vertical alignment for connecting the pipe work.

5 Commission

In accordance with Part L1 2006 of the Building Regulations and BS7593:1992 code of practice for the treatment of hot water and central heating systems, we strongly recommend flushing the heating system post installation of new radiators and then adding the correct quantity and type of inhibitor for use with your radiator and system to prevent corrosion. Damage caused to systems not protected by a suitable inhibitor will not be covered by manufacturer's guarantee.