



USER
MANUAL

S4.



1. Rotating crown key
2. Premium metal casing
3. Sensors
4. Microphone
5. Speaker
6. Multifunction Button

SPECIAL FEATURES

1.8" 3D Curved Screen Display

Bluetooth **Voice calling**

Split screen display

Triple theme display

Blood **Glucose**

Health Monitors

In-built **18 watch faces**

Customizable Widgets

Up to **7 days** battery

Location sharing

Voice assistant enabled

Multisport Training





Scan the QR code to download the
smartwatch app

Or

Download 'WEARFIT PRO' App
from the Playstore or iOS app store

Install straps

To attach the straps, slide in the bottom of the strap into the gap on the watch case.

Similar to a bank card swipe in the machine.



Remove straps

To remove the straps, slide the band outwards from the main watch casing.

Opposite of the installation process.

- Charge the smartwatch before using
- Full charge in less than 90 mins
- Connect the back of the watch to the magnetic charging pin available in the box
- Please use a 5V charging adapter or connect USB with the laptop

NOTE: Do not use any fast/dash charging adapters





Ignite S4 & CB-S4

Note:

- All notifications, alerts, reminder and data received from phone to watch or vice versa will be connected over Ignite S4.
- For calls, CB-S4 needs to be connected.

- Turn on the Bluetooth on your mobile phone.
- Create an account and login to the app
- Open App > device > Add device > choose Ignite S4

NOTE: Once connected, you will receive all the notifications on the watch.



CONNECT – FOR ANDROID

CONNECT – FOR ANDROID




Once the smartwatch is paired with your phone, you will receive a pop-up asking to automatically connect to CB-S4.

OR

- In the watch, swipe from top to bottom once on the main interface
- Enable the 'BT Calling' icon.
- Open the phone's BT settings > Search for 'CB-S4' in your Bluetooth list and connect.
- Upon successful connection, you will be able to make/receive calls from the watch.

- Turn on the Bluetooth on your mobile phone.
- Create an account and login to the app
- Open APP > device > Add device > choose Ignite S4
- In the app, click on 'pair' to connect and 'Cancel' to cancel.
- Click on **allow** in the next pop up in order to receive notifications
- Click on 'pair' to connect and 'Cancel' to cancel

NOTE: Once connected, you will receive all the notifications on the watch.



CONNECT – FOR IOS



CB-S4 connection procedure

- Swipe from top to bottom once on the watch screen.
- Click on the BT calling icon and enable it.
- Search for 'CB-S4' in the phone's BT list and connect.
- Upon successful connection, you will be able to make/receive calls from the watch.

NOTE: To add your favorite contacts, go to Devices tab - Favorite contacts - Add/remove contacts from the list - click Synchronize.

Built in watch faces

- Press & hold the home screen / Rotate the crown key
- You will enter the 'Watch face' menu
- Scroll & select your favorite screen

Note: You can customize the watch faces from the app



Split-screen display

- Swipe from left to right once on the main screen
- You can see the current time, date, and day
- You will be able to access the QR code to connect to the phone
- Click on the 'SOS' icon to make the call

Note : 1) SOS number should be added from the contacts and should be synced
2) CB-S4 should be connected to make the call

- You will be able to access the recent applications used.





Blood Glucose

- Open the 'Wearfit Pro' app, go to 'Devices' tab, click on the Application market tab
- Install 'Blood Glucose reference trend' app and sync it to the watch
- In the watch, click on the crown button or the MFB once to enter the Menu
- Click on the 'app store' icon and select the 'blood sugar' option
- You will be able to view the graph of your blood sugar level, more details will be available in the Wearfit Pro app

Breathe

- Click on crown button/MFB once to enter Menu
- Click on the 'Breathe' icon, and hit the play to start the breathe training
- You can even set the training duration & breathing rhythm

Breathe rate

- In 'Wearfit Pro' app > Devices > Application Market tab
- Install 'Breathe Rate' app & sync it to the watch
- In watch, click on crown button/MFB once to enter Menu
- Open 'app store' > 'breathe rate' > You can view the graph of your breathing level.
- More details will be available in the Wearfit Pro app



Pedometer/distance/calories burnt

- Click on the crown button or the MFB once to enter the Menu
- Click on the 'Data' icon
- You can see **all** the tracked data of steps, distance, and calories burnt
- **Scroll** down for more detailed analysis



Sleep monitor

- Click on the crown button or the MFB once to enter the Menu
- Click on the 'Sleep' icon
- You will be able to see the number of hours slept and also the light and deep sleep analysis
- **Scroll** down for more details

Heart rate

- Click on the crown button or the MFB once to enter the Menu
- Click on the 'HR' icon
- You will be able to check your Heart Rate
- Scroll down for more details



Blood pressure

- Click on the crown button or the MFB once to enter the Menu
- Click on the 'Blood Pressure' icon'
- Wait for 10-15 secs for the reading to complete
- Scroll down for more details

SpO2

- Click on the crown button or the MFB once to enter the Menu
- Click on the 'SpO2' icon
- Wait for 10-15 secs for the reading to complete
- Scroll down for more details



MET

- Click on the crown button or the MFB once to enter the Menu
- Click on the 'MET' icon
- You can see the periodical average of the data

Pressure

- Click on the crown button or the MFB once to enter the Menu
- Click on the 'Pressure' icon
- You get to see the display of the Pressure range (1-29 relaxed, 30-59 normal, 60-79 medium, 80-99 high)



Weather updates

- Click on the crown button or the MFB once to enter the Menu
- Click on the 'Weather' icon
- Check the weather forecast update

Automatic tracking on App

- Open the 'Wearfit Pro' App and go to Devices tab
- Click on the 'Other Settings' tab
- Enable the 'Hourly point measurement'

This function, enables the watch to automatically measure health data every hour



Music control

- Click on the crown button or the MFB once to enter the Menu
- Click on the 'Music' icon
- You can play / pause & change tracks

Indoor Activities

- Click on the crown button or the MFB once to enter the Menu
- Click on the 'Indoor activities' icon to explore 6 different activities



Outdoor Sports

- Click on the crown button or the MFB once to enter the Menu
- Click on the 'Outdoor sports' icon to explore 7 different activities

Call reminder

- Open the 'Wearfit Pro' app and click on the 'Devices' tab
- Click on the 'Notification' icon
- Enable 'incoming call' and 'SMS' alerts

Note: You can speak on the watch as it has in-built speaker and mic. CB-S4 has to be connected to make/receive calls from the watch



Message notifications

- Swipe from bottom to top once on the main screen
- You will be able to see your latest messages

Always-on display


- Swipe from top to bottom once on the main interface
- Click on the 'Always-on' icon to enable/disable it

Note: Use Always-on display with minimal brightness to save battery



Rotating crown key

- Can be used to switch between the watch faces on the home screen
- Can be used to scroll between the apps
- Click on the crown key to return to home screen



Location sharing

- Open the 'Wearfit Pro' app, in the Home tab, click on the 'You and me' tab
- You can add your friends or family members profiles by click on the + symbol > Invite new members.
- By entering their details, you can connect with them and be able to view their health data, location, and more
- In the watch, swipe from top to bottom once on the main screen, click on the location icon
- You will be able to view your friends or family members profiles and their location and health data

Silent/Vibration mode

- Swipe from top to bottom once on the main interface
- Swipe left, enable the vibration mode to silent the notifications on the watch



Screen lock

- Swipe top to bottom on home screen & swipe left
- Click on lock icon to disable touch responses on watch
- Press and hold the rotating crown for 3 secs to unlock watch

Do not disturb mode

- Swipe from top to bottom once on the main interface
- Click on the 'Settings' icon, scroll and select 'Do not disturb mode' and enable it
- In the 'Wearfit Pro' app, go to 'Devices' tab and click on 'Notification' tab
- Enable all the apps from which you wish to get notifications



Camera

- Open 'Wearfit Pro' app, click on "Devices"
- Scroll down to 'Taking pictures' & allow App camera access
- On watch, click crown button or MFB to enter Menu
- Click on the 'Shake to take pictures' icon
- Shake wrist to click pictures

Stopwatch

- Click on the crown button or the MFB once to enter the Menu
- Click on the 'Stopwatch' icon and activate
- You also have Pause option



Countdown

- Click on the crown button or the MFB once to enter the Menu
- Click on the 'Countdown' icon
- Now adjust the time and activate the timer

Brightness

- Click on the crown button or the MFB once to enter the Menu
- Open the 'Set up' app and click on the 'Dimming' icon
- Now you can adjust the brightness of the watch accordingly



Alarm clock

- Go to the Wearfit Pro app and select the Devices tab
- Click on the 'Alarm' to add a new alarm or enable an existing alarm

Calculator

- Click on the crown button or the MFB once to enter the Menu
- Click on the 'Calculator' icon
- You will be able to do the basic calculations



Sedentary reminder

- Go to the 'Wearfit Pro' app
- Click on the 'Devices' tab and then click on the 'Health remind' tab
- Enable the 'Sedentary reminder' in the app
- You can set the timing for idle alert via the App


Drink water reminder

- Go to the 'Wearfit pro' App
- Click on the 'Devices' tab and then click on the 'Health remind' tab
- Enable the 'Drink water reminder' in the app
- You can set the timing for idle alert via the app



Set up


- Swipe from top to bottom once on the main interface
- Click on the 'Settings' icon
- You will be able to access the following features



Wallet

- Go to the 'Wearfit Pro' app
- Click on the 'Devices' tab and then click on the 'Wallet' tab
- Click on the app for which you wish to add the account
- Add the QR code of the app and bind it to the watch
- On the watch, swipe from top to bottom once on the main interface
- Click on the 'Wallet' icon
- You get to see the QR code for the app synced
- Scan the QR code on the watch to process the transaction

Note: Using the QR code, you can send/receive money from others



Business card

- Go to the 'Wearfit Pro' app
- Click on the 'Devices' tab and then click on the 'Business card' tab
- Click on the app for which you wish to add the card
- Add the QR code of the app and bind it to the watch
- On the watch, swipe from top to bottom once on the main interface
- Click on the 'Business card' icon
- You get to see the available QR codes for different apps synced
- Go to the respective app on your phone and scan the QR code to connect

Sound and Vibration

- Swipe from top to bottom once on the main interface
- Click on the 'Settings' icon and select 'Sound and vibration'
- You will be able to control the volume for calls and media
- You also have access to control the vibration level



Add components

- Swipe from right to left once on the main screen
- Click on the + symbol
- You will be able to customize the widgets by adding/removing from the selected apps

Restore factory

- Swipe from top to bottom once on the main interface
- Click on the 'Settings' icon
- Now scroll to 'Restore Factory' and click on it to reset watch




Power off


- Swipe from top to bottom once on the main screen
- Click on the 'Settings' icon
- Now scroll and click on 'Shutdown' to turn the smartwatch off


Disclaimer

- The Ignite S4 will display only the numbers of the caller on the watch screen for call notification alerts.
- Optical sensors present on the back of the smartwatch are used to track the health vitals, do not rely on them for medical purposes.
- These smartwatches sometimes can accidentally detect non-surface object reading due to differences in pressure on the motion sensors.
- Crossbeats will not be responsible for in-app purchases made via WearFit Pro.
- Crossbeats does not save your personal data and is not responsible for any data stored on WearFit Pro.
- Battery life may vary depending on usage patterns.
- The watch charging time might slightly vary depending on how much battery percentage has been depleted and the voltage supply for a charge.
- To receive notifications, calls and other alerts ensure your data and Bluetooth connections are stable.
- Our smartwatches are waterproof and are not suitable for diving. Also using them in the shower with harsh chemicals can damage the watch.
- Use the smartwatch with appropriate apps to achieve the best results.



 +91 96112 93293

 +91 96112 93293

 support@crossbeats.com