



Orbit
Infinite

USER MANUAL



1. Premium Metal body
2. Multi-motion sensors
3. Charging pin
4. 1.39" 3D Curved AMOLED screen
5. Multi-function button
6. Menu button

SPECIAL FEATURES

- Sharp **AMOLED** Display
- 1.39" 3D Curved** Screen
- TWS** Connection
- Bluetooth **Voice calling**
- Music **storage**
- Voice **recording**
- Always-on-display**
- 110+ Sports** modes
- 100+ watch faces**
- Unlimited **contacts**
- 4** themes
- Power saver** mode





Scan the QR code to download the
smartwatch app

Or

Download 'Fit Winner' App from the
Playstore or iOS app store

Install straps

Adjust the quick release lever to sit into the position.

Release the lever when positioned correctly in order to set the strap.



Remove straps



To remove the straps, turn over the watch and find the quick-release lever.

While pressing the quick-release lever inward, gently pull the strap away from the watch to release it.

- Charge the smartwatch before using it
- Full charge in less than 2 hours
- Connect the back of the watch to the magnetic charging pin available in the box
- Please use a 5V charging adapter or connect USB with the laptop

NOTE: Do not use any fast/dash charging adapters






CB-INFINITI & INFINITI AUDIO

Note:


- All notifications, alerts, reminders, and data received from phone to watch or vice versa, will be connected over CB-INFINITI.
- For calls, INFINITI AUDIO needs to be connected.

- Turn on the Bluetooth on your mobile phone.
- Create an account and log in to the app
- Open App > Device > Add a Device > CB-INFINITI

NOTE: Once connected, you will receive all the notifications on the watch.



CONNECT – INFINITI AUDIO



- Open the phone's BT settings > Search for 'INFINITI AUDIO' in your BT list and connect.
- Upon successful connection, you will be able to make/receive calls from the watch

Built in watch faces

- Touch and hold on the home screen
- You will enter the 'Watch face' menu
- Scroll & select your favorite screen





Watch faces in app

- Go to Fit Winner app > Device > Watch
- Market Pick you choice of dial



Pedometer/distance/calories burnt

- Swipe from right to left once on the main screen
- You can see all the tracked data of steps, distance, and calories burnt
- Swipe up for more detailed data



Sleep monitor

- Click on the Menu button once
- Scroll & select the Sleep icon
- You can see the number of hours slept and also the light & deep sleep analysis
- Swipe up for more detailed data

Heart rate

- Swipe from right to left twice on the main screen.
- You will be able to measure your Heart Rate
- Automatic tracking on App
- Open the 'Fit Winner' app > Device
- Enable the Automatic Health Monitor




Blood Pressure

- Click on the Menu button
- Scroll & select the Blood Pressure icon
- Wait for 10-15 secs for the reading to
- complete Swipe up for more detailed data

SpO2

- Swipe from right to left thrice on the main screen
- Click to start the measurement
- Swipe up for more detailed data




Breathe

- Click on the Menu button
- Scroll & select the Breathe icon Tap to start the breath training

How to access Other Menu

- Swipe from bottom to top once on the main screen to enter Menu




Brightness

- Swipe from top to bottom once on the main screen
- Go to Settings > Scroll & select Brightness
- Adjust the brightness as required

Dual theme

- Swipe from top to bottom once on the main screen
- Go to Settings > Scroll & select View mode
- Select the required Menu style




Sports Mode

- Click on the Menu button
- Scroll & select the Sports icon to explore 110+ different sports modes

Flashlight

- Click on the Menu button, Scroll & Select Flashlight
- Tap on it to turn on/off the flashlight





Weather Updates

- Click on the Menu button,
- Scroll & Select Weather icon to check for the forecast update


Camera Shutter

- Go to 'Fit Winner' app > Device > Take a photo
- Allow App to access Camera
- On the watch, Click on the Menu button > Scroll & select Camera
- Tap once to take a picture



Notifications

- Go to 'Fit Winner' app > Device > Message push
- Enable all the apps you wish to receive the notifications
- On the watch, Click on the Menu button > Scroll & select Messages
- You get to see all the notifications received from the selected apps



Music control

- Swipe from left to right once on the main screen
- You will be able to - change tracks, play/pause, control volume level, shuffle or repeat mode.
- You also have an option to select between local storage & from the connected mobile device, to play the songs.
- When in Local mode, you can even add TWS Earbuds and listen to the songs through the buds.

Note: You need to add the songs manually to the watch's local storage

• Connect your watch to the desktop via the charging cable

• You will be able to view the drive in your system

- Save the songs in the drive and you will be able to access it through the watch's local storage.

Voice Recorder

- Click on the Menu button > Scroll & select Recorder
- Click on the play button to start the recording, and stop to end
- Click on the “:” to view the saved recordings, you can also delete the saved files



Calculator

- Click on the Menu button > Scroll & select Calculator
- You will be able to do the basic calculations

Stopwatch

- Click on the Menu button > Scroll & select the Stopwatch option
- Click on the Play button to activate
- You also have pin the lap, pause, and reset options




Alarm

- Click on the Menu button > Scroll & select Alarm Clock
- You can add up new alarms, and also enable/disable them

Countdown

- Click on the Menu button > Scroll & select Timer
- Select the time & tap to start the timer



Always-on display

- Swipe from top to bottom once on the main screen
- Open Settings > Display > Always on
- You can set the time duration as well

Set Time

- Swipe from top to bottom once on the main screen
- Open Settings > Set Time
- You have the option to manually set the time & date of the watch



Power saver mode

- Swipe from top to bottom once on the main screen
- Open Settings > PowerSave
- Turn it On to save the battery of the watch

USB mode

Swipe from top to bottom once on the main screen

- Open Settings > USB Mode, you can now store the songs in the watch's local storage

You can shuffle between USB mode/charging mode

Note: This only works when the charging cable is connected to the system




Restart

- Swipe from top to bottom and open Settings > Scroll & select Reboot
- Click 'OK' to restart the watch

Factory Reset

- Swipe from top to bottom and open Settings > Scroll & select Reset
- Click 'OK' to reset



Power Off

- Swipe from top to bottom and open Settings > Scroll & select Shutdown
- Click 'OK' to turn off the watch

Disclaimer


- Optical sensors present on the back of the smartwatch are used to track the health vitals, do not rely on them for medical purposes.
- Crossbeats does not save your personal data and is not responsible for any data stored on FitWinner.
- Battery life may vary depending on usage patterns.
- The watch charging time might slightly vary depending on how much battery percentage has been depleted and the voltage supply for a charge.
- To receive notifications, calls and other alerts ensure your data and Bluetooth connections are stable.
- Our smartwatches are water resistant and are not suitable for diving. Also using them in the shower or any other prolonged water encounter can damage the watch.
- Use the smartwatch with appropriate apps to achieve the best results.
-


CHARGING GUIDELINES



- Use only 10W adapters for charging your smart watch.
- Caution against using high-power mobile adapters (beyond 10W), as this may lead to charger faults.
- Using adapters with higher power ratings can result in malfunctions and reduce the lifespan of device and your chargers.
- Users can contact customer support for any further assistance or clarification on concerns related to charging and power adapters.



 +91 9611293293

 +91 9611293293

 support@Crossbeats.com