



IGNITE
SPECTRA
MAX

USER
MANUAL



1) Premium metal casing

2) Rotating Crown

3) Silicone strap

4) Speaker

5) Microphone

6) Sensors

SPECIAL FEATURES

1.81" HD Touch Screen
Retina AMOLED Screen
Always-on
Bluetooth Voice **Calling**
120+ Sports modes
Rotating crown design
Built-in **Games**
AI **Health** trackers
Smart features enabled



Scan the QR code to download the smartwatch app
OR
Download 'Da Fit' App from the Playstore or iOS app
store

INSTALL STRAPS



- To attach the straps, slide the pin (the side opposite to quick-release lever) into the notch on the watch. Attach the strap with the clasp to the top of the watch.
- While pressing the quick-release lever inward, slide the other end of the strap into place.
- When both ends of the pin are inserted, release the quick-release lever.



REMOVE STRAPS


- To remove the straps, turn over the watch and find the quick-release lever.
- While pressing the quick-release lever inward, gently pull the strap away from the watch to release it.

CHARGING



- Charge the smartwatch before using it
- Full charge in less than 75 mins
- Connect the back of the watch to the magnetic charging pin available in the box
- Please use a 5V charging adapter or connect USB with the laptop

Note: Do not use any fast/dash charging adapters




CONNECT

Spectra_Max & Max_Audio

Note:

- All notifications, alerts, reminders, and data received from phone to watch or vice versa, will be connected over Spectra_Max
- For calls, Max_Audio needs to be connected



- Turn on the Bluetooth on your mobile phone
- Create an account and login to the app
- Open App > Devices > Add Device > choose Spectra_Max

NOTE: Once connected, you will receive all the notifications on the watch



MAX_AUDIO

- In the watch, swipe from top to bottom once on the main interface
- Open Settings > Enable Phone Call
- Open the phone's BT settings > Search for 'Max_Audio' in your BT list and connect
- Upon successful connection, you will be able to make/receive calls from the watch

FEATURES



Built in watch faces

- Press and hold the home screen
- You will enter the 'Watch face' Menu
- Scroll & select your favorite screen

Note: You can customize the watch faces from the app



Pedometer/distance/calories burnt

- Swipe from right to left once on the main screen
- You can see **all** the tracked data of steps, distance, and calories burnt
- **Scroll** down for more detailed analysis

FEATURES



Sleep monitor

- Swipe from right to left twice on the main screen
- You will be able to see the number of hours slept and also the light and deep sleep analysis
- Scroll down for more details



Heart rate

- Swipe from right to left thrice on the main screen
- Tap on the screen to start the reading
- You will be able to check your Heart Rate
- Scroll down for more details

FEATURES



Blood Pressure

- Swipe from right to left 4 times on the main screen
- Tap on the screen to start the reading
- Wait for 10-15 secs for the reading to complete
- Scroll down for more details



Breathe

- Swipe left to right once on the main screen
- Scroll and select the Breathing option
- Tap on the screen to start the breath training

FEATURES



SpO2


- Swipe from right to left 5 times on the main screen
- Tap on the screen to start the reading
- Wait for 10-15 secs for the reading to complete
- Scroll down for more details



Women's Health

- Open the Da Fit app > Devices > Others
- Scroll and enable the Physiological cycle reminder
- You can set up the period cycle details in the app
- In the watch, swipe from left to right once on the main screen
- Scroll & select Period

FEATURES



Automatic tracking on App

- Open the 'Da Fit' app & go to Devices tab
- Click on the 'Others' tab
- Enable the 'Continuous Heart Rate Detection'

This function, enables the watch to automatically measure health data every hour



Weather Updates

- Swipe from top to bottom once on the main screen
- Click on Weather icon to check the weather update

Vibration mode

- Swipe from top to bottom once on the main screen
- Click on the vibration icon to enable/disable it

OTHER FEATURES



Flash light

- Swipe from top to bottom once on the main screen
- Click on the Flash light icon to enable/disable it



Theatre mode

- Swipe from top to bottom once on the main screen
- Click on the Theatre mode icon to enable/disable it

OTHER FEATURES



Brightness

- Swipe from top to bottom once on the main screen
- Click on the Brightness icon to adjust the brightness of the watch accordingly



Low Power Mode

- Swipe from top to bottom once on the main screen
- Click on the Settings icon
- Scroll & Enable the Low Power Mode to save the battery

OTHER FEATURES



Voice Assistant

- Swipe from top to bottom once on the main screen
- Click on the Settings icon
- Scroll & Select AI voice to start using the voice assistants

Note: The voice assistants will be the same as on your smart phone



Music control

- Swipe from right to left on the main screen for 7 times
- You will be able to - change tracks, play/pause.

OTHER FEATURES



Sports

- Swipe from left to right once on the main screen
- Scroll & select 'Training' icon to explore 27 different activities



Message notifications

- Swipe from bottom to top once on the main screen
- You will be able to see your latest messages



Camera Shutter

- Swipe from left to right once on the main screen
- Scroll & select the Shutter icon
- In the app, go to Devices tab > Shutter > Give camera permission
- In the watch, click to capture



Calculator

- Swipe from left to right once on the main screen
- Scroll & select the Calculator icon
- You will be able to do the basic calculations

OTHER FEATURES



Alarm

- Swipe from left to right once on the main screen
- Scroll & select the Alarm icon
- You can enable/disable the already set alarm from the app
- In the app, go to Devices > Alarms > Set your alarms accordingly



Stopwatch

- Swipe from left to right once on the main screen
- Scroll & select the 'Stopwatch' icon and activate
- You also have Pause, pin the lap, and reset options

OTHER FEATURES



Timer

- Swipe from left to right once on the main screen
- Scroll & select the 'Timer' icon and select the timing to activate

Add components

- Swipe from right to left to find the '+' symbol
- You can add shortcuts of your choice

OTHER FEATURES



Call Reset

- Swipe from top to bottom once on the main screen
- Click on the 'Settings' icon, scroll & select the 'Call Reset' icon to reset the calling related data



Reset

- Swipe from top to bottom once on the main screen
- Go to Settings > System > Reset
- Click '✓' to reset or '✕' to cancel



Restart

- Swipe from top to bottom once on the main screen
- Go to Settings > System > Restart
- Click '✓' to restart or '✕' to cancel

OTHER FEATURES




Power

- Swipe from top to bottom once on the main screen
- Go to Settings > System > Power Off
- Click '✓' to turn off the watch or '✕' to cancel

Disclaimer


- Optical sensors present on the back of the smartwatch are used to track the health vitals, do not rely on them for medical purposes.
- These smartwatches sometimes can accidentally detect non-surface object reading due to differences in pressure on the motion sensors.
- Crossbeats will not be responsible for in-app purchases made via Da Fit.
- Crossbeats does not save your personal data and is not responsible for any data stored on Da Fit.
- Battery life may vary depending on usage patterns.
- The watch charging time might slightly vary depending on how much battery percentage has been depleted and the voltage supply for a charge.
- To receive notifications, calls and other alerts ensure your data and Bluetooth connections are stable.
- Our smartwatches are water-resistant and are not suitable for diving. Also using them in the shower with harsh chemicals can damage the watch.
- Use the smartwatch with appropriate apps to achieve the best results.


CHARGING GUIDELINES




- Use only 10W adapters for charging your smart watch.
- Caution against using high-power mobile adapters (beyond 10W), as this may lead to charger faults.
- Using adapters with higher power ratings can result in malfunctions and reduce the lifespan of device and your chargers.
- Users can contact customer support for any further assistance or clarification on concerns related to charging and power adapters.



 +91 9611293293

 +91 9611293293

 support@crossbeats.com