



DEFLEX HEAT SHIELDS FOR INDIAN CHIEFTAIN

- WARNING** This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.
- CAUTION** This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.
- ATTENTION** This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation. Read completely and understand the instructions prior to starting installation.

NOTE: Ciro products are designed and manufactured under very strict quality control. Ciro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a limited lifetime warranty against LED failure. Ciro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed, unmodified and maintained. Ciro will not be liable for any consequential and incidental damages, including labor, or non-Ciro products. Please visit Ciro3d.com for our complete warranty policy.

Included Parts



Installation Instructions:

1. Park on a level surface and shut off the motorcycle. Ensure that the engine has time to cool before installation.
2. Clean area on side cover with an ammonia based cleaner to thoroughly remove any wax, dirt, or other factory coatings. Fig. 1
3. Dry fit Deflex Heat Shields to understand correct position. There should be approximately 1/2" clearance between the top edge and the fuel tank. Fig. 2 The side should follow the body line on the side cover as shown in Fig. 3.
4. Remove backing tape and adhere to side cover. Press firmly for 30-60 seconds. Fig. 4
5. Adhesive is rideable in one hour and cures fully in 24 hours.

