



LED LIGHTED SADDLEBAG HINGE COVERS

WARNING This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.

CAUTION This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.


ATTENTION This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation. Read completely and understand the instructions prior to starting installation.

NOTE: Ciro products are designed and manufactured under very strict quality control. Ciro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a lifetime warranty against LED failure. Ciro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed and maintained. Ciro will not be liable for any consequential and incidental damages, including labor, or non-Ciro products. Please visit Ciro3d.com for our complete warranty policy.

Installation Instructions:

- Step 1 Park on a level surface, allow the vehicle to cool.
- Step 2 Remove the seat and locate the black OEM 6-pin wiring harness, Fig.6, and install the wiring adapter.
- Step 3 From the wiring adapter, route each output to the corresponding side of the motorcycle. The output with the brown wire goes to the right side, the output with the violet wire goes to the left side.
- Step 4 Connect the LED Lighted Saddlebag Hinge Covers to the wiring adapter to familiarize yourself with how they function. Disconnect the LED Lighted Saddlebag Hinge Covers and set aside to begin installation.
- Step 5 Starting with one side of the motorcycle, open the saddlebag and remove the two tether screws shown in Fig.1. Protect surfaces from damage as the saddlebag lid lays open. Set the screws aside for reinstallation.
- Step 6 Hold the factory faceplate in hand and remove the three torx head screws securing it shown in Fig.2. The faceplate and screws will not be reused.
- Step 7 Attach the LED Lighted Saddlebag Hinge Cover using three of the supplied screws. Use a medium strength liquid thread locker. Tighten to 40-45 in-lbs.
- Step 8 Use a "step drill" to create a 9/16" hole in the location shown in Fig.3(A). Pass wire though hole to the interior of saddlebag.
- Step 9 Install an included grommet onto the wire and push carefully into the drilled hole.



Step 10 Reinstall tether using previously removed screws.

Step 11 Remove saddlebag from motorcycle, place on work surface making sure to protect painted surfaces.

Step 12 Measure 2" down from the front saddlebag retainer, Fig.3(B), use a "step drill" to create a 9/16" hole.

Step 13 Route the wire out of saddlebag interior. Install an included grommet onto the wire and push carefully into the drilled hole.

Step 14 Add retainers and cable ties to the inside of the saddlebag to secure the wire as shown in Fig.4.

Step 15 Reinstall saddlebag.

Step 16 Repeat steps 5 through 15 on the opposite side of the motorcycle.

Step 17 Route the LED Lighted Saddlebag Hinge Cover wires out of the saddlebag and under the seat to the wiring harness as shown in Fig.5. Secure excess wire and reinstall the seat being careful not to pinch or damage wires.

ATTENTION

Unplug the connectors of the LED Lighted Saddlebag Hinge Covers prior to removing the saddlebags to prevent damage.

