

FS PERFORMANCE ENGINEERING

Adjustable Splitter Support Rods - What you need to know

IF YOU ORDERED ANODIZED COLORED RODS

 \rightarrow We have <u>**CERAMIC COATED</u>** your barrels to protect them from UV exposure. We recommend ceramic coating them every 3-6 months as prolonged sun exposure causes fading.</u>

 \rightarrow Do NOT use harsh soaps (high pH) to clean the support rods. The chemicals will break down the seal and cause fading/discoloration - usually to purple. We recommend pH neutral solutions.

What You'll Need

- 3/16" Allen Wrench
- 7/16" Open End Wrench
- 1/2"Open End Wrench
- 3/4" Open End Wrench
- Drill & 5/16" Drill Bit

What's Important

- Use BLUE threadlocker (not red) on the bolt threads upon final installation
- Do NOT use threadlocker on the heim joint threads
- Account for the length and hole locations BEFORE final installation
- Hold the 7/16" wrench flats to tighten the 1/2" jam nuts against the barrels
- Hold the 3/4" wrench flats to tighten the 3/16" allen head bolts/washers against the splitter & rod end piece
- Use the washers underneath the bolts on the underside of splitter, and inside of the bumper/mounting point
- Tighten bolts appropriately we like "very tight". If you are afraid of scratching your parts with the wrenches then use a soft paper towel in between.

<u>Maintenance</u>

Your heim joints are prone to weathering. We recommend adding anti-seize onto the heim joint threads every couple months. It is also a good idea to periodically move the jam nuts up and down the heim joint threads to prevent build up, or even ceramic coating any exposed thread!

Two More Things

1.) Send us pictures & use **#FSPerformanceEngineering** on social media

- 2.) ENJOY YOUR NEW SUPPORT RODS!
- 3.) We LOVE great reviews. It keeps us in business and we appreciate it greatly!

For questions feel free to give us a call at (661) 809-0954 Or shoot us an email at <u>costas@fspeinc.com</u> or <u>jim@fspeinc.com</u>