


1. Take the part B and using the screwdriver (P), install the dowels (L) as shown in the illustration.
2. Using the screwdriver (P), close the eccentric ties located on the parts (D, E, F, G) by turning them by 180degrees clockwise, as shown in the illustration







https://www.facebook.com/wowhelperco/



https://www.pinterest.com/PetsHelperCo/



Instagram



Facebook



Pinterest












Etsy









- 1. Take the elements C, E, G, H.
  2. Take the parts (G and E) and using the screwdriver (P)
- using the screwdriver (P), install the dowel (L) as shown in the illustration.
- 3. Using the screwdriver (P), close the eccentric ties locatedon the part (C) by turning them

by 180degrees clockwise, as shown in the illustration

4. Fasten the parts from below with screws (M) and fasten the parts from above with screws (N), as shown in the illustration using hex wrench (O).







1. Take the elements C, D, H, J.


2. Take the parts (D and E) and using the screwdriver (P), install the dowel (L) as shown in the illustration.

3. Using the screwdriver (P), close the eccentric ties locatedon the part (C) by turning them by 180 degrees clockwise, as shown in the illustration

4. Fasten the parts from below with screws (M), as shown in the illustration using hex wrench (O).

!!! Part (D) is attached last !!!







2. Take the parts (D and F) and using the screwdriver (P), install the dowel (L) as shown in the illustration.

3. Using the screwdriver (P), close the eccentric ties located on the part (C) by turning them by 180degrees clockwise, as shown in the illustration

4. Fasten the parts from below with screws (M) and fasten the parts from above with screws (N), as shown in the illustration using hex wrench (O).