

For LIGHT Colored Fabrics - Inkjet Transfer Sheets Instructions

Items needed:

- Inkjet printer
- White or light colored t-shirt, canvas bag, apron, etc. (cotton or cotton/poly blend for best results)
- HeatnBond® Inkjet Transfer Sheet™ - Light
- Household iron
- Pillowcase
- Waist-high (or lower) hard, smooth, heat-resistant surface (DO NOT use ironing board)
- Pressing sheet (included-DO NOT discard)


1. Create & Print:

Design your image using your own graphics, photos and/or text in your favorite computer software. For best results, select the closest match below in your printer settings:

Quality: best or high quality

Media: photo paper or iron on t-shirt transfer

Orientation: Select mirror image (reverse image). Mirror image is required when using light transfer sheets so graphics appear correctly when viewed on the garment or project. Mirror Image may be referred to as “t-shirt” mode or “reverse” mode in the printer’s settings. If this setting is not available, reverse or mirror your design in your favorite editing software.



Remove all paper from your inkjet printer and place one transfer sheet in the paper tray so the inkjet image prints on the unmarked white side. Print your image and allow it to dry for 30 minutes. Cut out printed design, leaving a ¼ -inch narrow border around the image. Keep corners rounded to avoid lifting during ironing or washing.

2. Preparation:

Pre-heat iron for 3 minutes to high (cotton) setting **no steam**. It is recommended that the water reservoir be empty. Place a pillowcase on a hard, smooth, heat-resistant surface. Place t-shirt, canvas bag, apron, etc. on the pillowcase and iron for 1-2 minutes to release moisture and remove wrinkles. Gently stretch fabric by tugging on the sides and smooth out with hands.

3. Iron: *(read all directions before proceeding)*

Ironing should be done by an adult or with adult supervision.

***When ironing, it is important to apply heavy and constant pressure (iron with two hands and ample body pressure).**


Pressure is your friend, the more the better.

It is also crucial that all areas of the image receive equal time, heat and pressure when ironing. Pay special attention while ironing to the corners and edges. Insufficient time, pressure or heat will produce poor results.


Place the HeatnBond® Inkjet Transfer Sheet™ with the printed image face down in desired position onto project.

Ironing Times			
Page Size	Step 1: Iron	Step 2: Spin & Iron	Total Ironing Time
Full Page	90 seconds	90 seconds	180 seconds
Half Page	45 seconds	45 seconds	90 seconds
Quarter Page	30 seconds	30 seconds	60 seconds

Step 1: Iron the HeatnBond® Inkjet Transfer Sheet™ using a straight continuous motion with heavy pressure forward and back while gliding the iron from side to side. Repeat until designated time in step 1 on chart above is reached.



Step 2: Spin your garment or project 180° and continue ironing until designated time in step 2 on chart above is reached.



Peel off liner while hot, using a smooth, even motion. If the image begins lifting, it means you have not applied enough pressure and/or heat. Stop and re-iron the edges and corners.

4. Finishing:

After peeling off the transfer liner, place the enclosed pressing sheet over the entire transferred image. With firm pressure, iron across pressing sheet for 45-60 seconds. Peel the sheet off while hot. The transfer is now finished!

Care Instructions:

- Wait 24 hours before washing
- Turn garment or project inside out
- Machine wash cold, with mild detergent
- Do not use bleach or bleach alternatives
- Remove promptly after washing as the color may bleed if left in the washer
- Tumble dry low or lay flat to dry
- DO NOT iron directly on transfer. If necessary, cover with pressing sheet.



Visit our website for detailed instructions and video tutorials on this product. This product is for standard inkjet printers only. Store unused product in the original packaging in a cool, dry place.